

PowerWorld Simulator

Auxiliary File Format Description for Specifying Contingency Definitions and Remedial Actions

Date : December 1, 2015 (Simulator Version 19 Release)

Last Update : August 11, 2022 (Simulator Version 22 Patch)

Prepared by : James Weber, Ph.D.
Director of Software Development
PowerWorld Corporation
(217) 384-6330 ext. 13
weber@powerworld.com



PowerWorld
Corporation

2001 South First Street
Champaign, IL 61820
(217) 384-6330
www.powerworld.com

- Updates : December 18, 2015 (Simulator 19 patch update)
- Added fields `EvalInRef1` . . . `EvalInRef8` to `ModelExpression`
 - Added field `ObjectFieldEvalRef` to `ModelConditionCondition`
- May 3, 2016 (Simulator 19 patch update)
- Added Interface Merit Order Open actions
- January 26, 2017 (Simulator 19 patch update)
- Updated first figure describing `TimeDelays` in `ModelFilter` section to be consistent with the second figure to avoid confusion
 - Updated documentation of fields to the 3WXformer record for `Amps`, `MVA`, `MW`, `Mvar`, `Percent` and `PercentMVA`
- January 31, 2017
- Updated documentation of fields for the `DCTransmissionLine` record for `MWRect`, `MWInv`, `MvarRect`, `MWInv`, `AmpsDC`, `Online`, `DerivedStatus`, `DerivedOnline`, `VdcRect`, `VdcInv`
- March 2, 2017
- Cleaned up some typos for “LookupTable” and “Option,Value” references.
 - Modified lookup examples to make it obvious that floating point numbers can be used
 - Made it clear that <SUBDATA> tags for `ModelExpressions` must start a line of text
- March 28, 2017
- Added section 2.4.19 and 2.4.20 for `MTDCRecord` and `MTDCConverter` objects. Also added respective Key Field list in Section 2.3
- August 17, 2017
- Fixed typo of field name “ByPass” for a `Branch` object in Section 2.4
 - Cleaned up language in `Branch Actions` in Section 5.15.5
 - Added more description of `BlankZero` fields in Section 5.11
- March 15, 2018
- Added Section 2.5 along with explicit declaration of (key), (required) and (optional, default ***) notation throughout the document
- May 14, 2018
- Fixed some typos in `Injection Group` field descriptions where we were referring to `Substations`
 - Added new “SELF CLEAR” modifier on a fault action for transient stability
- February 5, 2019
- Fixed typo in `Contingency actions` table for `Interface` objects. The `SETTO` documentation implied you could perform a `MWMERITORDER` which you can not
 - Fixed typo in `Contingency actions` table for `Substation` objects. The `SETTO` and `CHANGE BY` documentation regarding `REF` values is now more clear.
- August 11, 2022
- Added field `CriteriaCheckOnce` to `RemedialActionElement`

Table of Contents

1	DOCUMENT SUMMARY	1
2	BASIC FILE FORMAT RULES	2
2.1	SYNTAX RULES.....	2
2.1.1	Naming Conventions.....	2
2.1.2	Handling quotes inside of quoted strings	2
2.2	OBJECT TYPE STRINGS.....	3
2.2.1	Branch Objects (2-terminal AC devices)	3
2.3	SPECIFYING AN OBJECT USING A STRING	3
2.3.1	Special Notes to Maintain Compatibility between PowerWorld and EPC Power Flow File format conventions	4
2.3.2	Special Note on Branch and LineShunt objects and Multi-Section Lines.....	5
2.3.3	Special Note on Branch objects and Three-Winding Transformers.....	6
2.3.4	Primary Keys	7
2.3.5	Secondary Keys	7
2.3.6	Label Identifiers	7
2.3.7	Naming Collisions.....	8
2.4	OBJECT FIELD DEFINITIONS	8
2.4.1	Branch and MSBranch Fields	8
2.4.2	Bus Fields	11
2.4.3	Gen Fields	12
2.4.4	Load Fields	12
2.4.5	Shunt Fields.....	13
2.4.6	Area Fields	13
2.4.7	Zone Fields	14
2.4.8	Substation Fields.....	14
2.4.9	Injection Group Fields.....	15
2.4.10	Interface Fields	15
2.4.11	3WXFormer Fields.....	16
2.4.12	DCTransmissionLine Fields.....	17
2.4.13	LineShunt Fields	17
2.4.14	VSCDCLine Fields.....	18

2.4.15	ModelExpression Fields	18
2.4.16	VoltageControlGroup Fields.....	18
2.4.17	Model Filter Fields	19
2.4.18	Model Condition Fields	19
2.4.19	MTDCRecord Fields.....	19
2.4.20	MTDCConverter Fields	19
2.5	DOCUMENTATION OF KEY, REQUIRED, AND OPTIONAL FIELDS.....	20
3	FILTERING AND DEVICE FILTERING	21
3.1	FILTER, CONDITION (FILTERING)	21
3.2	NESTED FILTERS.....	23
3.3	DEVICE FILTERING	23
3.4	SPECIFYING A FILTER OR DEVICE FILTER USING A STRING.....	24
4	SCRIPT SECTIONS TO SET DEFAULTS	25
5	DATA RECORD STRUCTURES.....	26
5.1	AREA (SETTINGS FOR CONTINGENCY MODELING)	28
5.2	BUS (SETTINGS FOR CONTINGENCY MODELING)	29
5.3	VOLTAGE CONTROL GROUP (SETTINGS FOR CONTINGENCY MODELING).....	29
5.4	SHUNT VOLTAGE CONTROL GROUP (SETTINGS FOR CONTINGENCY MODELING).....	30
5.5	GEN (SETTINGS FOR CONTINGENCY MODELING).....	31
5.6	SHUNT CONTROL (SETTINGS FOR CONTINGENCY MODELING).....	32
5.7	SIM_SOLUTION_OPTIONS_VALUE	33
5.8	CTG_OPTIONS_VALUE.....	35
5.8.1	Using Transient Stability Dynamic Models in Steady State Contingency Analysis.....	37
5.9	INTERFACE AND INTERFACEELEMENT.....	39
5.10	INJECTIONGROUP AND PARTPOINT.....	41
5.11	MODELEXPRESSION.....	43
5.11.1	Lookup Tables	44
5.11.2	Functions Available for Expression String.....	45
5.12	MODELCONDITION AND MODELCONDITIONCONDITION	46
5.13	MODELFILTER AND MODELFILTERCONDITION	49
5.13.1	Handling DisableIfTrueInRef for ModelFilterConditions.....	50
5.13.2	Calculated Time Delay of a Model Filter	50
5.14	RELATIONSHIPS BETWEEN OBJECTS	52
5.15	CONTINGENCY, CONTINGENCYELEMENT (TSCONTINGENCY, TSCONTINGENCYELEMENT)	54
5.15.1	Special Treatment for ContingencyElement Object Field.....	56

5.15.2	Criteria Status	56
5.15.3	Calculated Time Delay	57
5.15.4	Contingency Actions	57
5.15.5	Contingency Actions with 'Value' strings	58
5.15.6	Special InjectionGroup Contingency Action for Generators by Merit Order	77
5.15.7	Special Interface Contingency Action for Merit Order Open	77
5.16	REMEDIALACTION AND REMEDIALACTIONELEMENT	78
5.17	MODELRESULTOVERRIDE	79
6	STEADY STATE CONTINGENCY ANALYSIS WITH RAS AND STABILITY MODELS	80
7	TRANSIENT STABILITY CONTINGENCY ANALYSIS PROCESSING WITH RAS	81
8	LIMIT MONITORING SETTINGS	82
8.1	LIMITSET	82
8.1.1	Branch and Interface relationship to LimitSet	84
8.1.2	Bus relationship to LimitSet	84
8.2	AREA (SETTINGS FOR LIMIT MONITORING)	85
8.3	ZONE (SETTINGS FOR LIMIT MONITORING)	85
8.4	BUS (SETTINGS FOR LIMIT MONITORING)	86
8.5	BRANCH (SETTINGS FOR LIMIT MONITORING)	86
8.6	INTERFACE (SETTINGS FOR LIMIT MONITORING)	87
8.7	CUSTOMMONITOR	87
9	FINAL DEMONSTRATION	89
9.1	SAVING A FILE IN THIS FORMAT	89
9.2	SAVING A FILE IN THIS FORMAT WITH MORE FLEXIBILITY	91
9.3	LOADING A FILE IN THIS FORMAT INTO POWERWORLD SIMULATOR	92
9.4	EXAMPLE FILE IN THIS FORMAT	93

1 Document Summary

This document provides a set of data record definitions with the goal of enabling the exchange of all data related to running power flow and transient stability contingency simulations among engineers throughout the electric utility industry. This will include any information needed to define the contingencies as well as remedial action schemes (RAS) and post-contingency solution options important to accurately simulate the power flow based contingency solutions. Specifications for data record definitions necessary to define what is monitored in a contingency processor are also given.

This initial definition will achieve most of this objective, and in particular, will define and document record structures and a file format that can be used to specify the following:

1. File format syntax rules (Section 2.1), Syntax for defining references to other objects in the power system model from within this text file (Sections 2.2 and 2.3), Syntax for field names (Section 2.4), Syntax for Filtering (Section 3), and Syntax for simple SCRIPT section (Section 4)
2. Options for how area, bus, and generators respond during a post contingency power flow solution, meant to model post-transient behavior (Sections 5.1, 5.2, and 5.5)
3. Options for how a contingency processor solution is performed (Sections 5.7 and 5.8)
4. Generic Structures for defined RAS logic and actions in the power flow contingency processor (Sections 5.10, 5.11, 5.12, and 5.13)
5. Contingency records for use by either a *power flow* contingency processor or a *transient stability* processor (Section 5.13.1)
6. Remedial Action Schemes appropriate for a *power flow* contingency processor (Section 5.16)
7. Use of transient stability dynamic models in the power flow contingency analysis solution environment (Section 5.8.1)
8. Specification of Limit Monitoring Settings (Section 8)

In addition to defining and documenting the record structures and file formats, a demonstration of reading and writing this information from a text file format is shown in Section 9. The ability to read and write this new format has been integrated into PowerWorld Simulator.

While this will be a very good list of accomplishments that is achieved by these data definitions, it does leave a hole in the ability to immediately, completely and generically specify RAS for use in the *transient stability* environment. The long-term way in which RAS will be modeled in the transient stability environment and how this modeling information will be shared among engineers is not fully formed. There is not a broad agreement yet within the engineering community on how this should be done. PowerWorld Corporation suspects that there are dozens of variations of what the final environment might look like in the heads of different engineers.

While this hole represents a portion of this overall vision that PowerWorld Corporation is highly interested in, we think that the first step in getting to the power engineering community's long-term solution is to concentrate on getting the list above completed. This will give everyone who uses these data definitions an opportunity to study what is available now. It will then help better inform decisions for follow-on efforts related to modeling RAS in the transient stability environment.

2 Basic File Format Rules

2.1 Syntax Rules

The following is a list of general syntax rules that apply throughout this file format:

- All strings are case *insensitive*. Thus "Contingency" is treated the same as "CONTINGENCY" or "contingency" or "CoNtInGeNcY". This will be true for names, fields, and any key words in the file syntax.
- Any line that starts with the two backslashes (//) will be treated as a comment and be ignored when parsing the file. Text appearing after two backslashes will also be treated as comments.
- Blank lines of text are ignored and skipped
- Many text lines are space delimited strings that use double quotes (") as string unifiers. Note that these are straight quotes. Smart quotes such as “ ” are not supported by the format so be careful when copying and pasting from some text editors.
- Any TAB characters in the text file will be treated as a single space when read by a file parser
- Consecutive spaces in the position of a delimiter are treated as a one string delimiter

2.1.1 Naming Conventions

There are many objects in this file format that have a name including Model Conditions, Model Filters, Model Expressions, Contingencies, Remedial Action Schemes, and Injection Groups. There will be no restrictions placed on the length or content of the names in this format, except that they are limited to ASCII characters. Obviously the user should use discretion and not create names with 1,500 characters, but the file format will not specifically preclude this bad behavior.

2.1.2 Handling quotes inside of quoted strings

There are many places in the file format that require a string enclosed in either double quotes or single quotes. Sometimes there are even double quote strings that contain a space delimited string that uses single quotes inside of the double quotes.

For example, to specify a particular area, a space delimited string containing the string AREA followed by the name of the area enclosed in single quotes is used. The entire string is then enclosed in double quotes. However, if the name of the area contains either double or single quotes, this could cause trouble in the text parser. To accommodate this potential, the format specifies that such quotes or double quotes be repeated if contained inside of a string. Consider the examples in the following table:

Area Name	Object ID String
WECC's Office	"AREA 'WECC's Office'"
"HIGH" Point's	"AREA '"HIGH"' Point's'"

In most situations such as object names, using quotes or double quotes is highly discouraged. However, it may be natural to include quotes in some of the fields in this document such as the Memo field for a contingency. The memo field is a free-form string in which the user includes notes about the contingency. Thus in general, this format will not enforce any requirement regarding quotes because in the end it is not necessary. The format will require that software parsers handle these situations.

2.2 Object Type Strings

There are many places in this file format where a particular object type must be referenced. All object type strings must not contain any spaces. The following is a list of some of the allowable object types:

```
Branch, Bus, Gen, Shunt, Load, Area, Zone, Substation, InjectionGroup, Interface,
3WXFormer, DCTransmissionLine, LineShunt, VSCDCLine, ModelExpression, Contingency,
ContingencyElement, TSContingency, TSContingencyElement, RemedialAction,
RemedialActionElement, CTG_Options_Value, Sim_Solution_Options_Value, LimitSet,
CustomMonitor, ModelFilter, ModelFilterCondition, ModelCondition,
ModelConditionCondition, Filter, Condition
```

2.2.1 Branch Objects (2-terminal AC devices)

An object type BRANCH signifies either an AC transmission line, 2-winding transformer, a series capacitor or reactor, or any AC device which connects two buses. Within a BRANCH there is then a field BranchDeviceType which can have the following entries: Line, Transformer, Series Cap, Breaker, Disconnect, ZBR, Fuse, Load Break Disconnect, Or Ground Disconnect. This enumeration of device types comes from the Common Information Model (CIM) specification, except that a ZBR is called a Jumper in CIM. In general a user may toggle between these various device types, with the exception of a Transformer. Once an object is specified as a transformer it may not be turned back into a another branch device type.

2.3 Specifying an object using a string

There are many places in this file format where a particular object must be referenced. In these situations a string will be specified that is enclosed in double quotes. The object string will be space delimited with the first string representing the object type. Object type strings from Section 2.2 will never have spaces in them. Following the object type string there will be identification information for the object. This information allows for three potential formats that the software will need to parse: Primary Keys, Secondary Keys, or Labels. While each object can have labels, each different object type can have a different number of key fields. The key fields for the various object types are as follows:

Object Type	Primary Key Fields	Secondary Key Fields
Gen	BusNum ID	BusNameNomkV ID
Bus	Number	NameNomkV
Branch	BusNumFrom BusNumTo Circuit	BusNameNomkVFrom BusNameNomkVTo Circuit
Branch <i>(Special treatment for interacting with Branches using the EPC format)</i>	MSBusNumFrom MSBusNumTo Circuit Section	MSBusNameNomkVFrom MSBusNameNomkVTo Circuit Section
Load	BusNum ID	BusNameNomkV ID

Shunt	BusNum ID	BusNameNomkV ID
Area	Number	Name
Zone	Number	Name
Substation	Number	Name
InjectionGroup	Name	<i>none available</i>
Interface	Name	Number
3WXformer	BusNumPri BusNumSec BusNumTer Circuit	BusNameNomkVPri BusNameNomkVSec BusNameNomkVTer Circuit
DCTransmissionLine	BusNumRect BusNumInv Circuit	BusNameNomkVRect BusNameNomkVInv Circuit
LineShunt	BusNumFrom BusNumTo BusNumLoc Circuit ID	BusNameNomkVFrom BusNameNomkVTo BusNameNomkVLoc Circuit ID
LineShunt <i>(Special treatment for interacting with Branches using the EPC format)</i>	MSBusNumFrom MSBusNumTo MSBusNumLoc Circuit ID Section	MSBusNameNomkVFrom MSBusNameNomkVTo MSBusNumLoc Circuit ID Section
VSCDCLine	Name	<i>none available</i>
ModelExpression	Name	<i>none available</i>
MTDCRecord	Number	<i>none available</i>
MTDCConverter	BusNumAC BusNumDC MTDCNumber	<i>none available</i>

2.3.1 Special Notes to Maintain Compatibility between PowerWorld and EPC Power Flow File format conventions

The feature above for using the Interface Number as a secondary key field has been added to Simulator Version 18. The Interface name remains the primary key and PowerWorld Simulator requires that the name be unique for all interfaces. Interface numbers within PowerWorld Simulator have traditionally not been maintained by our user base and as a result when writing out the information to this format, PowerWorld Simulator will always write the name of the interface. We can however read files which use the number as a key identifier.

The three-winding transformer key identifiers in PowerWorld Simulator are slightly different than what is shown in the previous table, however for the purposes of writing out and reading this format, changes


have been made to PowerWorld Simulator Version 18 so that the key identifiers as shown in the table can be used. This makes the format more consistent with those used by PSS/E and PSLF.

2.3.2 Special Note on Branch and LineShunt objects and Multi-Section Lines

In PowerWorld Simulator as well as PSS/E RAW files, branch records have 3 unique identifiers: “from bus”, “to bus”, and “circuit ID”. There is also a concept of a multi-section line, but this is purely an aggregation object that groups together a series of branches whose statuses are coordinated. Thus within a multi-section line, when one branch changes status, then all branches within the multi-section line group change status to stay coordinated with other branches. The unique identifiers within the various branches in the multi-section line include the intermediate bus numbers or name/kv combinations.

Within a PSLF EPC file format however, the concept of a multi-section line is fundamentally embedded within the concept of the EPC format’s branch record. Thus instead of only 3 identifiers, there are 4 identifiers for a branch within the EPC format: “from bus”, “to bus”, “circuit ID”, and “section number”. There can then be a number of sections that traverse the from bus toward the to bus.

As an example, consider the multi-section line shown below which has 7 sections in series that traverse from bus 40489 to 40687. Normally within PowerWorld Simulator (and a PSS/E RAW file) the 4th section would be identified as "Branch 40704 40706 2". Within GE PSLF however, this branch would instead be identified as "Branch 40489 40687 2 4". Both of these have the same meaning but there are fundamental differences in the identifiers used.



This is something that must be managed by this format. To be consistent with the file format traditionally used within Western Electricity Coordinating Council (WECC) to transfer power flow data between members (which is the EPC file), the format described in this document will force consistency with the EPC file concept of a branch record. The intermediate bus numbers 40700 through 40710 above would not appear in the EPC file format at all and thus are not part of the normal WECC data formats. Because this format does not create any branches, but only refers to branches to define contingency events, model conditions, and so forth, this can be achieved within the PowerWorld structure and is achievable by any other software tool which manages multi-section line records. If the file format involved the creation of branches then this would be more troublesome, but for the RAS and contingency format this is acceptable.

Therefore, anywhere that a branch is referred to using the object ID string with primary or secondary keys as described in the following sections, if the branch is part of a multi-section line, then 4 identifiers

must be used and parsed accordingly. For branches that are not part of a multi-section line when reading in a file in this format the parser must handle the omission of the identifier if it's not needed. In addition a parser must be able to ignore this 4th identifier in a file if it's not needed. When identifying branches using labels this is not relevant and the object ID string is simply "Branch 'My Label'".

A similar convention will be used for the LineShunt object. If a line shunt exists with Shunt ID "A" at bus 40706 at Section 6 of the multi-section line as shown in the picture above, then normally PowerWorld Simulator would refer to this Line Shunt as "LineShunt 40708 40710 40708 2 A". To maintain compatibility with the treatment of multi-section lines in the EPC file format this must be expressed instead as "LineShunt 40489 40687 40489 2 A 6". The Section ID has been appended to the end of the key field lists. Also note that the 3rd identifier shows the terminal bus identifier for the multi-section line record which is on the same side as the line shunt relative to its branch.

Again, anywhere that a LineShunt is referred to using the object ID string with primary or secondary keys as described in the following sections, if the branch to which the LineShunt is connected is part of a multi-section line, then 6 identifiers must be used and parsed accordingly instead of 5. Note that when identifying line shunts using labels this is not relevant and the object ID string would be simply "LineShunt 'My Label String'".

2.3.3 Special Note on Branch objects and Three-Winding Transformers

In PowerWorld Simulator as well as PSLF files, when referring to a particular winding of a three-winding transformer, the unique identifiers include the bus identifier for the internal bus (also called the star bus). Within a PSS/E RAW file however, the identifying information for these internal buses is not persistent (for example, in a RAW file the internal buses of three-winding transformers do not exist in the bus table). This is similar to the previous concept in the EPC format where the intermediate buses of multi-section lines do not exist. As a result, to help allow with PSS/E support when reading or writing a particular winding of a terminal of a three-winding transformer we will allow an alternate way to describe the branch. This will effect situations such as defining interface definitions, or when monitoring the flow on a winding branch of a three-winding transformer in a Model Condition.

Consider a three-winding transformer which has terminals at buses 10001, 10002 and 10003 and has a circuit of AB and an internal bus number of 10004. In the past in Simulator and PSLF one would refer to one of the windings using the internal star bus number. Instead we will now identify the branch using 4 unique identifiers that include the three terminal buses and the circuit ID. The branch will then be interpreted to represent the winding associated with the first terminal bus listed. This means that the order of the second and third buses lists does not matter. As a result our three windings would be represented as follows.

Winding	Traditional Identifying String in PSLF and Simulator	Modified Method which will not use the Internal Bus Number
Primary	"BRANCH 10001 10004 'AB'"	"BRANCH 10001 10002 10003 'AB'" or "BRANCH 10001 10003 10002 'AB'"
Secondary	"BRANCH 10002 10004 'AB'"	"BRANCH 10002 10001 10003 'AB'" or "BRANCH 10002 10003 10001 'AB'"

Tertiary	"BRANCH 10003 10004 'AB'"	"BRANCH 10003 10001 10002 'AB'" or "BRANCH 10003 10002 10001 'AB'"
----------	---------------------------	---

2.3.4 Primary Keys

Primary keys for many objects are the bus numbers associated with the object and some string identifiers. The format of the object string using primary keys is then the object type and then a list of keys separated by spaces. If a key string has any spaces, a *single* quote must be used to enclose the key. Note: A single quote is used because throughout the format these entire object strings are enclosed in double quotes.

General Format	"Objecttype 'key1' 'key2' 'key3'"
Generator	"GEN 23 '12'"
Bus	"BUS 33"
Branch	"BRANCH 23 29 'AB'"
Branch	"BRANCH 23 29 'AB' 4" <i>(multi-section line branch)</i>
Branch	"BRANCH 23 29 66 'AB'" <i>(three-winding transformer winding)</i>
3WXformer	"3WXFORMER 23 29 66 'AB'"
Area	"AREA 51"
Zone	"ZONE 93"
Substation	"SUBSTATION 37"

2.3.5 Secondary Keys

Secondary keys for some objects are also available. These are often a combination of the bus name and nominal kV value of a bus, or for other objects they replace the numbers with names. Not all objects will have secondary key fields. For example, an injection group has only a name.

General Format	"Objecttype 'key1' 'key2' 'key3'"
Generator	"GEN 'Bus 23_138.00' '12'"
Bus	"BUS 'Bus 33_500.00'"
Branch	"BRANCH 'MyName 23_138.00' 'MyName 29_138.00' 'AB'"
Branch	"BRANCH 'MyName 23_138.00' 'MyName 29_138.00' 'AB' 4" <i>(multi-section line branch)</i>
Branch	"BRANCH 'Name45_345.00' 'Name29_138.00' 'Name28_69.00' 'AB'" <i>(three-winding transformer winding)</i>
Area	"AREA 'Fifty One'"
Zone	"ZONE 'Ninety Three'"
Substation	"SUBSTATION 'Thirty Seven'"

2.3.6 Label Identifiers

Label Identifiers are can also be specified for a particular object. Each particular object could potentially have multiple labels assigned to them, but within one object type, only one object can have a particular label. The format of the object string using a label is then simply the object type followed by the label enclosed in single quotes.

General Format	"Objecttype 'label'"
Generator	"GEN 'GrandCoule12'"
Bus	"BUS 'Coulee_N56'"

Branch	"BRANCH 'CaptJackGrizzly_56"
--------	------------------------------

2.3.7 Naming Collisions

It is possible in this format for a power system model to have secondary fields which do not create a unique identifier for the case. For example, the secondary key fields for buses are the concatenation of the Name and Nominal kV. These are *almost* always unique, but not *always*. For example, in a recent case there are 4 buses named CanyonGT at 13.8 kV (numbers 25211-25214). When reading from a file referencing the bus "CanyonGT_13.8", this format would just pick the one that a software vendors search routine finds first. There is no guarantee that this will be the one intended, so this is something the user must be careful with if using secondary key fields.

It is also possible for the label identifiers to collide with the secondary keys as well. Our experience in practice is that the labels are derived from unique identifiers in the EMS models which are longer than the secondary key strings and are a concatenation of the substation name(s), some unique delimiter like a \$. Thus in practice this shouldn't happen, but it is possible.

It is even possible with labels that there could be a conflict between the primary key and the label. We do not expect to see too many buses with a label of "1234", but a user could do something like that.

Regardless of these hypothetical limitations, when parsing these strings, this format instructs that software parsers will always look first for the primary keys, then the secondary keys, and finally for any of the labels. Thus if there is a conflict between secondary keys and the labels, then the secondary key will have precedence.

2.4 Object Field Definitions

The following is the start of a list of fields that will be defined for each object type. Collaboration between power engineers, PowerWorld Corporation staff, and other software vendor staff will more fully define which fields are necessary for modeling purposes of contingency analysis. Adding new variables to the parsing will be trivial for the software vendors so we will add them as requested.

2.4.1 Branch and MSBranch Fields

Field	Description
BusNumFrom	Number of the from bus
BusNameFrom	Name of the from bus
BusNameNomkVFrom	Combination of the Name and the kV of the from bus separated by an underscore. For example "Johnson_34.5"
BusNumTo	Number of the to bus
BusNameTo	Name of the to bus
BusNameNomkVTo	Combination of the Name and the kV of the to bus separated by an underscore. For example "Johnson_34.5"
Circuit	Circuit ID of the branch
Status	either OPEN or CLOSED
DerivedStatus	either OPEN, OPENFROM, OPENTO, or CLOSED

Online	YES OR NO
DerivedOnline	either OPEN, OPENFROM, OPENTO, OR CLOSED
Bypass	Either Bypassed OR Not Bypassed
MWFrom	MW flow at the from bus going toward the to
MWTo	MW flow at the to bus going toward the from
MWFromIntoBus	MW flow at the from bus going toward the from <i>Added in Simulator Version 20</i>
MWToIntoBus	MW flow at the to bus going toward the to <i>Added in Simulator Version 20</i>
MWMax	Maximum absolute value of MWFrom and MWTo
MVARFrom	Mvar flow at the from bus going toward the to
MvarTo	Mvar flow at the to bus going toward the from
MVARFromIntoBus	Mvar flow at the from bus going toward the from <i>Added in Simulator Version 20</i>
MvarToIntoBus	Mvar flow at the to bus going toward the to <i>Added in Simulator Version 20</i>
MvarMax	Maximum absolute value of MvarFrom and MvarTo
AmpsFrom	Amps at the from bus
AmpsTo	Amps at the to bus
AmpsMax	Maximum of the AmpsFrom and AmpsTo
MVAFrom	MVA at the from bus
MVATo	MVA at the to bus
MVAMax	Maximum of the MVAFrom and MVATo
LineShuntMvarFrom	Sum of the nominal Mvar from line shunts at the from bus of the branch
LineShuntMvarTo	Sum of the nominal Mvar from line shunts at the to bus of the branch
LineShuntMWFrom	Sum of the nominal MW from line shunts at the from bus of the branch
LineShuntMWTo	Sum of the nominal MW from line shunts at the to bus of the branch
PercentMVA	Percentage of the MVA limit
PercentMVAAFrom	Percentage of MVA limit A at the from bus of the branch <i>Added in Simulator Version 20</i>
PercentMVAATo	Percentage of MVA limit A at the to bus of the branch <i>Added in Simulator Version 20</i>
PercentMVABFrom	Percentage of MVA limit B at the from bus of the branch <i>Added in Simulator Version 20</i>
PercentMVABTo	Percentage of MVA limit B at the to bus of the branch <i>Added in Simulator Version 20</i>
PercentMVACFrom	Percentage of MVA limit C at the from bus of the branch <i>Added in Simulator Version 20</i>
PercentMVACTo	Percentage of MVA limit C at the to bus of the branch <i>Added in Simulator Version 20</i>
Percent	Percentage flow on the branch according to the software's monitoring options. This value may be based on the Amps instead of MVA for example

PercentFrom	Percentage flow on the branch at the from end of the branch according to the software's monitoring options. This value may be based on the Amps instead of MVA for example
PercentTo	Percentage flow on the branch at the to end of the branch according to the software's monitoring options. This value may be based on the Amps instead of MVA for example
Monitor	Set to YES to monitor the device or NO to not. See Section 8 for details.
LimitSet	Name of the LimitSet to which the branch belongs. See Section 8 for details.
LimitMVAA	MVA Limit A. See Section 8 for details.
LimitMVAB	MVA Limit B. See Section 8 for details.
LimitMVAC	MVA Limit C. See Section 8 for details.
LimitMVAD	MVA Limit D. See Section 8 for details.
LimitMVAE	MVA Limit E. See Section 8 for details.
LimitMVAF	MVA Limit F. See Section 8 for details.
LimitMVAG	MVA Limit G. See Section 8 for details.
LimitMVAH	MVA Limit H. See Section 8 for details.
LimitAmpA	Amp Limit A. This is calculated from LimitMVAA by determine what Amp level that would correspond to at nominal voltage.
LimitAmpB	Amp Limit B
LimitAmpC	Amp Limit C
LimitAmpD	Amp Limit D
LimitAmpE	Amp Limit E
LimitAmpF	Amp Limit F
LimitAmpG	Amp Limit G
LimitAmpH	Amp Limit H

The following are special fields for identifiers consistent with the EPC format's treatment of multi-section lines.

Field	Description
MSBusNumFrom	If the branch is not part of a multi-section line then this is the same as BusNumFrom. If branch is part of a multi-section line then this is the number of the from bus of the multi-section line.
MSBusNameNomkVFrom	If the branch is not part of a multi-section line then this is the same as BusNameNomkVFrom. If branch is part of a multi-section line then this is the name_NomkV of the from bus of the multi-section line.
MSBusNumTo	If the branch is not part of a multi-section line then this is the same as BusNumTo. If branch is part of a multi-section line then this is the number of the to bus of the multi-section line.
MSBusNameNomkVTo	If the branch is not part of a multi-section line then this is the same as BusNameNomkVTo. If branch is part of a multi-section line then this is the name_NomkV of the to bus of the multi-section line.
Section	If the branch is not part of a multi-section line this entry is blank. If branch is part of a multi-section line, this is the section number within the multi-section line.

2.4.2 Bus Fields

Field	Description
Number	Number of the bus
Name	Name of the bus
NameNomkV	Combination of the Name and the kV of the bus separated by an underscore. For example "Johnson_34.5"
Status	Either DISCONNECTED or CONNECTED
Vpu	The per unit voltage magnitude of the bus
Vangle	The angle of the bus in degrees
kV	The voltage magnitude in kilovolts
NomkV	The nominal voltage of the bus in kilovolts
LoadMW	The total load at the bus in MW. If there are no loads defined at the bus then this value is blank.
LoadMvar	The total load at the bus in Mvar. If there are no loads defined at the bus then this value is blank.
GenMW	The total generation at the bus in MW. If there are no generators defined at the bus then this value is blank.
GenMvar	The total generation at the bus in Mvar. If there are no generators defined at the bus, value is blank.
GenMWMax	The sum of generation Max MW at the bus. If there are no generators defined at the bus, value is blank.
GenMWMin	The sum of generation Min MW at the bus. If there are no generators defined at the bus, value is blank.
GenMvarMax	The sum of generation Max Mvar at the bus. If there are no generators defined at the bus, value is blank.
GenMvarMin	The sum of generation Min Mvar at the bus. If there are no generators defined at the bus, value is blank.
ShuntMvar	The total switched shunt (both svd and bus) at the bus in Mvar. If there are no shunts (svd or bus) defined at the bus, value is blank.
Monitor	Set to NO to signify that the bus should not be monitored. Set to YES to make it eligible for monitoring as described in Section 8.
LimitSet	Set to the name of the Limit Set to which the Bus belongs. See Section 8 for details.
UseSpecificLimits	Set to YES to signify that the bus has its own limits specified by LimitHighA...LimitHighD and LimitLowA...LimitLowD. See Section 8 for details.
LimitHighA	High voltage limit A. See Section 8 for details.
LimitHighB	High voltage limit B. See Section 8 for details.
LimitHighC	High voltage limit C. See Section 8 for details.
LimitHighD	High voltage limit D. See Section 8 for details.
LimitLowA	Low voltage limit A. See Section 8 for details.
LimitLowB	Low voltage limit B. See Section 8 for details.
LimitLowC	Low voltage limit C. See Section 8 for details.
LimitLowD	Low voltage limit D. See Section 8 for details.

2.4.3 Gen Fields

Field	Description
BusNum	Number of the terminal bus of the generator
BusName	Name of the terminal bus of the generator
BusNameNomkV	Name_NomkV of the terminal bus of the generator
ID	ID of the generator. This is unique for generators which are connected to the same bus.
Status	either OPEN or CLOSED
DerivedStatus	either OPEN or CLOSED but determined by looking at the surrounding breaker topology
Online	YES or NO
MW	MW output of the generator
MWMax	Maximum MW output of generator
MWMin	Minimum MW output of generator
Mvar	Mvar output of the generator
MvarMax	Maximum Mvar output of generator
MvarMin	Minimum Mvar output of generator
MVA	MVA of generator
CTGPreventAGC	field for contingency analysis discussed later.
CTGPartFact	field for contingency analysis discussed later.
CTGMaxResp	field for contingency analysis discussed later.
UseLineDrop	field for contingency analysis discussed later.
Xcomp	field for contingency analysis discussed later.
Rcomp	field for contingency analysis discussed later.
AGC	YES or NO (specifies if generator respond to automatic generator control features)
PartFact	Numerical value for specifying the participation factor of the generator

2.4.4 Load Fields

Field	Description
BusNum	Number of the terminal bus of the load
BusName	Name of the terminal bus of the load
BusNameNomkV	Name_NomkV of the terminal bus of the load
ID	ID of the load. This is unique for loads which are connected to the same bus.
Status	Either OPEN or CLOSED
DerivedStatus	Either OPEN or CLOSED but determined by looking at the surrounding breaker topology
Online	YES or NO
MW	MW of load
Mvar	Mvar of Load
MVA	MVA of Load
SMW	Constant Power MW of Load
SMvar	Constant Power Mvar of Load
IMW	Constant Current MW of Load

IMvar	Constant Current Mvar of Load
ZMW	Constant Impedance MW of Load
ZMvar	Constant Impedance Mvar of Load

2.4.5 Shunt Fields

Field	Description
BusNum	Number of the terminal bus of the shunt
BusName	Name of the terminal bus of the shunt
BusNameNomkV	Name_NomkV of the terminal bus of the shunt
ID	ID of the shunt. This is unique for shunts which are connected to the same bus.
Status	Either OPEN or CLOSED
DerivedStatus	Either OPEN or CLOSED but determined by looking at the surrounding breaker topology
Online	YES or NO
MW	MW of shunt (normally zero)
MWNom	Nominal MW of shunt (normally zero)
Mvar	Mvar of shunt at present per unit voltage
MvarNom	Nominal Mvar of shunt
MvarNomMax	Maximum Nominal Mvar
MvarNomMin	Minimum nominal Mvar
VoltageControlGroup	Name of the Voltage Control Group to which the Switched Shunt belongs

2.4.6 Area Fields

Field	Description
NomkVMin	Minimum nominal voltage of the area.
NomkVMax	Maximum nominal voltage of the area.
LoadMW	The sum of load MW at all loads in the area. If there are no loads defined in the area, value is blank.
LoadMvar	The sum of load Mvar at all loads in the area. If there are no loads defined in the area, value is blank.
GenMW	The sum of generation MW in the area. If there are no generators defined in the area, value is blank.
GenMvar	The sum of generation Mvar in the area. If there are no generators defined in the area, value is blank.
GenMWMax	The sum of generation Max MW in the area. If there are no generators defined in the area, value is blank.
GenMWMin	The sum of generation Min MW in the area. If there are no generators defined in the area, value is blank.
GenMvarMax	The sum of generation Max Mvar in the area. If there are no generators defined in the area, value is blank.
GenMvarMin	The sum of generation Min Mvar in the area. If there are no generators defined in the area, value is blank.

MonitorLimits	YES or NO to monitor limits in this area
MonitorMinkV	Minimum nominal kV that will be monitored
MonitorMaxkV	Minimum nominal kV that will be monitored
CTGMakeupGen	field for contingency analysis discussed later.

2.4.7 Zone Fields

Field	Description
NomkVMin	Minimum nominal voltage of the zone.
NomkVMax	Maximum nominal voltage of the zone.
LoadMW	The sum of load MW at all loads in the zone. If there are no loads defined in the zone, value is blank.
LoadMvar	The sum of load Mvar at all loads in the zone. If there are no loads defined in the zone, value is blank.
GenMW	The sum of generation MW in the zone. If there are no generators defined in the zone, value is blank.
GenMvar	The sum of generation Mvar in the zone. If there are no generators defined in the zone, value is blank.
GenMWMax	The sum of generation Max MW in the zone. If there are no generators defined in the zone, value is blank.
GenMWMin	The sum of generation Min MW in the zone. If there are no generators defined in the zone, value is blank.
GenMvarMax	The sum of generation Max Mvar in the zone. If there are no generators defined in the zone, value is blank.
GenMvarMin	The sum of generation Min Mvar in the zone. If there are no generators defined in the zone, value is blank.
MonitorLimits	YES or NO to monitor limits in this zone
MonitorMinkV	Minimum nominal kV that will be monitored
MonitorMaxkV	Minimum nominal kV that will be monitored

2.4.8 Substation Fields

Field	Description
NomkVMin	Minimum nominal voltage of the substation.
NomkVMax	Maximum nominal voltage of the substation.
LoadMW	The sum of load MW at all loads in the substation. If there are no loads defined in the substation, value is blank.
LoadMvar	The sum of load Mvar at all loads in the substation. If there are no loads defined in the substation, value is blank.
GenMW	The sum of generation MW in the substation. If there are no generators defined in the substation, value is blank.
GenMvar	The sum of generation Mvar in the substation. If there are no generators defined in the substation, value is blank.
GenMWMax	The sum of generation Max MW in the substation. If there are no generators defined in the substation, value is blank.

GenMWMin	The sum of generation Min MW in the substation. If there are no generators defined in the substation, value is blank.
GenMvarMax	The sum of generation Max Mvar in the substation. If there are no generators defined in the substation, value is blank.
GenMvarMin	The sum of generation Min Mvar in the substation. If there are no generators defined in the substation, value is blank.

2.4.9 Injection Group Fields

Field	Description
Name	Name of the injection group
MW	The total net MW injection of the group.
Mvar	The total net Mvar injection of the group.
LoadMW	The sum of load MW at all loads in the injection group. If there are no loads defined in the injection group, value is blank.
LoadMvar	The sum of load Mvar at all loads in the injection group. If there are no loads defined in the injection group, value is blank.
GenMW	The sum of generation MW in the injection group. If there are no generators defined in the injection group, value is blank.
GenMvar	The sum of generation Mvar in the injection group. If there are no generators defined in the injection group, value is blank.
GenMWMax	The sum of generation Max MW in the injection group. If there are no generators defined in the injection group, value is blank.
GenMWMin	The sum of generation Min MW in the injection group. If there are no generators defined in the injection group, value is blank.
GenMvarMax	The sum of generation Max Mvar in the injection group. If there are no generators defined in the injection group, value is blank.
GenMvarMin	The sum of generation Min Mvar in the injection group. If there are no generators defined in the injection group, value is blank.
CountGen	Number of generator participation points
CountGenOnline	Number of Online generator participation points
CountLoad	Number of load participation points
CountLoadOnline	Number of Online load participation points
CountShunt	Number of switched shunt participation points
CountShuntOnline	Number of Online switched shunt participation points

2.4.10 Interface Fields

Field	Description
Name	Name of the interface
Number	Number of the interface
MW	MW flow on interface
Mvar	Mvar flow on interface
MVA	MVA flow on interface
Percent	Percent of limit used on interface according to the software's monitoring options
Monitor	Set to YES to monitor the device or NO to not

LimitSet	Name of the LimitSet to which the interface belongs
LimitMWA	MW Limit A. See Section 8 for details.
LimitMWB	MW Limit B. See Section 8 for details.
LimitMWC	MW Limit C. See Section 8 for details.
LimitMWD	MW Limit D. See Section 8 for details.
LimitMWE	MW Limit E. See Section 8 for details.
LimitMWF	MW Limit F. See Section 8 for details.
LimitMWG	MW Limit G. See Section 8 for details.
LimitMWH	MW Limit H. See Section 8 for details.

2.4.11 3WXFormer Fields

Field	Description
BusNumPri	Number of the primary bus
BusNamePri	Name of the primary bus
BusNameNomkVPri	NameNomkV for primary bus
BusNumSec	Number of the secondary bus
BusNameSec	Name of the secondary bus
BusNameNomkVSec	NameNomkV of the secondary bus
BusNumTer	Number of the tertiary bus
BusNameTer	Name of the tertiary bus
BusNameNomkVTer	NameNomkV of the tertiary bus
Circuit	Circuit ID of the transformer
StatusPri	Status of the primary winding
StatusSec	Status of the secondary winding
StatusTer	Status of the tertiary winding
MWPri	MW flow at the primary bus going into the transformer
MWSec	MW flow at the secondary bus going into the transformer
MWTer	MW flow at the tertiary bus going into the transformer
MvarPri	Mvar flow at the primary bus going into the transformer
MvarSec	Mvar flow at the secondary bus going into the transformer
MvarTer	Mvar flow at the tertiary bus going into the transformer
AmpsPri	Amps at the primary bus
AmpsSec	Amps at the secondary bus
AmpsTer	Amps at the tertiary bus
MVAPri	MVA at the primary bus
MVASec	MVA at the secondary bus
MVATer	MVA at the tertiary bus
PercentMVAPri	Percentage of the MVA limit at the primary bus
PercentMVASec	Percentage of the MVA limit at the secondary bus
PercentMVATer	Percentage of the MVA limit at the tertiary bus

PercentPri	Percentage flow on the primary bus winding according to the software's monitoring options. This value may be based on the Amps instead of MVA for example
PercentSec	Percentage flow on the secondary bus winding according to the software's monitoring options. This value may be based on the Amps instead of MVA for example
PercentTer	Percentage flow on the tertiary bus winding according to the software's monitoring options. This value may be based on the Amps instead of MVA for example

2.4.12 DCTransmissionLine Fields

Field	Description
BusNumRect	Number of the rectifier bus
BusNameRect	Name of the rectifier bus
BusNameNomkVRect	NameNomkV of the rectifier bus
BusNumInv	Number of the inverter bus
BusNameInv	Name of the inverter bus
BusNameNomkVInv	NameNomkV of the inverter bus
Circuit	Circuit ID of the DC Line
MWRect	MW flow into the line at the rectifier end of the DC Transmission Line
MWInv	MW flow into the line at the inverter end of the DC Transmission Line
MvarRect	Mvar flow into the line at the rectifier end of the DC Transmission Line
MvarInv	Mvar flow into the line at the inverter end of the DC Transmission Line
AmpsDC	DC Amps on the line
DerivedStatus	either OPEN, OPENFROM, OPENTO, or CLOSED
Online	YES or NO
DerivedOnline	either OPEN, OPENFROM, OPENTO, or CLOSED
VdcRect	DC voltage in kV at the Rectifier
VdcInv	DC voltage in kV at the Inverter

2.4.13 LineShunt Fields

Field	Description
BusNumFrom	Number of the from bus of the branch to which the lineshunt is connected
BusNameFrom	Name of the from bus of the branch to which the lineshunt is connected
BusNameNomkVFrom	NameNomkV of the from bus of the branch to which the lineshunt is connected
BusNumTo	Number of the to bus of the branch to which the lineshunt is connected
BusNameTo	Name of the to bus of the branch to which the lineshunt is connected
BusNameNomkVTo	NameNomkV of the to bus of the branch to which the lineshunt is connected
Circuit	Circuit ID of the branch
BusNumLoc	Number of the bus at which the shunt is connected
BusNameNomkVLoc	NameNomkV of the location at which the Line Shunt is connected

ID	ID field for the line shunt (must be unique for all shunts connected to the same end of branch)
----	---

The following are special fields for identifiers consistent with the EPC format's treatment of multi-section lines.

Field	Description
MSBusNumFrom	If the line shunt's branch is not part of a multi-section line then this is the same as BusNumFrom. If line shunt's branch is part of a multi-section line then this is the number of the from bus of the multi-section line.
MSBusNameNomkVFrom	If the line shunt's branch is not part of a multi-section line then this is the same as BusNameNomkVFrom. If line shunt's branch is part of a multi-section line then this is the Name_NomkV of the from bus of the multi-section line.
MSBusNumTo	If the line shunt's branch is not part of a multi-section line then this is the same as BusNumTo. If line shunt's branch is part of a multi-section line then this is the number of the to bus of the multi-section line.
MSBusNameNomkVTo	If the line shunt's branch is not part of a multi-section line then this is the same as BusNameNomkVTo. If line shunt's branch is part of a multi-section line then this is the name_NomkV of the to bus of the multi-section line.
Section	If the line shunt's branch is not part of a multi-section line this entry is blank. If line shunt's branch is part of a multi-section line, this is the section number within the multi-section line.
MSBusNumLoc	Multi-Section line terminal bus number which is on the same side as the line shunt relative to its branch
MSBusNameNomkVLoc	Multi-Section line terminal bus name and nominal kV which is on the same side as the line shunt relative to its branch

2.4.14 VSCDCLine Fields

Field	Description
Name	Name of the VSCDCLine. This is the unique identifier
BusNumRect	Number of the rectifier bus
BusNameRect	Name of the rectifier bus
BusNameNomkVRect	NameNomkV if the rectifier bus
BusNumInv	Number of the inverter bus
BusNameInv	Name of the inverter bus
BusNameNomkVInv	NameNomkV of the inverter bus

2.4.15 ModelExpression Fields

Field	Description
Result	The result of the model expression evaluation

2.4.16 VoltageControlGroup Fields

Field	Description
Name	The name of the voltage control group

Status	Status of the group. Set to one of the following three choices: ON, OFF, or FORCEON These will be discussed more a later section
--------	---

2.4.17 Model Filter Fields

Field	Description
Name	Name of the Model Filter contained in double quotes. Note: Names must be unique across all other ModelFilters and ModelConditions.
Memo	Extra String
Meets	Value will be YES if the Model Filter logic evaluates to TRUE in the present system state.

2.4.18 Model Condition Fields

Field	Description
Name	Name of the Model Condition contained in double quotes. Note: Names must be unique across all other ModelFilters and ModelConditions.
Memo	Extra String
Meets	Value will be YES if the Model Condition logic evaluates to TRUE in the present system state.

2.4.19 MTDCRecord Fields

Field	Description
Number	Number of the MTDCRecord
Name	Name of the MTDCRecord
MWRect	AC MW flow into the record on all rectifier converters
MvarRect	AC Mvar flow into the record on all rectifier converters
MWInv	AC MW flow into the record on all inverter converters (this value will be negative as they are for inverters)
MvarInv	AC Mvar flow into the record on all inverter converters
MWInv	DC Amps leaving the converter

2.4.20 MTDCConverter Fields

Field	Description
MTDCNumber	Number of the MTDCRecord
BusNumAC	Number of the AC bus
BusNameAC	Name of the AC bus
BusNameNomkVAC	NameNomkV of the AC bus
BusNumDC	Number of the DC bus
BusNameDC	Name of the DC bus
BusNameNomkVDC	NameNomkV of the DC bus
MW	MW flow into the line at the AC bus of the converter
Mvar	Mvar flow into the line at the AC bus of the converter
Amps	DC Amps leaving the converter

Status	either OPEN or CLOSED
Online	YES OR NO

2.5 Documentation of Key, Required, and Optional fields

Each field of an object in PowerWorld Simulator is classified by PowerWorld as either a key field, required field, or an optional field. Key fields were discussed earlier in this document and key fields represent the fields necessary for uniquely defining a particular object. Thus when defining a new object, you must specify the key fields. In addition to this concept, the remaining input fields can be grouped into *Required* fields and *Optional* fields. Required fields are those that must be included when creating new objects when loading data from an auxiliary file. These are fields for which no default value is specified. If Required fields are omitted from the auxiliary file section then the entire section of the auxiliary files will be ignored. By omitted, it is meant that field is not included in the *list of field names* in the header of a section as described in Section 5 of this document. Optional fields are those fields that are not required when creating a new object and if excluded from the auxiliary file section then a default value will be assumed.

Throughout the remainder of this documentation there will be tables listing the Object Fields for the definition of particular object types in an auxiliary file. Within these tables there will be a column showing the name of the field along with a column containing a description and rules for the field. In order to denote whether a field is a Key field, Required field, or Optional field, the tables in the remainder of this document will include a notation in small text underneath the field name. As an example, consider the following table. The small text (key) or (required) will indicate that the field is a Key field or Required field. The small text (optional, default ***) will indicate that the field is optional and if omitted then the default value of *** is assumed. The word blank is used frequently such as (optional, default blank) and means that the field would be assumed as an empty string.

Field	Description and Rules for Field
MyFieldName (key)	Description of the field
AnotherAnother (key)	Description of the field
MyField (required)	Description of the field
OtherStringField (optional, default YES)	Description of the field
OtherNumericField (optional, default 2.5)	Description of the field
DataMaintainerAssign (Optional, default blank)	Name of the DataMaintainer for this object. This can be blank as well which indicates no DataMaintainer has been assigned.

3 Filtering and Device Filtering

Filtering and Device Filtering can be used to designate a grouping of a type of objects. For example, one may want to specify that all Bus objects that meet a particular Filter should be monitored. This will be used with Custom Monitors described in Section 8.7. Filtering can be done either by building a logical description of which objects to choose (building a “Filter”) or by specifying another object which itself inherently defines the filter (Device Filtering). These will be presented here and a format for their specification will be presented.

3.1 Filter, Condition (filtering)

The definition of a Filter allows you to create a Boolean operator that applies to a type of object. This is different than the Model Conditions or Model Filters described in Section 5.12 and 5.13 that create combinations of Boolean operators that apply to specific objects. The definition of the Filter uses the following list of fields:

Field	Description and Rules for Field
ObjectType (key)	Identifies the type of object to which this Filter can be applied using the object type string in format specified in Section 2.2.
Name (key)	The Name of Filter. This must be unique across all filters that have the same ObjectType.
Logic (required)	Logic to apply to the list of comparisons (AND, OR, NAND, NOR, XOR, OneTRUE). OneTrue logic means that there is exactly one true input to the gate. XOR logic tests if there are an odd number of true inputs.
Enabled (optional, default YES)	Set to YES to use the filter result normally. Set to NO to ignore this filter result, which when used alone means the filter result will return TRUE. When set to NO and used in a nested filter definition, the filter will act as though it does not exist at all (treatment depends on the overall nested filter logic).
DataMaintainerAssign (Optional, default blank)	Name of the DataMaintainer for this object. This can be blank as well which indicates no DataMaintainer has been assigned.

Filters are made up of any number of Condition objects. The fields recognized by the Condition object type are shown in the following table:

Field	Description and Rules for Field
ObjectType (key)	ObjectType of the Filter to which the Condition applies. This is a key field.
Filter (key)	Name of the Filter to which the Condition applies. This is a key field.
CondNum (key)	Number specifying a number ID of the condition. Omitting this value, or specifying a value of zero, will cause this to automatically add the condition to the existing Filter. Otherwise by specifying a number you can edit an existing condition. This is a key field.

ObjectField (required)	A field associated with the object to which this model condition applies. A list of fields is shown in Section 2.4. In addition to these fields, you may also specify the string "_UseAnotherFilter" to signify that this condition refers to another Filter. This will be important for the creation of more complex nested filter definitions as described in Section 3.2.
ConditionType (required)	<p>The comparison operator applied to the ObjectField and the Value and OtherValue entries. There are many choices as follows:</p> <ul style="list-style-type: none"> = equal (should not use for numbers) <> not equal > greater than < less than >= greater than or equal <= less than or equal <p>Integer comparisons</p> <ul style="list-style-type: none"> inrange enter a string as the Value of the form "2-5, 70-90" notinrange enter a string as the Value. Opposite of inrange. <p>String Comparisons</p> <ul style="list-style-type: none"> contains returns whether string contains a particular substring notcontains opposite of contains startswith returns whether a string starts with a string notstartswith opposite of startswith <p>Two value comparisons</p> <ul style="list-style-type: none"> about specify two values. Return whether the field is within the OtherValue (tolerance) of the Value notabout specify two values. Opposite of about between specify two values the field is between notbetween specify two values the field is not between <p>_UseAnotherFilter comparisons</p> <ul style="list-style-type: none"> Meets returns whether another filter's conditions are met Not Meets returns whether another filter's conditions are not met
Value (optional, default 0 or blank)	<p>Value or Field or Expression. The entry specifies the value to which the field is compared. This may be done in three ways</p> <p><i>Value</i> : 1.459 or a String</p> <p><i>Field</i> : start with the tag <Field> and then follow with a string using the format as the ObjectField string</p> <p><i>Model Expression</i> : start with the tag <Expression> and then follow the name of the Model Expression</p>
OtherValue (optional, default 0 or blank)	This entry's format is the same as the Value entry. It is only used for the between, notbetween, about, and notabout Condition Types
Absolute (optional, default NO)	Set to YES to take the absolute value of the ObjectField being compared

A sample file section is shown as follows:

```
Filter (ObjectType,Name,Logic,Enabled,DataMaintainerAssign)
{
"Gen" "Roughrider over Max" "AND" "YES" "My Maintainer"
}
```

```

Condition (ObjectType,Filter,CondNum,ObjectField,ConditionType,Value,OtherValue,Absolute)
{
"Gen" "Roughrider over Max" 1 "MW" ">" "<Field>MWMax" "" "NO"
}

```

3.2 Nested Filters

Once you choose the Logic for the Filter, that logic is applied across all conditions in the filter. Therefore if you wish to use the AND condition, all conditions you define will be applied using AND. There is a way to combine different conditions within the same filter. This is accomplished by allowing nested filters. In other words, one condition of a filter can be that another filter is met. To refer to one filter from within another, use the special field `"_UseAnotherFilter"`. Then choose whether the ConditionType `Meets` or `NotMeets`. Finally, enter the name of the Filter in the Value field. This allows you to define conditions using one logical comparison in one filter, and then use that filter to combine those conditions with other conditions using a different logical comparison.

For example, consider the logical comparison of *A and (B or C)*. To replicate this, you would define one filter (*AF1*) that contains the logic *B or C*. Then you can define a filter (*AF2*) that contains the logic *A and (AF1)*.

A sample file section showing a nested filter is shown as follows:

```

FILTER (ObjectType,Name,Logic,Enabled)
{
"Load" "Neg MW" "AND" "NO" "YES"
"Bus" "Neg Load or Generator" "OR" "NO" "YES"
}
CONDITION (ObjectType,Filter,CondNum,ObjectField,ConditionType,Value,OtherValue,Absolute)
{
"Load" "Neg MW" 1 "LoadMW" "<" "0" "" "NO"
"Bus" "Neg Load or Generator" 1 "BusGenMW" "notisblank" "" "" "NO"
"Bus" "Neg Load or Generator" 2 "_UseAnotherFilter" "meets" "<Load>Neg MW" "" "NO"
}

```

3.3 Device Filtering

Device Filtering allows you to directly use one of the power system model objects as a filter. The relationship between the object type being listed and the object type of the device filter determines how filtering is done. For example, an injection group can be used as a device filter to filter a list of generators. The result of using this filter will be only the generators that are inside the Injection Group.

As another example, if you are using an injection group as a device filter to filter a list of branches, then you will get only branches that are connected to the terminal bus of any generator, load, or switched shunt contained in the injection group. Device filtering can be often used instead of more complicated Filters, with the benefit being that a new data record (a new Filter) is not needed.

3.4 Specifying a Filter or Device Filter using a string

In places in this file format where there is a choice to refer to a “Filter” there will be an explicit object type implied in that circumstance (call that the primary ObjectType). For example, in Section 8.7 a CustomMonitor has a field ObjectType and then fields for FilterPre and FilterPost. Thus for a CustomMonitor, the ObjectType determines how the string for specifying the FilterPre and FilterPost is interpreted. There are three ways to specify the filter string:

1. Enter a string that represents the name of the filter. This will look through all filters that share the primary ObjectType.
2. Enter a string that starts with the name of a different object type (using an object type string from Section 2.2) enclosed in < and >, followed by the name of a filter for the other object type. For example, for a Custom Monitor, if ObjectType = Branch, then a filter string of "<BUS> My FilterName" would signify that the branches should be filtered according to the bus filter named “My FilterName”. When filtering across object types, all of the secondary object types that apply to the primary object type are evaluated against the Filter and an OR logic is applied so that if any of the secondary objects meets the filter then the primary object meets the filter.
3. When specifying a device filter, in the place that a filter name is to be expressed, simply enter the following syntax "<DEVICE> Object ID String", where Object ID String is a string of the same format as described in Section 2.3. A device filter works simply by choosing all of the primary object types that are contained in the Device referenced. For example if the primary object type is GEN, and the Device Filter is an Injection Group, then all generators that are inside the injection group will meet the device filter.

4 Script Sections to Set Defaults

There are several data records in later sections (such as generators and buses in Sections 5.2 and 5.5) that will generally have the same settings for all but a small number of exceptions. For instance, generator line drop compensation is typically not used. So that we do not require 1,000s of file entries to enumerate all the objects that use the default setting, the file format will permit the specification of a special script command that sets all values for a particular object type.

This command will be placed inside of a special SCRIPT section enclosed in curly braces much the same way as will be done with various data records below. The command will have the following syntax:

```
SetData(objecttype, [fieldlist], [valuelist], filter);
```

Objecttype will represent one of the strings referred to in Section 2.2. This will be followed by a list of fields enclosed in square brackets. The fields will be the same ones described in Section 2.4. This will be followed by a comma-delimited list of string containing values to assign to these fields; again enclosed in square brackets. Each value should also be enclosed in double quotes. Finally a fourth parameter should be specified as the string ALL to signify that these defaults should be applied to all objects of this type. The fourth parameter could also be a filter or device filter using the format described in Section 3.4, but that will not be needed for any of the formats needed in this document.

For example, the following sections would set all the various default options for Bus and Generators data records described in Section 5.2 and 5.5. Note that this can be done within only one SCRIPT section or within many SCRIPT sections within the same text file.

```
SCRIPT
{
SetData(Gen, [CTGMaxResp], [-1.0], All);
}
SCRIPT
{
SetData(Gen, [CTGPreventAGC,CTGPartFact], ["NO","same"], All);
SetData(Gen, [UseLineDrop], ["NO"], All);
SetData(Bus, [CTGLoadThrow], [""], All);
}
```

5 Data Record Structures

There are many object type sections that will be needed for defining the data records necessary to define contingencies and RAS.

The following data records are necessary for defining the solution options and how the behavior of various objects is handled during a contingency solution:

- Area (settings for contingency modeling)
- Bus (settings for contingency modeling)
- Gen (settings for contingency modeling)
- Shunt Voltage Control Groups
- Shunt (settings for contingency modeling)
- CTG_Options_Value
- Sim_Solution_Options_Value

The following are necessary helper objects for defining the contingency records themselves:

- InjectionGroup, PartPoint
- ModelExpression
- ModelCondition, ModelConditionCondition
- ModelFilter, ModelFilterCondition

The following are records that define the action contingency records:

- Contingency, ContingencyElement,
- TSContingency, TSContingencyElement
- RemedialAction, RemedialActionElement

The following are data records necessary for defining how limits are monitored during the power flow contingency analysis:

- LimitSet
- Area (settings for limit monitoring)
- Zone (settings for limit monitoring)
- Bus (settings for limit monitoring)
- Branch (settings for limit monitoring)
- Interface (settings for limit monitoring)
- Filter, Condition
- CustomMonitor

The basic file structure will allow defining object type sections and multiple object type sections may appear in the same text file. In addition, an object type section can be repeated in the file if desired. For example, it may be convenient to list settings for an Area record related to the solution options separately from the options related to limit monitoring.

An object type section will be identified as a line of text that starts with its unique string which is defined in Section 2.2. Note that when a software package parses the file if it comes across an object type which is not recognized, the software should NOT cause a fatal file read error. Instead appropriate warning messages could be shown to the user but the software should just ignore this entire data section and continue reading the remainder of the file. The object type will be followed by an open parenthesis, a comma-delimited list of field names, and then a close parenthesis. The order in which the fields are listed in this comma-delimited list dictates the order in which the fields will be read from the file. Including this header makes the file easier to read and also allows for the format to grow as new fields may be needed as new features are needed for software tools in the future. This takes a small part of the XML-inspired idea of having a self-defining format, however it does not take it to the extreme which XML does by placing these field identifiers around *every* individual field value. This header will appear once and there can then be any number of records (a few or 10,000s) that follow the header and do not require repeated header strings.

Syntax rules regarding the list of field names are as follows:

- The list of field names may take up several lines of the text file
- The list of field names should be encompassed by parenthesis ()
- When encountering the comment string `'//'` in one of these lines of the text file, all text to the right is ignored but the parser will continue to read the list of fields on the next line of text
- Blank lines, or lines whose first characters are `'//'` will be ignored and not read
- Field names must be separated by commas

The field names available for each object type are described in detail in the rest of the document. Note that when a software package parses this list of fields it should NOT cause a fatal file read error if it runs across a field name that is not recognized. Appropriate warning messages could be shown to the user but it should just ignore those fields and respective values in the value lists. This document will specify which fields are necessary for defining contingency and RAS related information only, but there is clearly more information available in the software tools. The assumption is that any new fields added in the future will represent optional new features for Contingency and RAS.

After the list of field names are terminated by a close parenthesis, a left curly brace { is used to signify the start of data for this object type. Following this is a list of the values for the various fields for many different objects. The values must be in the order specified in the list of field names header. To terminate this object section a right curly brace } must be entered at the start line of a line of text.

Syntax rules for the list of values are as follows:

- The value list may take up several lines of the text file. The parser will just read values until it has read the number of values specified in the list of field names.
- Each new data object must start on its own line of text (thus any extra values that may have existed on the previous line of text will be ignored, though some warning messages are recommended)

- When encountering the comment string ‘///’ in one of these lines of the text file, all text to the right of this is ignored. Comments need not be stored by the software tools however.
- Blank lines, or lines whose first characters are ‘///’ will be ignored as comments.
- Remember that the right curly brace must appear on its own line at the end of the data list.
- Strings can be enclosed in double quotes, but this is not required. You should however always enclose strings that contain spaces in double quotes. Otherwise, strings containing spaces would cause errors in parsing because the values are space-delimited.
- The order in which the object records are read from inside of the same object type section will NOT impact the result of reading that section. For some objects that can refer to other objects of the same type this will require the parser to be sophisticated enough to handle this. For example, Model Expression #1 may take the maximum value of Model Expression #2 and #3. The file format specification does NOT require that Model Expression #2 and #3 appear in the data section BEFORE Model Expression #1. There are many similar examples.
- The order in which the object type sections are read from the file however may impact the result of reading the entire file. For example, if a Model Expression record refers to an Injection Group, then that Injection Group needs to have been defined before the Model Expression. Software tools may try to allow for these discrepancies to ease user interaction with these files, but that is not required. The format assumes that the user is responsible for being careful.

Experienced users of PowerWorld Simulator may have a question about the dialogs that commonly appear with PowerWorld Simulator asking if you would like to create a new object in your case. For this modified format the assumption will always be that objects should be created.

A sample file section is shown as follows:

```
ObjectTypeString (fieldname1, fieldname2, fieldname3, fieldname4)
{
  "Fields" "describing" "the" "object1"
  "Fields" "describing" "the" "object2"
}
ObjectTypeString2 (fieldname1, fieldname2, fieldname3)
{
  "Fields" "describing" // comment here
    "object1" // object 1 is spread across two lines of text then
  "Fields" "describing" "object2"
}
```

5.1 Area (settings for contingency modeling)

Special area contingency options are entered to specify special post contingency solution modeling of areas. The fields recognized by this object type are shown in the following table:

Field	Description and Rules for Field
ObjectID	Identifies the area using the object string in format specified in Section 2.3
CTGMakeupGen (optional, default 0.0)	Set to a numerical value for area participation factor. See Section 5.8 on field MakeUpPower for object type CTG_Options_Value.

A sample file section is shown as follows:

```
Area (ObjectID, CTGMakeupGen)
{
  "AREA 40"           0.80
  "AREA 50"           0.15
  "AREA 'PG AND E'"  0.35
  "AREA 'ALBERTA'"   0.05
}
```

5.2 Bus (settings for contingency modeling)

Special bus contingency options are entered to specify special post contingency solution modeling of buses. The fields recognized by this object type are shown in the following table.

Field	Description and Rules for Field
ObjectID	Identifies the bus using the object string in format specified in Section 2.3
CTGLoadThrow (optional, default blank)	If a bus becomes disconnected as a result of a contingency solution, all loads at the bus will move over to this bus during the solution. Specifying a value of blank means that this will not occur at all. A blank value is the default value. The bus is identified using the object string in format specified in Section 2.3.

A sample file section is shown as follows:

```
Bus (ObjectID, CTGLoadThrow)
{
  "Bus 50"           "Bus 52"
  "Bus 'Jackie43_345.00'" "Bus 'Jackie44_345.00'"
}
```

5.3 Voltage Control Group (settings for contingency modeling)

Special Voltage Control Groups are created to which switched shunts are assigned so that switching can be properly coordinated during a contingency power flow solution. The following modification is made to how switched shunt control is performed in the contingency power flow solution.

1. Process all the other shunts in each “Voltage Control Group” as follows
 - a. Determine the switched shunt that has the largest deviation below V_{low} (call this shunt “LowShunt”)
 - b. Determine the switched shunt that has the largest deviation above V_{high} (call this shunt “HighShunt”)
 - c. Note: measure *largest deviation* in kV not per unit (thus regulated buses with a higher nominal voltage have a higher precedence)
 - d. Note: Only switched shunts that are marked as Control Mode = Discrete participate in these control groups. Any marked as Continuous, SVC, Fixed, or BusShunt will be ignored and will not switch at all (including in Step 2 below)
 - e. If *LowShunt* was found, then move that switch shunt UP by one step
Else if *HighShunt* was found move this shunt DOWN by one step
2. Once all voltage control groups are processed simply perform the rest of the switched shunt as has always been done, but ensure we don’t move any shunts that are part of a Voltage Control Group.

The fields recognized by this object type are shown in the following table:

Field	Description and Rules for Field
Name (key)	The name of the voltage control group
Status (optional, default ON)	Status of the group. Set to one of the following three choices: ON : This means that during the power flow solution, all shunts in this voltage control group will use the modified control method. Note that shunts will still be disabled if the global option for disabling switched shunt control is chosen. OFF : This means the shunts in the voltage control group default back to their individual settings so the solution behaves as though the voltage control group does not exist. FORCEON : This works the same as ON, but will ignore the global option for disabling the switched shunt control.

A sample file section is shown as follows:

```
VoltageControlGroup (Name, Status)
{
  "My Group Name 1" "ON"
  "My Group Name 2" "OFF"
  "My Group Name 3" "FORCEON"
}
```

5.4 Shunt Voltage Control Group (settings for contingency modeling)

Special switched shunt contingency options are entered to specify groups of switched shunts that will coordinate their switching during a power flow solution. The fields recognized by this object type are shown in the following table:

Field	Description and Rules for Field
ObjectID	Identifies the shunt using the object string in format of Section 2.3
VoltageControlGroup (optional, default blank)	Name of the Voltage Control Group to which the shunt belongs.

A sample file section is shown as follows:

```
Shunt (ObjectID, VoltageControlGroup)
{
  "Shunt 'Texan_69.0' '1'" "My Group Name 1"
  "Shunt 'Viking_345' '1'" "My Group Name 1"
  "Shunt 'Viking_345' '2'" "My Group Name 2"
  "Shunt 'Jet_69.0' '1'" "My Group Name 2"
  "Shunt 77 '1'" "My Group Name 3"
}
```

5.5 Gen (settings for contingency modeling)

Special generator contingency options are entered to specify post contingency solution modeling of generators. The fields recognized by this object type are shown in the following table:

Field	Description and Rules for Field
ObjectID	Identifies the generator using the object string in format of Section 2.3
CTGPreventAGC (optional, default NO)	Set to one of the following three choices: Respond : Generator MW output will respond to changes during the contingency power flow solution YES : Generator MW output will not change NO : Setting specified in the case will be used (the AGC field)
CTGPartFact (optional, default same)	Specifies a participation factor that will be used to determine the amount of response from a generator relative to other generators. Specifying a value of "same" will instruct the software to use the same participation factor as it would normally use (will use the PartFact field of the generator).
CTGMaxResp (optional, default blank)	Specify the maximum MW deviation allowed during the contingency power flow solution. Value may be specified as a number of MW, or if the value ends with the character % then the maximum MW response will be calculated as this percentage of the maximum MW limit of the generator. A blank or negative entry may also be specified to instruct that no special maximum response be enforced (normal generator MW limits would still be enforced regardless of this setting).
UseLineDrop (optional, default NO)	Set to either YES, NO or POSTCTG. NO : Use normal voltage control based on the regulated bus and voltage setpoint. YES : Use line drop compensation voltage control always, including in the power flow solution. POSTCTG : Use line drop compensation voltage control only during the contingency power flow solution. When set to POSTCTG, the Rcomp and Xcomp values and pre-contingency P and Q of the generator will be used to calculate the pre-contingency voltage of the compensated voltage and the generator will operate to maintain the compensated voltage at a constant during the contingency power flow solution. Also, if Rcomp and Xcomp are near zero, instead of modeling line drop the contingency processor will change the generator to regulate its own terminal bus to contingency reference state value.
Rcomp (optional, default 0.0)	Line Drop Compensation or Reactive Current Compensation resistance value used during a contingency power flow solution. Value will be expressed in per unit on the system MVA base. Negative values signify reactive current compensation, while positive values signify line drop compensation.
Xcomp (optional, default 0.0001)	Line Drop Compensation or Reactive Current Compensation reactance value used during a contingency power flow solution. Value will be expressed in per unit on the system MVA base. Negative values signify reactive current compensation, while positive values signify line drop compensation.

A sample file section is shown as follows:

```

Gen (ObjectID,CTGPreventAGC,CTGPartFact, CTGMaxResp, UseLineDrop, Rcomp, Xcomp)
{
"Gen 'Texan_69.0' '1' " "NO"      same      22.0      "NO"      0.0000  0.0001
"Gen 'Viking_345' '1' " "YES"     54.0     "11%"     "NO"      0.0000  0.0123
"Gen 'Viking_345' '2' " "RESPOND" same      5.0      "PostCTG" 0.0000 -0.0500
"Gen 'Jet_69.0' '1' " "YES"     88.0     " "       "PostCTG" 0.0000  0.0512
"Gen 55 '1' " "NO"      same      " "       "NO"      0.0000  0.0001
}

```

5.6 Shunt Control (settings for contingency modeling)

Special switched shunt contingency options are entered to specify post contingency solution modeling of generators. The fields recognized by this object type are shown in the following table:

Field	Description and Rules for Field
ObjectID	Identifies the switched shunt using the object string in format of Section 2.3
CTGShuntMode (optional, default is Default)	Specify a value to which ShuntMode should be changed during the post contingency power flow solution. Options are the same as for ShuntMode field (<i>Fixed</i> , <i>Discrete</i> , <i>Continuous</i> , <i>Bus Shunt</i> , or <i>SVC</i>) but the value may also be set to <i>Default</i> indicating that it should not change the ShuntMode during the Post-Contingency auxiliary file.
CTGRegUse (optional, default NO)	If this value is set to <i>YES</i> , then during the post contingency power flow solution the RegHigh and RegLow of the switched shunt will be changed to match CTGRegHigh and CTGRegLow. If the existing shunt is set to use the RegTargetHigh value then the target values will be changed such that <ul style="list-style-type: none"> • RegTarget = CTGRegLow • RegTargetHigh = CTGRegHigh Otherwise, the target value will be changed to the middle of the new range with a value of <ul style="list-style-type: none"> • $RegTarget = (CTGRegLow + CTGRegHigh)/2$
CTGRegLow (optional, default 0.99)	Used as described in CTGRegUse above.
CTGRegHigh (optional, default 1.00)	Used as described in CTGRegUse above.
CTGMvarUse (optional, default NO)	This is only used for switched shunts that are one of the following control models (the CTGShuntMode above could make this become true during the contingency solution.) <ol style="list-style-type: none"> 1. Continuous Control Mode 2. SVC Control Mode (but not if SVCType = svsmo2) If this value is set to <i>YES</i> , then during the post-contingency power flow solution, fields associated with the shunt blocks and use of continuous element of the switched shunt will be modified to achieve the CTGMvarMin and CTGMvarMax values specified.
CTGMvarMin (optional, default 0.0)	Used as described in CTGMvarUse above.
CTGMvarMax (optional, default 0.0)	Used as described in CTGMvarUse above.

A sample file section is shown as follows:

```

Shunt (ObjectID,CTGShuntMode,CTGRegUse,CTGRegHigh,CTGRegLow,
      CTGMvarUse,CTGMvarNomMax,CTGMvarNomMin)
{
"Shunt '11010' 'v1'" "Default"      "YES" 1.0450 1.0450 "YES" 50.0 -10.0
"Shunt '30585' 'v'"  "Discrete"    "NO"  ""      ""      "NO"  ""      ""
"Shunt '30631' 'v'"  "Default"      "YES" 1.0250 1.020  "YES" 30.0 -50.0
"Shunt '47439' '5'"  "Default"      "NO"  1.0250 1.0150 "NO"  9.10  0.0
"Shunt '55492' 'v'"  "Continuous"   "NO"  ""      ""      "NO"  ""      ""
"Shunt '65845' 'v'"  "Default"      "NO"  1.02556 0.99556 "NO"  20.0  0.0
}

```

5.7 Sim_Solution_Options_Value

There is set of power flow solution options that impact the contingency solutions in a contingency processor. Each power flow solution option (Sim_Solution_Options_Value) has a unique string identifier and then a particular set of potential values associated with them. The field names for the object are simply *Option* and *Value*. The following table shows a list of the string identifiers for each option and a description of what the value should contain. These options may be overridden by contingency analysis options as well, which are discussed in Section 5.8. Any file parser should simply ignore any options that the tool does not recognize, need, or use. It should simply provide warning messages that the option is not recognized, needed or used as appropriate.

Option	Value
DynAssignSlack	Set to YES to allow the contingency power flow solution to dynamically assign new slack buses if new electric islands are created as a result of switching in the contingency. Set to NO to not allow this (new islands will be treated as dead).
PUConvergenceTol	Floating point value of the convergence tolerance. Units are in per unit. Thus to express a 0.02 MVA tolerance, if SBase = 100, then enter 0.0002.
MaxItr	Integer for maximum inner power flow loop calculation iterations
MinVoltILoad	Floating point for minimum PU Voltage for Constant Current Loads
MinVoltSLoad	Minimum PU Voltage for Constant Current Loads Minimum PU Voltage for Constant Power Loads
EnforceGenMWLimits	Set to YES to enforce generator MW limits or NO to not enforce
MaxItrVoltLoop	Integer for maximum voltage control loop calculation iterations (generator Mvar checking, tap control, shunt control, etc.)
LTCTapBalance	Set to YES to force parallel transformer taps to balance their tap ratios or NO to leave them alone.
ChkPhaseShifters	Set to YES to allow phase shifter control or NO to prevent it.
ChkSVCs	Set to YES to allow SVC switched shunt control or NO to prevent it.
ChkShunts	Set to YES to allow switched shunt control or NO to prevent it.
ChkTaps	Set to YES to allow transformer tap ratio control or NO to prevent it.
ChkDCTaps	Set to YES to allow DC transmission lines to move transformer tap as part of the DC transmission line voltage control. Set to NO to prevent it.

ChkVarImmediately	Set to YES to check generator Mvar limits after each inner power flow loop iteration.
MinLTCSense	Specify a floating point value representing the minimum transformer tap sensitivity (derivative of control voltage with respect to change the tap ratio). Transformers with a sensitivity below this value will not be moved.
ModelPSDiscrete	Set to YES to model phase shifters as a discrete control or NO to allow the phase shift angle to vary continuously between the minimum and maximum angle.
PreventOscillations	Set to YES to prevent controller oscillations.
ShuntInner	Set to YES to model continuous switch shunts as PV buses in the inner power flow loop.

A sample file section is shown as follows:

```

Sim_Solution_Options_Value (Option,Value)
{
  "DynAssignSlack"      "YES"
  "DisableOptMult"     "NO"
  "MaxItr"              "100"
  "MinVoltILoad"       "0"
  "MinVoltSLoad"       "0"
  "AGCTolerance"       "0.05"
  "EnforceGenMWLimits" "YES"
  "LTCtapBalance"      "YES"
  "ChkPhaseShifters"   "YES"
  "ChkSVCs"            "YES"
  "ChkShunts"          "YES"
  "ChkTaps"            "YES"
  "ChkDCTaps"          "YES"
  "DisableGenMVRCheck" "NO"
  "ChkVarImmediately"  "NO"
  "MaxItrVoltLoop"     "20"
  "MinLTCSense"        "0.01"
  "ModelPSDiscrete"    "NO"
  "PreventOscillations" "YES"
  "ShuntInner"         "YES"
}

```


5.8 CTG_Options_Value

Each contingency solution option has a unique string identifier and then a particular set of potential values associated with them. The field names for the object are simply *Option* and *Value*. The following table shows a list of the string identifiers for each option and a description of what the value should contain. Any file parser should simply ignore any options that the tool does not recognize, need, or use. It should simply provide warning messages that the option is not recognized, needed or used as appropriate.

Option	Value
TSMModelsTrip	Comma-delimited list of transient stability model types that will act or trip in the contingency processor. See Section 5.8.1 for more details.
TSMModelsMonitor	Comma-delimited list of transient stability model types that will only be monitored in the contingency processor. See Section 5.8.1 for details.
TSMModelMaxDelay	A number of seconds. See Section 5.8.1 for more details.
DisableGenDropOverlap	There are particular ContingencyElement actions that open generators within an injection group in merit order. If more than one contingency element such as this is implemented in the same contingency, then there may be overlap in the list of generators between the multiple injection groups. Set this value to YES to treat these actions independently. Set this value to NO to count any generation change in the first injection group to count toward the total change desired in subsequent injection groups.
MakeUpPower	Set to one of the following three choices Area Part Factors : Specifies that changes in injection caused by the contingency should be made up by the areas in the case in proportion to the Area records CTGMakupGen factors (see Section 5.1). Within each area, the individual participation factors of generators on AGC determine how much power will come from each generator. Gen Part Factors : Specifies that changes in injection caused by the contingency should be made up by the all generators in the case in proportion to the individual participation factors of generators on AGC. Same as Power Flow : Specifies that changes in injection caused by the contingency should be made up in the same way that the regular power flow solution is configured to solve. <i>This option is not recommended.</i>
AGCTolerance	Specify the MW control loop solution tolerance in MWs
IgnoreRASIfTrueInRef	Set to YES to disable any RemedialActionElements where the Model Criteria evaluates to true in the reference case. <i>Added in Simulator Version 20</i>

All of the Sim_Solution_Options_Value options presented in Section 5.7 may be overridden by a contingency analysis specific option. Within the CTG_Options_Value records any of these values may be specified as `Default` which will indicate that the option simply defaults to the global power flow

solution options shown in Section 5.7. The following options are also available for the CTG_Options_Value object and represent advanced limit monitoring settings that will ignore or report special limit violations based on a change monitored value from the contingency reference case.

Option	Value
MonDiscBus	Set to YES to report as a violation any bus that becomes disconnected as a result of a contingency. Set to NO to not do this.
VoltChangePercent	Set to YES to treat following change values as a percentage change from the contingency reference case. Thus if AlwaysLowVoltDec = 0.05 interpret this as a 5% decrease from the reference case. Set to NO to treat voltage changes as a per unit change, thus 0.05 means a 0.05 per unit change.
The following 5 options allow the specification of limit violations that should always be reported based on a change in value from the contingency reference case, even if the value does not exceed the limits	
AlwaysReport	Set to YES to enable the following 4 options for always reporting violations based on a change in value from the contingency reference case. Set to NO to ignore these 4 options.
AlwaysBranchInc	Specify a percentage. This is the minimum change in a branch flow in percentage (of the post-contingency rating) that the loading on a branch must increase so that the branch gets reported as a violation
AlwaysHighVoltInc	Specify a per unit voltage change (interpretation is determined by field VoltChangePercent). This is the minimum amount that a bus voltage must increase for a bus high voltage violation to be reported
AlwaysInterfaceInc	Specify a percentage value. This is the minimum change in interface flow in percentage (of the post-contingency rating) that the loading on an interface must increase so that the interface gets reported as a violation.
AlwaysLowVoltDec	Specify a per unit voltage change (interpretation is determined by field VoltChangePercent). This is the minimum amount that a bus voltage must decrease for a bus low voltage violation to be reported.
The following 5 options allow the specification of limit violations that should never be reported based on a change in value from the contingency reference case, even if the value does exceed the limits	
NeverReport	Set to YES to enable the following 4 options for never reporting violations based on a change in value from the contingency reference case. Set to NO to ignore these 4 options.
NeverBranchInc	Specify a percentage value. This is the minimum change in percentage (of the post-contingency rating) that the loading on a line/transformer must increase before the line/transformer gets reported as a violation.
NeverHighVoltInc	Specify a per unit voltage change (interpretation is determined by field VoltChangePercent). This is the minimum change in a bus voltage that must occur for bus high voltage violation to be reported.
NeverInterfaceInc	Specify a percentage value. This is the minimum change in percentage (of the post-contingency rating) that the loading on an interface must increase before the interface gets reported as a violation.
NeverLowVoltDec	Specify a per unit voltage change (interpretation is determined by field VoltChangePercent). This is the minimum change in a bus voltage that must occur for a bus low voltage violation to be reported.

A sample file section is shown as follows:

```

CTG_Options_Value (Option, Value)
{
"MakeUpPower"           "Gen Part Factors"
"AGCTolerance"          "0.05"
"DisableGenDropOverlap" "NO"
"TSModelsTrip"         "LOCTI, TIOCRS, TIOCR1"
"TSModelsMonitor"      "MSC1"
"TSModelMaxDelay"      "3600"
"DynAssignSlack"       "YES"
"PUConvergenceTol"    "0.0002"
"MaxItr"               "100"
"MinVoltILoad"         "Default"
"MinVoltSLoad"         "Default"
"EnforceGenMWLimits"  "YES"
"MaxItrVoltLoop"      "Default"
"LTCTapBalance"       "YES"
"ChkPhaseShifters"    "NO"
"ChkSVCs"             "YES"
"ChkShunts"           "NO"
"ChkTaps"              "NO"
"DisableGenMVRCheck"  "NO"
"ChkVarImmediately"   "YES"
"MinLTCsense"         "Default"
"ModelPSDiscrete"     "NO"
"PreventOscillations" "YES"
"ShuntInner"          "YES"
}

```

5.8.1 Using Transient Stability Dynamic Models in Steady State Contingency Analysis

Transient stability dynamic models can be handled in the steady state power flow environment when appropriate. Obviously a generator stabilizer or exciter model will not be used in a steady state solution, but some dynamic models specify behavior that occurs in the same time frame as steady state power flow contingency solutions are meant to model (say between 60 seconds and several minutes). Examples of whether different models may apply are as follows:

Models applicable to a Steady State Power Flow Solution	Models <u>not</u> applicable to a Steady State Power Flow Solution
<ul style="list-style-type: none"> • Over-Current Branch Relays • Under/Over Voltage Relays for Generators, Load, or Lines • Switched Shunt Models • Distance/Impedance Relays • Under voltage motor tripping specified with a motor • Possibly Load Voltage-Dependent Models 	<ul style="list-style-type: none"> • Generator Stabilizer • Generator Exciter • Generator Machine Models • Generator Governor Models (might switch sides some day?) • Load Motor Dynamic Models • Over or Under Frequency Models for Generators, Load, or Branches

An ability to optionally specify which types of dynamic models should be automatically handled in power flow contingency analysis should be defined in the file format. This is handled by the special contingency solutions options TSModelsTrip and TSModelsMonitor shown in the earlier table.

Transient stability model types that are listed in TSModelsTrip will model the steady state behavior of the dynamic model and cause actions to occur if appropriate. For example, an over-current relay may cause a transformer to open if the current exceeds the pickup threshold.

Transient stability model types that are listed in TSModelsMonitor will not cause actions to occur, but the contingency processor will report if a dynamic model would have caused an action to occur. For instance an over-current relay may report that the transformer would have tripped. This reporting should be similar to reporting violations in any existing contingency analysis processor

When processing transient stability models listed in TSModelsTrip and TSModelsMonitor, any dynamic model that would not respond within the time delay TSModelMaxDelay will be assumed to not act in the power flow contingency processor. The default value is 3600 seconds (1 hour), so if a relay setting had a time delay of 5000 seconds then it would not act in the power flow contingency processor. The intent of the field TSModelMaxDelay is not to specify what time delays should be considered. Because this is representing steady state analysis, we expect that any reasonable time delays would always be reached. The intent of TSModelMaxDelay is to detect user settings in the transient stability models that the user really intended to signify a “disabled” model. For example, a user may change a time delay to 9999 as a way to disable the model. That works fine in transient stability as you’d never run the simulation that long. While it would be more appropriate to go to the stability model and disable the model itself, the user may do what was just described instead. Thus our intent was to say any relay with a time delay greater than 3600 seconds (1 hour) means the model should be ignored.

Note that any dynamic model that is not listed in either TSModelsTrip or TSModelsMonitor will simply be ignored by the power flow contingency processor. This will be the default behavior of contingency processors.

5.9 Interface and InterfaceElement

An Interface represents a collection of Branch, DCTransmissionLine, InjectionGroup, Gen, Load, MultiSectionLine, and Interface object, as well as potentially some BranchOpen or BranchClose entries which represent the contingent elements. The fields recognized by the Interface object type are shown in the following table.

Field	Type	Description
Name (key)	String	Name of the Interface
Number (optional, defaults to highest existing Number and adds 1)	Integer	Number of the Interface
MonDirection (required)	String	Direction in which the interface is monitored: Either FROM -> TO, TO -> FROM
MonBoth (optional, default NO)	String	Set to YES to monitor both directions
MWOffSet (optional, default 0.0)	Real	Number specifying a shift applied to the value reported as
LimitMWA... LimitMWO (optional, default 0.0)	Real	15 MW limits associated with the interface
LimitMWANeg... LimitMWO Neg (optional, default 0.0)	Real	15 negative MW limits associated with the interface <i>Added in Simulator Version 20</i>
DataMaintainerAssign (optional, default blank)	String	Name of the DataMaintainer for this object. This can be blank as well which indicates no DataMaintainer has been assigned.

Interfaces are made up of any number of InterfaceElement objects. The fields recognized by the InterfaceElement object type are shown in the following table:

Field	Type	Description
InterfaceName (key)	String	Name of the Interface to which the InterfaceElement Belongs
Element (key)	Integer	Description of the value measured for this InterfaceElement There are eleven kinds of elements allowed in an interface. Please note that the direction specified in the monitoring elements is important. <ul style="list-style-type: none"> "BRANCH num1 num2 ckt" : Monitor the MW flow on the branch starting from bus num1 going to bus num2 with circuit ckt. (order of bus numbers defines the direction) "AREA num1 num2" : Monitor the sum of the AC branches that connect area1 and area2. "ZONE num1 num2" : Monitor the sum of the AC branches that connect zone1 and zone2. "BRANCHOPEN num1 num2 ckt" : When monitoring the elements in this interface, monitor them under the

		<p>contingency of opening this branch.</p> <ul style="list-style-type: none"> • "BRANCHCLOSE num1 num2 ckt" : When monitoring the elements in this interface, monitor them under the contingency of closing this branch. • "DCLINE num1 num2 ckt" : Monitor the flow on a DC line. • "INJECTIONGROUP 'name'" : Monitor the net injection from an injection group (generation contributes as a positive injection, loads as negative). • "GEN num1 id" : Monitor the net injection from a generator (output is positive injection) • "LOAD num1 id" : Monitor the net injection from a load (output is negative injection). • "MSLINE num1 num2 ckt" : Monitor the MW flow on the multi-section line starting from bus num1 going to bus num2 with circuit ckt. • "INTERFACE 'name'" : Monitor the MW flow on the interface given by name. • "GENOPEN num1 id" : When monitoring the elements in this interface, monitor them under the contingency of closing this generator. <i>(GENOPEN added in January 9, 2018 patch of Simulator 20)</i> • "LOADOPEN num1 id" : When monitoring the elements in this interface, monitor them under the contingency of closing this load. <i>(LOADOPEN added in January 9, 2018 patch of Simulator 20)</i> <p>Note: bus# values may be replaced by a string enclosed in single quotes where the string is the name of the bus followed by an underscore character and then the nominal voltage of the bus. Labels may also be used as follows.</p> <ul style="list-style-type: none"> • bus# values for all element types may be replaced by a string enclosed in single quotes where the string is the label of the bus. • for GEN or LOAD elements, the section <i>num1 id</i> may be replaced by the device's label. • For MSLINE, DCLINE, or BRANCH elements, the <i>num1 num2 ckt</i> section may be replaced by the device's label.
MeterFar (optional, default NO)	String	Set to YES to meter at the far end of the Element. Otherwise set to NO. Note that the <i>direction</i> of the element is determined by the Element field. This only determines which end to meter and not the directionality of the measurement.
Weight (optional, default 1.0)	Real	A number by which the measured flow will be multiplied.

PartFact (optional, default 0.0)	String	Enter a string representing a numeric value for the participation factor or a field or Model Expression used for calculating the numeric value of the participation factor. To indicate a field or Model Expression, the following syntax can be used: <Field>Field Name : Set equal to the value of this field for the Element. The fields are the strings described in Section 2.4. <Expression>Name : Set equal to the value of this Model Expression.
--	---------------	--

A sample file section is shown as follows:

```

INTERFACE (Number,Name,MonDirection,MWOffset,MonBoth,LimitMWA,LimitMWB,
          LimitMWC,LimitMWD,LimitMWE,LimitMWF,LimitMWG,LimitMWH,LimitMWI,
          LimitMWJ,LimitMWK,LimitMWL,LimitMWM,LimitMWN,LimitMWO,
          DataMaintainerAssign)
{
  1 "ALBERTA - BRITISH COLUMBIA " "FROM -> TO" 0.0000 "NO " 1000.0 -1200.0 0.0
0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 "DM1"
  2 "ALBERTA - SASKATCHEWAN " "FROM -> TO" 0.0000 "NO " 150.0 -150.0 0.0
0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 "DM1"
  76 "ALTURAS PROJECT" "FROM -> TO" 0.0000 "NO " 300.0 -300.0 0.0
0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 "DM1"
}

INTERFACEELEMENT (InterfaceName,Element,MeterFar,Weight,PartFact)
{
"ALBERTA - BRITISH COLUMBIA" "BRANCH 54456 50791 1" "NO " 1.000000 0
"ALBERTA - BRITISH COLUMBIA" "BRANCH 54232 50776 1" "YES" 1.000000 0
"ALBERTA - BRITISH COLUMBIA" "BRANCH 54329 50830 1" "NO " 1.000000 0
"ALBERTA - SASKATCHEWAN" "BRANCH 54674 55473 30" "YES" 1.000000 0
"ALTURAS PROJECT" "BRANCH 40537 64058 1" "NO " 1.000000 0
}

```

5.10 InjectionGroup and PartPoint

An InjectionGroup represents a collection of generators, loads, switched shunts, or other injection groups. A primary purpose when modeling contingencies is to use an injection group to model generator drop schemes. The fields recognized by the InjectionGroup object type are shown in the following table.

Field	Description and Rules for Field
Name (key)	Name of the Injection Group. There can be only one Injection Group with this name.
DataMaintainerAssign (optional, default blank)	Name of the DataMaintainer for this object. This can be blank as well which indicates no DataMaintainer has been assigned.

Injection Groups are made up of any number of PartPoint objects. The fields recognized by the PartPoint object type are shown in the following table:

Field	Description and Rules for Field
GroupName (key)	Name of the Injection Group to which this PartPoint belongs
Object (key)	Identifies the object for this injection point using the object string in format specified in Section 2.3. The object type must be either Gen, Load, Shunt or InjectionGroup.
AutoCalcMethod (required)	<p>Specifies how the participation factor of this object is determined. The choices depend on the object type as shown below.</p> <p>GEN</p> <p><i>SPECIFIED</i> : Set to the numerical value in field PartFact <i>MAX GEN MW</i> : Set equal to the Maximum MW Output <i>MAX GEN INC</i> : Set equal to the (Max MW – Present MW) <i>MAX GEN DEC</i> : Set equal to the (Present MW – Min MW) <Field>Field Name : Set equal to the value of this generator field. The fields are the strings described in Section 2.4. <Expression>Name : Set equal to the value of this Model Expression.</p> <p>LOAD</p> <p><i>SPECIFIED</i> : Set to the numerical value in field PartFact <i>LOAD MW</i> : Set Equal to the Load MW <Field>Field Name : Set equal to the value of this load field. The fields are the strings described in Section 2.4. <Expression>Name : Set equal to the value of this Model Expression.</p> <p>SHUNT</p> <p><i>SPECIFIED</i> : Set to the numerical value in field PartFact <i>MAX SHUNT MVAR</i> : Set equal to the Maximum Mvar <i>MAX SHUNT INC</i> : Set equal to the (Max Mvar – Present Mvar) <i>MAX SHUNT DEC</i> : Set equal to the (Present Mvar – Min Mvar) <Field>Field Name : Set equal to the value of this shunt field. The fields are the strings described in Section 2.4. <Expression>Name : Set equal to the value of this Model Expression.</p> <p>INJECTIONGROUP</p> <p><i>SPECIFIED</i> : Set to the numerical value in field PartFact <Field>Field Name : Set equal to the value of this injection group field. The fields are the strings described in Section 2.4. <Expression>Name : Set equal to the value of this Model Expression.</p>
PartFact (required)	Present numeric value for the participation factor. It may be automatically recalculated based on the AutoCalcMethod and AutoCalc fields.
AutoCalc (required)	Set to YES to specify that the participation factor value should be automatically recalculated before every use of the injection group based on the AutoCalcMethod. If set to NO, the PartFact should be specified.

A sample file section is shown as follows:

```

InjectionGroup (Name,DataMaintainerAssign)
{
"Boundary Generators" "DM1"
"Bridger Generators" "DM1"
}
PartPoint (GroupName, Object, AutoCalcMethod, PartFact, AutoCalc)
{
"Boundary Generators" "GEN 46464 51" "MAX GEN MW" 50 "YES"
"Boundary Generators" "GEN 46466 52" "MAX GEN MW" 50 "YES"
"Boundary Generators" "GEN 46468 53" "MAX GEN MW" 50 "YES"
"Bridger Generators" "GEN 65386 1" "SPECIFIED" 557.00 "NO"
"Bridger Generators" "GEN 65387 1" "SPECIFIED" 557.00 "NO"
"Bridger Generators" "GEN 65388 1" "<Expression>MyName" 557.00 "NO"
"Bridger Generators" "GEN 65389 1" "<Field>Mvar" 557.00 "NO"
}

```

5.11 ModelExpression

ModelExpressions are mathematical expressions evaluated from one or more system parameters. For example, they would be used to model a RAS arming lookup table and as part of other RAS conditions. The fields recognized by the ModelExpression object type are shown in the following table:

Field	Description and Rules for Field
Name (key)	Name of the Model Expression contained in double quotes. This field is the unique identifier for the Model Expression.
Type (required)	Either Expression Or Lookup For Expression types, up to 8 variables may be specified by the fields defined by field names x1 through x8. If the Lookup type is used, then the field defined by field name x1 will represent the field used for a 1D lookup. For a 2D lookup the fields are defined by x1 and x2
Expression (optional, default blank)	When expression type is Expression then this represents the function of up to 8 variables. The expression should be written using the variable names x1, x2, x3, x4, x5, x6, x7, and x8. The functions supported by the Expression String are listed in Section 5.11.2.
Memo (optional, default blank)	Extra string enclosed in quotes
Object1, Object2, Object3, Object4, Object5, Object6, Object7, Object8 (optional, default blank)	There are 8 objects strings specify the object using the format described in Section 2.3.
x1, x2, x3, x4, x5, x6, x7, x8 (optional, default blank)	There are 8 field names which represent the field for a particular object using the convention described in Section 2.4.

BlankZero1, BlankZero2, BlankZero3, BlankZero4, BlankZero5, BlankZero6, BlankZero7, BlankZero8 (optional, default NO)	The result of evaluating a particular Object1:x1 combination may not always be a numerical value. It may also be a blank value indicating that the value is not defined. An example of this is the GenMW field of a bus object. BlankZero values determine how blank values should be treated for the 8 fields. If BlankZero1 is YES then a value for Object1:x1 which is blank will be evaluated as though Object1:x1 is a zero. If BlankZero1 is NO then a blank value for Object1:x1 will result in the entire expression evaluating to blank (invalid). (Note: omitting this value will result in a default of NO)
EvalInRef1, EvalInRef2, EvalInRef3, EvalInRef4, EvalInRef5, EvalInRef6, EvalInRef7, EvalInRef8 (optional, default NO)	These values determine whether the particular fields of objects are evaluated in the contingency reference state. An example use would be a Model Expression which calculates the change in the MWFrom values of a branch from the reference state value. (Note: omitting this value will result in a default of NO) <i>Added in Simulator Version 19, December 18, 2015 patch</i>
DataMaintainerAssign (optional, default blank)	Name of the DataMaintainer for this object. This can be blank as well which indicates no DataMaintainer has been assigned.

5.11.1 Lookup Tables

Lookup tables allow returning a value from a lookup based on the value of the specified x1 and/or x2 fields instead of specifying a mathematical expression.

The ModelExpression requires a special feature in the file format to handle the specification of a lookup table. This is done by using special tags to surround the lookup table specification. The lookup table is initiated by a line of text which starts with the tag <SUBDATA LookupTable> and then terminated by a line of text that starts with the tag </SUBDATA>. The formatting inside the tags is described as follows.

A lookup table represents either one or two dimensional tables (1D or 2D). This is determined by reading the first string in the first row inside the SUBDATA section. If the first text row inside the SUBDATA section starts with the string "x1x2", this signifies that this represents a two dimensional lookup table, otherwise it signifies a one-dimensional lookup table.

For 2D lookup tables, from that first string it will read the remainder of the numerical entries in the first row as x2 lookup points, the first column in the remainder of the rows as the x1 lookup points, and the subsequent entries as the various result values for the lookups for respective values of x1 and x2. The lookup value that is returned from the lookup is the intersection of the present values of fields x1 and x2 in the table where both values are less than or equal to the lookup points. Note that all x2 lookup points must be on the first line of text (no line wrapping allowed). Also each subsequent also does not allow text line wrapping.

For 1D tables the remainder of the first line of the SUBDATA section is ignored and in the following rows the first entry represents x1 lookup points while the second value represents the lookup value. The value that is returned from the table is the lookup value where the present value of x1 is less than or equal to the lookup point.

A sample file section is shown as follows:

```

ModelExpression (Name, Type, Expression, Memo, Object1, x1, Object2, x2,
                DataMaintainerAssign)
{
"Gen Drop Table 1" "Lookup" "" "Memo Str"
  "Interface 'My Int Name1'" "MW" "" "" "DM1"
  <SUBDATA LookupTable>
  // because it does not start with the string x1x2 this will
  // represent a one dimensional lookup table
  x1 Value // first row is ignored
  2700.0 0.0
  2900.1 500.9
  3200.2 1100.8
  4400.3 1700.7
  4800.4 1700.6
  </SUBDATA>
"Gen Drop Table 2" "Lookup" "" "Memo String Here"
  "Interface 'My Int Name1'" "MW" "Interface 'My Int Name2'" "MW" "DM1"
  <SUBDATA LookupTable>
  // because this starts with x1x2 this represent a two dimensional
  // lookup table. The first row represents lookup values for x2
  // The first column represents lookup values for x1.
  x1x2 1500 1600.5 1800 2000 2200 2400 2600 2800 3000 3100
  1900.0 0 0 0 0 0 0 0 0 0 0
  2000.1 0 0 0 0 0 0 0 0 0 600.9
  2200.2 0 0 0 0 0 0 0 0 600 600.8
  2400.3 0 0 0 0 0 0 0 600 900 900.7
  2600.4 0 0 0 0 0 0 600 900 900 900.6
  2800.5 0 0 0 0 0 600 900 900 900 1200.5
  3000.6 0 0 0 0 600 900 900 900 1500 1800.4
  3200.7 0 0 0 600 900 900 900 1500 2100 2400.3
  3400.8 0 0 600 900 900 900 1500 2100 2700 2850.2
  3600.9 0 600 900 900 900 1500 2100 2700 2850 2850.1
  3800.0 0 900.2 900 900 1500 2100 2600 2800 2850 2850.0
  4000.1 0 900.3 900 1500 2100 2400 2600 2800 2850 2850.9
  4200.2 0 900.2 1500 2000 2200 2400 2600 2800 2850 2850.8
  4400.3 0 1500.1 1800 2000 2200 2400 2600 2800 2850 2850.7
  4600.4 0 1600.1 1800 2000 2200 2400 2600 2800 2850 2850.6
  </SUBDATA>
  // remember that the list of 8 fields can be spread across multiple lines
"Gen Drop Armed" "Expression" "-max(x1,x2)" "Memo String Here"
  "ModelExpression 'Gen Drop Table 1'" "Expression" // Object1 x1
  "ModelExpression 'Gen Drop Table 2'" "Expression" // Object2 x2
}

```

5.11.2 Functions Available for Expression String

The functions available for use inside the Expression strings are as follows. Note that trigonometric functions are all in radians.

Function	Description	Example
()	Prioritizes an expression	5*(1+1) = 10
FACT	Factorial	5! = 120fact(5) = 120
^	Raised to the power of	4 ^ 5 = 1024
*	Multiply by	3 * 6 = 18
/	Divide by	9 / 2 = 4.5
DIV	Integer divide by	9 div 2 = 4
MOD	Modulo (remainder)	7 mod 4 = 3

Function	Description	Example
SIN	Sine	sin(pi) = 0
COS	Cosine	cos(pi) = -1
TAN	Tangent	tan(pi) = 0
ASIN	Arc sine	asin(1) = 1.570
ACOS	Arc cosine	acos(-1) = 3.14
ATAN	Arc tangent	atan(0) = 0
SEC	Secant	sec(0) = 1

+	Add	1 + 1 = 2
-	Subtract	9 - 5 = 4
>	Greater than	9 > 2 = 1
<	Less than	7 < 4 = 0
==	Equal test	5 == 4 = 0
>=	Greater or equal	3 >= 3 = 1
<=	Less or equal	#h3E <= 9 = 0
<>	Not equal	#b10101 <> 20 = 1
NOT	NOT	Not (2 > 1) = 0 Not (1 < 2) = value other than zero
AND	AND	(2 > 1) AND (2 > 3) = 0
OR	OR	(2 > 1) OR (2 > 3) = value other than zero
XOR	Exclusive OR	(2 > 1) XOR (3 > 1) = 0
IIF	If condition	IIf(1+1==2,4,5) = 4
MIN	Minimum value	min(10,3,27,15) = 3
MAX	Maximum value	max(1,9)=9
ABS	Absolute value	abs(-8) = 8
CEIL	Round up	ceil(6.2) = 7
RND	Random number	rnd(1) = .969
INT	Truncate to an integer	int(6.8) = 6
SGN	Sign of expression (-1, 0,or1)	sgn(-9) = -1
SQRT	Square root	sqrt(64) = 8

CSC	Cosecant	csc(1) = 1.18
COT	Cotangent	cot(1) = 0.642
SINH	Hyperbolic sine	sinh(3) = 10.01
COSH	Hyperbolic cosine	cosh(2) = 3.76
TANH	Hyperbolic tangent	tanh(1) = 0.76
COTH	Hyperbolic cotangent	coth(1) = 1.31
SECH	Hyperbolic secant	sech(0) = 1
CSCH	Hyperbolic cosecant	csch(1) = 0.85
ASINH	Hyperbolic arc sine	asinh(2) = 1.44
ACOSH	Hyperbolic arc cosine	acosh(9) = 2.89
ATANH	Hyperbolic arc tangent	atanh(.1) = 0.10
ACOTH	Hyperbolic arc cotangent	acoth(7) = 0.14
ASECH	Hyperbolic arc secant	asech(.3) = 1.87
ACSCH	Hyperbolic arc cosecant	acsch(2) = 0.48
EXP	e to the power of	exp(3) = 20.08
EXP2	2 to the power of	exp2(3) = 8
EXP10	10 to the power of	exp10(3) = 1000
LN	Natural log	ln(16) = 2.77
LOG2	Log base 2	log2(8) = 3
LOG10	Log base 10	log10(100) = 2

5.12 ModelCondition and ModelConditionCondition

ModelConditions are used to specify the conditions under which a contingency or RAS action should be performed or armed.

The fields recognized by the ModelCondition object type are shown in the following table.

Field	Description and Rules for Field
Name (key)	Name of the Model Condition contained in double quotes. Note: Names must be unique across all other ModelFilters and ModelConditions.
Object (optional, default blank)	The object to which the condition applies. Specify the object using the format described in Section 2.3.
FilterObjectType (required)	Most commonly, the list of ModelConditionConditions that apply to this ModelCondition are evaluated against the object referred to by Object. However, it is also possible to specify a different object type for the ModelConditionConditions. For example a BUS may be specified in the Object, but FilterObjectType may be set to BRANCH. If this is done then the Model Condition will evaluate to TRUE if any BRANCH connected to the bus meets the logic of the ModelConditionConditions. These inherent inter-object relationships are available for the object types enumerated in Section 2.2

FilterLogic (required)	Logic to apply to the list of comparisons (AND, OR, NAND, NOR, XOR, OneTRUE)
EvaluateInRef (optional, default NO)	Set to YES to cause the model condition to evaluate itself in the reference case and never reevaluate during a contingency solution
DisableIfTrueInRef (optional, default NO)	Set to YES to disable this model condition for the entire contingency run if it evaluated TRUE in the reference (this is used so that a model condition can be created that checks the status of a branch being opened, but you want to restrict it to triggering an event only when the branch is opened as a RESULT of the contingency). (See Model Filter explanation in Section 5.13.1).
Memo (optional, default blank)	Extra string enclosed in quotes
DataMaintainerAssign (optional, default blank)	Name of the DataMaintainer for this object. This can be blank as well which indicates no DataMaintainer has been assigned.

ModelConditions are made up of any number of ModelConditionCondition objects (apologies for the object type name, but nothing else makes sense). The fields recognized by the ModelConditionCondition object type are shown in the following table.

Field	Description and Rules for Field
ModelCondition (key)	Name of the ModelCondition to which this applies
CondNum (key)	Number specifying the number of the condition. Omitting this value, or specifying a value of zero will cause this to automatically add the condition to the existing ModelCondition. Otherwise by specifying a number you can edit existing conditions.
ObjectField (required)	A field associated with the object to which this model condition applies. A list of fields is shown in Section 2.4. In addition to these fields, you may also specify the string "_UseAnotherFilter" to signify that this condition refers to another Filter. This will be important for the creation of more complex nested filter definitions as described in Section 3.2.
ConditionType (required)	<p>The comparison operator applied to the ObjectField and the Value and OtherValue entries. There are many choices as follows:</p> <ul style="list-style-type: none"> = equal (should not use for numbers) <> not equal > greater than < less than >= greater than or equal <= less than or equal <p>Integer comparisons</p> <ul style="list-style-type: none"> inrange enter a string as the Value of the form "2-5, 70-90" notinrange enter a string as the Value. Opposite of inrange <p>String Comparisons</p> <ul style="list-style-type: none"> contains returns whether string contains a particular substring notcontains opposite of contains startswith returns whether a string starts with a string notstartswith opposite of startswith

	<p>Two value comparisons</p> <p>about specify two values. Return whether the field is within the OtherValue (tolerance) of the Value</p> <p>notabout specify two values. Opposite of about</p> <p>between specify two values field is between</p> <p>notbetween specify two values field is not between</p> <p>_UseAnotherFilter comparisons</p> <p>Meets returns whether another filter's conditions are met</p> <p>Not Meets returns whether another filter's conditions are not met</p>
<p>Value (optional, default 0 or blank)</p>	<p>Value or Field or Expression. The entry specifies the value to which the field is compared. This may be done in three ways</p> <p><i>Value</i> : 1.459 or a String</p> <p><i>Field</i> : start with the tag <Field> and then follow with a string using the format as the ObjectField string</p> <p><i>Model Expression</i> : start with the tag <Expression> and then follow the name of the Model Expression</p>
<p>OtherValue (optional, default 0 or blank)</p>	<p>This entry's format is the same as the previous entry. It is only used for the between, notbetween, about, and notabout Condition Types</p>
<p>Absolute (optional, default NO)</p>	<p>Set to YES to take the absolute value of the ObjectField begin compared</p>
<p>ObjectFieldEvalRef (optional, default NO)</p>	<p>Set to YES to specify that the ObjectField should be evaluated in the reference state of the contingency analysis tool.</p> <p><i>Added in Simulator Version 19, December 18, 2015 patch</i></p>

A sample file section is shown as follows:

```

ModelCondition (Name, Object, FilterObjectType, FilterLogic, EvaluateInRef,
                DisableIfTrueInRef, Memo, DataMaintainerAssign)
{
"2-11 Line (Open)"      "Branch 2 11 1"      "Branch" "AND" "YES" "YES" "check 2-11" "DM1"
"3-44 Line (Open)"      "Branch 3 44 1"      "Branch" "AND" "YES" "YES" "check 3-44" "DM1"
"Interface Bobby High" "Interface 'Bobby'" "Interface" "AND" "NO" "NO" "checkbobby" "DM1"
"Bus Jackie Low"        "Bus 'Jackie_500.00'" "Bus" "AND" "NO" "NO" "checkJackie" "DM1"
"Sample Field and Exp" "Gen 'Jackie_34.50' '1'" "Gen" "AND" "NO" "NO" "checkJackie" "DM1"
}
ModelConditionCondition (ModelCondition, CondNum, ObjectField, ConditionType,
                        Value, OtherValue, Absolute)
{
"2-11 Line (Open)"      "1" "DerivedOnline" "=" "Closed" "" "NO"
"3-44 Line (Open)"      "2" "DerivedOnline" "=" "Closed" "" "NO"
"Interface Bobby High"  "3" "MW"                ">" 500      "" "NO"
"Interface Bobby High"  "4" "Mvar"              ">" 100     "" "NO"
"Bus Jackie Low"        "5" "V"                 "<" 0.95    "" "NO"
"Sample Field and Exp"  "6" "MW"                ">" "MWMax" "" "NO"
"Sample Field and Exp"  "7" "Mvar"              ">" "Expression 'Mvar Lim'" "" "NO"
}

```

5.13 ModelFilter and ModelFilterCondition

ModelFilters are used to specify the conditions under which a contingency or RAS action should be performed or armed. They are useful for combining ModelConditions and other ModelFilters.

Field	Description and Rules for Field
Name (key)	Name of the Model Filter contained in double quotes. Note: Names must be unique across all other model filters and model conditions.
Logic (required)	Logic to apply to the list of comparisons (AND, OR, NAND, NOR, XOR, OneTRUE). OneTrue logic means that there is exactly one true input to the gate. XOR logic tests if there are an odd number of true inputs.
DisableIfTrueInRef (optional, default NO)	Set to YES to disable this model filter for the entire contingency run if it evaluated TRUE in the reference (See Model Filter explanation in Section 5.13.1). <i>Added in Simulator Version 20</i>
Memo (optional, default blank)	Extra string enclosed in quotes
DataMaintainerAssign (optional, default blank)	Name of the DataMaintainer for this object. This can be blank as well which indicates no DataMaintainer has been assigned.

ModelFilters are made up of any number of ModelFilterCondition objects. The fields recognized by the ModelFilterCondition object type are shown in the following table:

Field	Description and Rules for Field
ModelFilter (key)	Name of the Model Filter to which this applies
CondNum (key)	Number specifying the number of the condition. Omitting this value, or specifying a value of zero, will cause this to automatically add the condition to the existing ModelFilter. Otherwise you can edit existing ModelFilterConditions.
Criteria (required)	Name of a Model Filter or Model Condition in double quotes.
TimeDelay (optional, default 0.0)	Time delay in seconds. Represents the length of time that the Criteria must remain TRUE for the ModelFilterCondition to be considered to evaluate to true. When a ModelFilter is evaluated along with returning a boolean result, for TRUE results it will also return the TimeDelay required to achieve a TRUE result. The use of this field is described in Section 5.13.2
Logic (optional, default blank)	Value is either NOT or blank "NOT" : Treat logic as TRUE if it does NOT meet the Model Condition or Filter blank : Treat logic as TRUE if it does meet the Model Condition or Filter

A sample file section is shown as follows:

```

ModelFilter (Name,          Logic, Memo, DataMaintainerAssign)
{
  "One is Out"              "OR"  "Either 3-44 or 2-11 go out" "DM1"
  "Bobby Up and Jackie Down" "AND" "test on Bobby and Jackie"  "DM1"
}
ModelFilterCondition (ModelFilter, CondNum, Criteria,          Logic, TimeDelay)
{
  "One is Out"              1      "3-44 Line (Open)"          ""      5.0
  "One is Out"              2      "2-11 Line (Open)"          ""      3.0
  "Bobby Up and Jackie Down" 1      "Interface Bobby High"      ""      0.0
  "Bobby Up and Jackie Down" 2      "Bus Jackie Low"            "NOT"  0.0
}

```

5.13.1 Handling DisableIfTrueInRef for ModelFilterConditions

When the DisableIfTrueInRef field is set to YES for a ModelCondition that is used in a ModelFilterCondition and the condition is true in the contingency reference case, that ModelCondition will be ignored when evaluated as part of the ModelFilter. This means it will be evaluated to neither true nor false but instead will be treated as if it doesn't exist in the ModelFilter. If all ModelFilterConditions are ignored for the ModelFilter, the entire ModelFilter will be ignored.

Similarly, ModelFilters also have a DisableIfTrueInRef field. If this field is set to YES for a ModelFilter that is used in a ModelFilterCondition and the filter is true in the contingency reference case, that ModelFilter will be ignored when evaluated as part of the ModelFilter. This feature was *added in Simulator Version 20*.

For example, if a ModelFilter contains three conditions for three different branches being opened: Line A, Line B, AND Line C. Also, the ModelFilter is configured to be true if ALL of the branches are opened. If all three conditions are defined with DisableIfTrueInRef set to YES and Line A is out in the contingency reference state, the ModelFilter will be evaluated by checking only Line B AND Line C because the Line A condition has been ignored. If all three lines are out in the contingency reference case, the ModelFilter will be treated as if it doesn't exist and the contingency or RAS action using this ModelFilter will NOT be applied.

5.13.2 Calculated Time Delay of a Model Filter

A TimeDelay must be calculated for any ModelFilter that has ModelFilterConditions that use TimeDelays. The calculated time delay of a ModelFilter depends on the logic of the gate (OR, AND, NOR, NAND, XOR, OneTRUE) and the various TimeDelays in the logic diagram. The calculation occurs as follows.

Each input ModelFilterCondition will determine its own calculated time delay based on whether the Criteria object is a ModelFilter or a ModelCondition. We will call that the *InputTimeDelay*.


Criteria Object	<i>InputTimeDelay</i> for the ModelFilterCondition
ModelFilter	Use the summation of the Calculated Time Delay of the ModelFilter and the TimeDelay associated with this ModelFilterCondition
ModelCondition	Directly use TimeDelay associated with this ModelFilterCondition

With these *InputTimeDelays*, the ModelFilter's calculated time delay is then determined based on the Logic of the ModelFilter.


Gate Logic	Calculated Time Delay
AND	The maximum <i>InputTimeDelay</i> associated with any of the TRUE ModelFilterCondition inputs
OR	The minimum <i>InputTimeDelay</i> associated with any of the TRUE ModelFilterCondition inputs
NAND	The minimum <i>InputTimeDelay</i> associated with any of the FALSE ModelFilterCondition inputs
NOR	The maximum <i>InputTimeDelay</i> associated with any of the FALSE ModelFilterCondition inputs
XOR	The minimum <i>InputTimeDelay</i> associated with any of the TRUE ModelFilterCondition inputs.
OneTRUE	The <i>InputTimeDelay</i> associated with the TRUE ModelFilterCondition

Note that the calculated time delay for XOR gates has some ambiguity in what should be returned. We specify that the time delay is that associated with the minimum InputTimeDelay associated with any of the TRUE inputs.

To illustrate the calculation of the time delays, consider the following example logic diagram. The yellow filled boxes represent ModelCondition objects. The orange filled logic gates represent ModelFilter objects. The Blue boxes represent ModelFilterCondition objects. Also note that some of the ModelFilterCondition objects have NOT logic associated with them.




That same logic diagram and color code it with green representing TRUE, red representing FALSE, and grey representing disabled . The calculation of time delay is then shown in the figure with blue text.



5.14 Relationships between objects

The following figure shows the following object types

ModelCondition	For one model object, defines a boolean operation across a list of ModelConditionCondition objects
ModelConditionCondition	One boolean operation on the object contained in the ModelCondition. This may also point to a ModelExpression object
ModelFilter	Defines a boolean operation across a list of ModelFilterCondition objects
ModelFilterCondition	Object is contained in a ModelFilter and references either a ModelFilter or ModelCondition
ModelExpression	An object describing a mathematical expression or lookup table for the system.
ContingencyElement	The ModelCriteria field may reference either a ModelCondition or a ModelFilter The Action field may reference a ModelExpression



5.15 Contingency, ContingencyElement (TSContingency, TSContingencyElement)

Presently there are two separate data structures for storing power flow contingencies as compared to transient stability contingencies.

1. Power Flow Contingency (Contingency/ContingencyElement)
2. Transient Stability Contingency (TSContingency/TSContingencyElement)

While separate data structures within the software environment, they are very similar and will be described together with differences noted. The fields recognized by the Contingency (or TSContingency) object type are shown in the following table.

Field	Description and Rules for Field
Name (key)	Unique Name of the Contingency (or TSContingency)
Category (optional, default blank)	A comma delimited list of strings representing the contingency categories assigned to this contingency. For power flow contingencies, these categories will be used in conjunction with the CustomMonitor object described in Section 8.7. For transient stability contingencies, these categories could be used for additional limit monitoring features.
Skip (optional, default NO)	Set to NO and the contingency will be processed by a contingency analysis tool. Set to YES and a contingency processor will ignore this contingency.
Memo (optional, default blank)	Text field that can be used to provide comments about contingency
DataMaintainerAssign (optional, default blank)	Name of the DataMaintainer for this object. This can be blank as well which indicates no DataMaintainer has been assigned.

Each Contingency object is made up of any number of ContingencyElement objects, while TSContingency objects are made up of TSContingencyElement objects. The fields recognized by the ContingencyElement and TSContingencyElement object types are shown in the following table (Time is only available for the TSContingencyElement):

Field	Description and Rules for Field
Contingency (key)	Name of the contingency (or TSContingency) to which this element belongs
Object (key)	Identifies a power system or simulation element specified using the object string in format specified in Section 2.3. There are minor exceptions to this format described in Section 5.15.1.
Action (key)	A string describing this action. There are many options as shown in the following Section 5.15.4
Criteria (optional, default blank)	Name of either a ModelCondition or a ModelFilter that determines the situation under which the action will actually be implemented. The point at which this model criteria is evaluated will depend on the CriteriaStatus as well as whether this contingency is used for Power Flow Contingencies or Transient Stability Contingencies.

CriteriaStatus (optional, default Check)	Set to either Always, Never, Check, TopologyCheck ,PostCheck, or SolutionFail. Default value used when none specified is Check. Details are explained in Section 5.15.2. <i>For Transient Stability Elements, the choices are either Always, Never, or CHECK</i>
Persistent (optional, default NO)	<i>This field is only defined for the Power Flow Contingency Elements.</i> A YES or NO field. Any action that has Persistent set to YES and also has the CriteriaStatus field set to SOLUTIONFAIL, POSTCHECK or TOPOLOGYCHECK will be applied in the appropriate section of the overall contingency process any time that its Criteria is met. An exception to this is that a SOLUTIONFAIL element will only remain persistent up until a solution is successfully achieved. Once a solution is achieved then the SOLUTIONFAIL elements that had been applied will no longer be evaluated. This is done to ensure the SOLUTIONFAIL loop is not entered repeatedly. Default value used when none specified is NO.
Comment (optional, default blank)	Text field that can be used to provide comments attached to the element Default value used when none specified is empty string.
Time (optional, default 0.0)	Time at which the defined Action takes place specified in a real number in seconds. <i>This field is only defined for the Transient Stability Elements as presently the time has no impact meaning in the Power Flow Contingency.</i>
TimeDelay (optional, default 0.0)	<i>This field is only defined for the Power Flow Contingency Elements.</i> Time delay to wait before the defined Action takes place specified in a real number in seconds (see note below when using a ModelFilter). This is NOT an absolute time at which an action occurs, but serves as a relative ordering for the implementation of actions. Actions with the smallest time delay will be applied first during the TOPOLOGYCHECK and POSTCHECK solution steps. When a ContingencyElement's Criteria refers to a ModelCondition, then this TimeDelay will be used directly. When a ContingencyElement's Criteria refers to a ModelFilter, then the Time Delay used will be the summation of the ContingencyElement's TimeDelay and the Calculated Time Delay of a Model Filter. For more information on how a ModelFilter's Calculated Time Delay is determined see Section 5.13.2. Default value used when none specified is 0.0 (zero).

A sample file section is shown as follows:

```
Contingency (Name, Category, Skip, Memo, DataMaintainerAssign)
{
"L-2_Roughrider-Raven 2&3" "Double" "NO" "My Memo A" "DM1"
"L-2_Roughrider-Raven 1&2" "Double" "NO" "My Memo A" "DM1"
"L_Falcon-PatriotC1" "Single" "NO" "My Memo A" "DM1"
"T_Falcon-TitanC1" "Single" "NO" "My Memo A" "DM1"
}
ContingencyElement (Contingency, Object, Action, Criteria, CriteriaStatus,
TimeDelay, Persistent, Comment)
{
"L-2_Roughrider-Raven 2&3" "BRANCH 15 54 2" "OPEN" "" "CHECK" 0 "NO" ""
"L-2_Roughrider-Raven 2&3" "BRANCH 15 54 3" "OPEN" "" "CHECK" 0 "NO" ""
"L-2_Roughrider-Raven 1&2" "BRANCH 15 54 1" "OPEN" "" "CHECK" 0 "NO" ""
"L-2_Roughrider-Raven 1&2" "BRANCH 15 54 2" "OPEN" "" "CHECK" 0 "NO" ""
"L_Falcon-PatriotC1" "BRANCH 10 13 1" "OPEN" "" "CHECK" 0 "NO" ""
}
```

```

"T_Falcon-TitanC1"          "BRANCH 10 39 1" "OPEN" "" "CHECK" 0 "NO" ""
}TSContingency (Name, Category, Skip, Memo)
{
"Double Outage" "ReallyBad" "NO" "My Memo W"
"Fault Short"   "NotSoBad"  "NO" "My Memo X"
"Fault Long"    "ReallyBad"  "NO" "My Memo Y"
}
TSContingencyElement (Contingency,Time,Object,Action,Criteria,CriteriaStatus,Comment)
{
"Double Outage" 0.50 "Gen 14931 '1'" "OPEN" "" "ALWAYS" ""
"Double Outage" 0.50 "Gen 14932 '1'" "OPEN" "" "ALWAYS" ""
"Fault Short"   0.50 "Bus 'ROSS_345'" "FAULT 3PB SOLID" "" "ALWAYS" ""
"Fault Short"   0.60 "Bus 'ROSS_345'" "CLEARFAULT" "" "ALWAYS" ""
"Fault Long"    0.50 "Bus 'ROSS_345'" "FAULT 3PB SOLID" "" "ALWAYS" ""
"Fault Long"    1.50 "Bus 'ROSS_345'" "CLEARFAULT" "" "ALWAYS" ""
}

```

5.15.1 Special Treatment for ContingencyElement Object Field

For the GEN, LOAD, and SHUNT actions of CHANGEBY, SETTO, and MOVETO, there is one minor feature related to specifying the Object of the contingency element. If the id is omitted from the object string, then the action will apply to all the objects at the bus instead of a specified gen, load or shunt. As an example, "GEN 56 '1'" will apply to a specific generator, while "GEN 56" will apply to all generators at the specific bus instead.

When writing out a BRANCH action for OPEN or CLOSE, if the branch is one of the sections of a multi-section line, instead of writing out the FROM and TO Bus identifiers for the specific section in the key field identifiers, write out the FROM and TO bus identifier for the terminal of the multi-section line. When reading in the file, if the specific BRANCH is not found, then the file parser should search for multi-section lines instead.

5.15.2 Criteria Status

Specifies the point during the solution process at which the Criteria (ModelCondition or ModelFilter) is evaluated. For power flow contingency solutions it has the following interpretation

- Always : Means to ignore the Criteria and always do the action
- Never : Means to ignore the Criteria and never do the action
- Check : Means to evaluate the Criteria in the reference (base) case and implement the action before a power flow solution is attempted
- TopologyCheck : The Criteria will be evaluated after Check and Always actions are applied but BEFORE the power flow solution. The Criteria can evaluate system conditions related to topology changes even before the power flow solution is attempted.
- PostCheck : This Criteria will be evaluated AFTER all Check, Always, and TopologyCheck actions have been performed and AFTER the power flow solution is solved
- SolutionFail : This Criteria will be evaluated only AFTER a power flow solution failure occurs during the contingency process.

For Transient Stability Contingency Elements it has the following interpretation

Always	: Means to ignore the Criteria and always do the action
Never	: Means to ignore the Criteria and never do the action
Check	: Means to evaluate the Criteria in the initial condition and implement the action at the specified time during the simulation if the condition is met. This is intended to evaluate a pre-contingency RAS arming condition to determine whether something should be done.

5.15.3 Calculated Time Delay

When a ContingencyElement refers to a ModelFilter, then the Calculated Time Delay used for the Criteria will be a function of both the TimeDelay of the ContingencyElement and any TimeDelays associated with a ModelFilterCondition. The combination of the logic and time delay must be done appropriately so that the evaluation of a ModelFilter will now have both a TRUE/FALSE flag associated with it and a “calculated time delay”. The calculated time delay of a ModelFilter will depend on the whether it is an OR or an AND gate. For an OR gate, the calculated time delay will be equal to the minimum Time Delay associated with any of the ModelFilter’s TRUE inputs. For an AND gate, the calculated time delay will be equal to the maximum Time Delay associated with any of the ModelFilter’s TRUE inputs. (Note: remember that inputs to a ModelFilter can either be TRUE, FALSE or DISABLED).

5.15.4 Contingency Actions

Each object type has a unique set of actions that are available to be applied to the object. The actions available are listed in following tables. We recognize that there may need to be some additions to this list, but this document provides a list of all actions presently available in PowerWorld Simulator. Also remember that the power flow and transient contingencies are separate data structures. The columns in the table are as follows:

1. First column shows the syntax for this action for transient stability contingencies
2. Second column shows the syntax for this action for power flow contingencies
3. Third column describes what the action means. If an action is not presently applicable, then the first or second column will show “not applicable”.

It should be noted that in many simple cases such as OPEN and CLOSE actions the syntax is the same between the transient stability and power flow contingency elements, but for others they may differ.

Experienced PowerWorld Simulator users may notice that the syntax for the power flow contingencies has been modified and simplified for Simulator Version 18. The old syntax will remain in use and we will maintain forward and backward compatibility. Essentially the new format will form a “secondary key” for the contingency elements. This newer syntax is both simpler for PowerWorld Simulator users and will be easier for other software vendors to parse than our old syntax. The new syntax splits the object and action fields which were previously combined.

5.15.5 Contingency Actions with 'Value' strings

Many of the actions specify a 'value' string. For power flow contingencies only, this value may be expressed in three ways:

1. A numerical value that will be used directly. The single quotes are not necessary in this case.
Example = "SETTO '<Field>MWMax' MW"
2. A string which starts with <Field> and is followed by the name of a field of the object (such as described in Section 2.4) in which case that value will be evaluated and used. By appending the word REF at the end of the action string you may also instruct that the field be evaluated in the contingency reference case. Otherwise the value will be evaluated at the moment the action is implemented.
Example = "SETTO '<Field>MWMax' MW"
3. A string which starts with <Expression> and is followed by the name of a Model Expression. The result of the model expression will then be evaluated and used. By appending the word REF at the end of the action string you may also instruct that the model expression be evaluated in the contingency reference case. Otherwise the value will be evaluated at the moment the action is implemented.
Example = "SETTO '<Expression>Amount To Drop' MW"

Table 1: Branch Actions (Applies to both Transmission Lines and Transformers)

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
FAULT 50.0 3PB SOLID FAULT 50.0 SLG SOLID FAULT 50.0 3PB IMP 0.02 0.06 FAULT 50.0 3PB ADM 0.02 0.06 FAULT 50.0 3PB SOLID SELFCLEAR FAULT 50.0 SLG SOLID SELFCLEAR FAULT 50.0 3PB IMP 0.02 0.06 SELFCLEAR FAULT 50.0 3PB ADM 0.02 0.06 SELFCLEAR SELFCLEAR add May 14, 2018	not applicable	<p>Applies a fault at a specified distance on the branch. Starts with the word FAULT followed by the following parameters</p> <p>Percentage : value representing the location along the branch (For transformer objects this is ignored and values less than 50 are rounded to the NEAR end while values larger than 50 are rounded to the FAR end)</p> <p>Fault Type : String representing the type of fault applied. May be either 3PB, SLG, LL, DLG, Or 1PhaseOpen. If specifying anything other than 3PB (for 3-phase balanced faults), then you must have entered the entire positive and zero sequence information input data for the entire system. Simulator can then calculate the equivalent impedance seen by the positive sequence network caused by this fault. The stability simulation still only model the positive sequence network effects though.</p> <p>Fault Across : Specify whether the fault is across an impedance or admittance. Starts with the string SOLID, IMP, or ADM. For IMP and ADM, this is then followed by two numbers representing either R/X or G/B in per unit.</p> <p>(SELFCLEAR Added in May 14, 2018 patch of Simulator 20) Add the modifier SELFCLEAR at the end of the string to indicate that once the fault location becomes isolated from the system it will automatically clear itself.</p>
CLEARFAULT	not applicable	Removes an applied fault
OPEN BOTH	OPEN	Opens the branch at both ends
OPEN NEAR	not applicable	Opens the presumed breaker at the branch NEAR end
OPEN FAR	not applicable	Opens the presumed breaker at the branch FAR end
CLOSE BOTH	CLOSE	Closes the branch at both ends
CLOSE NEAR	not applicable	Closes the presumed breaker at the branch NEAR end
CLOSE FAR	not applicable	Closes the presumed breaker at the branch FAR end

BYPASS	BYPASS	Bypasses a series reactive element
NOTBYPASS	NOTBYPASS	Inserts a series reactive element
SET R value1 X value2	SETTO 'value1' Xpu SETTO 'value1' X%	Sets the branch impedance for the duration of the contingency.
Not applicable	SETTO 'value' LimitMVA	Sets the contingency rating of the line to the MVA value for the duration of the contingency. Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.
Not applicable	SETTO 'value' % SETTO 'value' MW	Change the MW setpoint of a phase shifting transformer. This only applies to a branch that has been marked as a Transformer and is on Phase control. When changing the MW setpoint, the middle of the MW control range will be changed for the transformer control and the deviation of the RegMax and RegMin to this midpoint will remain the same.
Not applicable	SETTO 'value' DEG	Change the phase angle of a of a phase shifting transformer. This only applies to a branch that has been marked as a Transformer and is on Phase control. When changing the MW setpoint, the middle of the MW control range will be changed for the transformer control and the deviation of the RegMax and RegMin to this midpoint will remain the same.
Not applicable	CHANGEBY 'value' % CHANGEBY 'value' MW	These work the same as the SETTO actions above, except instead of expressing that a value set to a particular amount, the devices are changed by to a particular amount instead.
	CHANGEBY 'value' DEG	These work the same as the SETTO actions above, except instead of expressing that a value set to a particular amount, the devices are changed by to a particular amount instead.

Table 2: Three-Winding Transformer Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
FAULT PRIMARY 3PB SOLID FAULT SECONDARY 3PB IMP 0.02 0.06 FAULT TERTIARY 3PB ADM 0.02 0.06	not applicable	Applies a fault at the respective terminal of the three-winding transformer. Starts with the word FAULT followed by the following parameters followed by the following parameters Fault Type : String representing the type of fault applied. May be 3PB, SLG,

		<p>LL, DLG, or 1PhaseOpen. If specifying anything other than 3PB (for 3-phase balanced faults), then you must have entered the entire positive and zero sequence information input data for the entire system. Simulator can then calculate the equivalent impedance seen by the positive sequence network caused by this fault. The stability simulation still only model the positive sequence network effects though.</p> <p>Fault Across : Specify whether the fault is across an impedance or admittance. Starts with the string SOLID, IMP, or ADM. (IMP = Impedance and ADM = Admittance). For IMP and ADM, this is then followed by two numbers representing either R/X or G/B in per unit.</p>
CLEARFAULT	not applicable	Removes an applied fault
OPEN	OPEN	Opens the three-winding transformer at all terminals
OPEN PRIMARY	not applicable	Opens the presumed breaker at the branch primary bus
OPEN SECONDARY	not applicable	Opens the presumed breaker at the branch secondary end
OPEN TERTIARY	not applicable	Opens the presumed breaker at the branch tertiary end
CLOSE	CLOSE	Closes the three-winding transformer at all terminals
CLOSE PRIMARY	not applicable	Closes the presumed breaker at the branch primary bus
CLOSE SECONDARY	not applicable	Closes the presumed breaker at the branch secondary end
CLOSE TERTIARY	not applicable	Closes the presumed breaker at the branch tertiary end

Table 3: Load Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
OPEN	OPEN	Opens the Load
CLOSE	CLOSE	Closes in the load. Note: In a transient stability simulation this is only allowed for some types of load models. Certain dynamic motor models are designed for modeling load starting, while others do not permit this.
CHANGEBY 100 MW CHANGEBY -30 %	CHANGEBY 'value' MWPF CHANGEBY 'value' % CHANGEBY 'value' MW CHANGEBY 'value' MVAR The following sets the MVAR equal to	Changes load level by a defined amount. For Transient Stability Analysis, the value must be specified in either MW : Value specified is then used to calculate a percentage change in the load based on what the load was in the initial condition and this percentage multiplier is applied to the load.

	<p>the present MW</p> <p>CHANGEBY 'MW' MVAR</p> <p>The following sets the MW equal to the Model Expression <i>My Expression</i> evaluated in the reference case</p> <p>CHANGEBY 'My Expression' MW REF</p>	<p>% : Value specified is a percentage of the contingency reference state load.</p> <p>For Power Flow Contingency Analysis,</p> <p>MWPF : Change the load assuming it varies with constant power factor. Value is interpreted as the change in MW with the Mvars moved to keep constant power factor.</p> <p>% : Will change both the MW and MVar of the load by a percentage applied to the contingency reference state load.</p> <p>MW : Will change only the load MW of the load and the value will be interpreted as MWs</p> <p>MVAR : Will change only the MVar of the load and the value will be interpreted as Mvars</p> <p>Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.</p>
Not applicable	<p>SETTO 'value' MWPF</p> <p>SETTO 'value' %</p> <p>SETTO 'value' MW</p> <p>SETTO 'value' MVAR</p>	<p>These work the same as the CHANGEBY actions above, except instead of expressing that a value change by a particular amount, the devices are set to a particular amount instead.</p>
Not applicable	<p>MOVETO 'busid' 'value' MWPF</p> <p>MOVETO 'busid' 'value' %</p> <p>MOVETO 'busid' 'value' MW</p> <p>MOVETO 'busid' 'value' MVAR</p>	<p>These work the same as the CHANGEBY actions above, except that the amount of change for the net MW and Mvar change at the particular devices are then added to the bus described by 'busid'. The 'busid' string follows the convention for buses described in Section 2.3.</p>

Table 4: Generator Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
OPEN	OPEN	Opens the generator
CLOSE	CLOSE	Closes in the generator. Note: In a transient stability simulation this is only allowed for some types of generator models. Certain dynamic motor models that are modeled as a generator (MOTOR1) are designed for modeling load starting, while others do not permit this.
Not applicable	<p>CHANGEBY 'value' %</p> <p>CHANGEBY 'value' MW</p> <p>CHANGEBY 'value' MVAR</p> <p>CHANGEBY 'value' Vpu</p>	<p>Changes generation level by a defined amount.</p> <p>For Transient Stability Analysis, this is not available.</p> <p>For Power Flow Contingency Analysis,</p>

	<p>The following sets the MVAR equal to the present MW CHANGEBY 'MW' MVAR</p> <p>The following sets the MW equal to the Model Expression <i>My Expression</i> evaluated in the reference case CHANGEBY 'My Expression' MW REF</p>	<p>⊘ : Will change the MW only of the generator by a percentage of the contingency reference state MW.</p> <p>MW : Will change only the MW of the generator and the value will be interpreted as MWs</p> <p>MVAR : will change only the MVar of the generator and the value will be interpreted as Mvars</p> <p>V_{pu} : will change the generator setpoint voltage and the value will be interpreted as per unit voltage</p> <p>Note that the 'value' string may be expressed in three ways. This functions the as described at the beginning of this section.</p>
Not applicable	SETTO 'value' ⊘ SETTO 'value' MW SETTO 'value' MVAR SETTO 'value' V _{pu}	These work the same as the CHANGEBY actions above, except instead of expressing that a value change by a particular amount, the devices are set to a particular amount instead.
Not applicable	MOVETO 'busid' 'value' ⊘ MOVETO 'busid' 'value' MW	These work the same as the CHANGEBY actions above, except that they only function on the MW values. The amount of change for the net MW change at the particular devices are then added to the bus described by 'busid'. The 'busid' string follows the convention for buses described in Section 2.3.
SET Exciter_Setpoint 1.05 pu SET Governor_Setpoint 1.05 ⊘ SET Power 50 MW SET Power 50 ⊘	Not applicable	Sets the Exciter_Setpoint (Vref), Governor_Setpoint (Pref), or POWER output of the particular generator to a particular value. For Exciter_Setpoint and Governor_Setpoint, values may be expressed either as per unit (pu) or as a percentage of the initial value (⊘). For POWER Values may be expressed either in MW or percentage of initial value (⊘). Also note that setting the MW output of a generator is only possible if the generator does not have a transient stability model associated with it, otherwise the action is ignored. This is because you cannot set the value of

		a dynamic variable directly. Basically to change the MW output of the generator you must change the governor setpoint.
RAMP Exciter_Setpoint 1.05 pu 5.0 RAMP Governor_Setpoint 1.05 % 5.0 RAMP Power 50 MW 5.0 RAMP Power 50 % 5.0	Not applicable	Works the same as the SET actions, except that it starts with the word RAMP and has one additional numerical parameter that specifies a number of seconds. The value in question for the action is that linearly ramped from its present value to the new value over that number of seconds.

Table 5: Bus Shunt and SVD Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
OPEN	OPEN	Opens the shunt
CLOSE	CLOSE	Closes in the shunt
Not applicable	CHANGEBY 'value' % CHANGEBY 'value' MW CHANGEBY 'value' MVAR CHANGEBY 'value' Vpu The following sets the MVAR equal to the present MW CHANGEBY 'MW' MVAR The following sets the MW equal to the Model Expression <i>My Expression</i> evaluated in the reference case CHANGEBY 'My Expression' MW REF	Changes shunt level by a defined amount. For Transient Stability Analysis, this is not available. For Power Flow Contingency Analysis, % : Will change the MVAR of the shunt by a percentage of the contingency reference state MVAR MW : Will change the MW of the shunt and the value will be interpreted as MWs MVAR : Will change the Mvars of the shunt and the value will be interpreted as Mvars Vpu : Will change the shunt setpoint voltage and the value will be interpreted as per unit voltage Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.
Not applicable	SETTO 'value' % SETTO 'value' MW SETTO 'value' MVAR SETTO 'value' Vpu	These work the same as the CHANGEBY actions above, except instead of expressing that a value change by a particular amount, the devices are set to a particular amount instead.
Not applicable	MOVETO 'busid' 'value' % MOVETO 'busid' 'value' MW MOVETO 'busid' 'value' MVAR Note: Vpu actions aren't available	These work the same as the CHANGEBY actions above, except that they only function on the MW values. The amount of change for the net MW change at the particular devices are then added to the bus described by

		'busid'. The 'busid' string follows the convention for buses described in Section 2.3.
--	--	--

Table 6: Line Shunt Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
Not applicable	OPEN	Opens the line shunt
Not applicable	CLOSE	Closes in the line shunt

Table 7: Bus Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
FAULT 3PB SOLID FAULT SLG SOLID FAULT 3PB IMP 0.02 0.06 FAULT 3PB ADM 0.02 0.06	not applicable	<p>Applies a fault at the bus. Starts with the word FAULT followed by the following parameters followed by the following parameters</p> <p>Fault Type : String representing the type of fault applied. May be either 3PB, SLG, LL, DLG, or 1PhaseOpen. If specifying anything other than 3PB (for 3-phase balanced faults), then you must have entered the entire positive and zero sequence information input data for the entire system. Simulator can then calculate the equivalent impedance seen by the positive sequence network caused by this fault. The stability simulation still only model the positive sequence network effects though.</p> <p>Fault Across : Specify whether there fault is across an impedance or admittance. Starts with the string SOLID, IMP, or ADM. For IMP and ADM, this is then followed by two numbers representing either R/X or G/B in per unit.</p>
CLEARFAULT	not applicable	Removes an applied fault
OPEN	OPEN	Opens the bus

Table 8: Interface Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
Not applicable	OPEN	Opens all AC lines, generators, and loads contained inside the interface including generators and loads inside any injection

		groups or other interfaces.
Not applicable	CLOSE	Closes all AC lines inside the interface
Not applicable	<p>CHANGEBY 'value' %MERITORDEROPEN CHANGEBY 'value' MWMERITORDEROPEN CHANGEBY 'value' %MERITORDEROPENEXCEED CHANGEBY 'value' MWMERITORDEROPENEXCEED</p> <p><i>The following options Added in Simulator Version 20</i></p> <p>CHANGEBY 'value' MWEFFECTOPEN CHANGEBY 'value' MWEFFECTOPENEXCEED CHANGEBY 'value' MWBESTFITOPEN CHANGEBY 'value' MWBESTFITOPENEXCEED CHANGEBY 'value' %BESTFITOPEN CHANGEBY 'value' %BESTFITOPENEXCEED</p> <p>The following sets the MW equal to the Model Expression <i>My Expression</i> evaluated in the reference case: CHANGEBY 'My Expression' MWMERITORDEROPEN REF</p> <p>The following sets the MW equal to the Model Expression <i>My Expression</i> evaluated in the reference case and the participation factors are evaluated in the reference case: CHANGEBY 'My Expression' MWMERITORDEROPEN REF PPREF</p>	<p>Changes interface flow by a defined amount by opening elements in the interface. For Transient Stability Analysis, this is not available. For Power Flow Contingency Analysis, the following options are available:</p> <p>See comments in Section 5.15.7 for the following choices.</p> <p>%MERITORDEROPEN : Will change the MW flow of the interface by a percentage of the contingency reference state flow. Change will be achieved by opening elements in the interface in merit order.</p> <p>MWMERITORDEROPEN : Will change the flow of the interface and the value will be interpreted as MWs. Change will be achieved by opening elements in the interface in merit order.</p> <p>%MERITORDEROPENEXCEED : Will change the flow of the interface by a percentage of the contingency reference state flow. Change will be achieved by opening elements in the interface in merit order. The change in flow is allowed to exceed the desired amount.</p> <p>MWMERITORDEROPENEXCEED : Will change the flow of the interface and the value will be interpreted as MWs. Change will be achieved by opening elements in</p>

		<p>the interface in merit order. The change in MW is allowed to exceed the desired amount.</p> <p>MWEFFECTOPEN : Value that is specified with the action is the desired <i>MW Effect</i> that the action should have. The participation factors defined with the InterfaceElements will be interpreted as effectiveness factors akin to transfer distribution factors. These factors are supplied as input by the user when defining the interface. The effectiveness factors are multiplied by present MW flow of elements in the interface to determine how much effect they will have if dropped. The flow of an element is determined by its MW flow multiplied by the weighting factor specified with the element. If the effect of a particular element is in the opposite direction of the desired effect, that element is skipped. The action will find the smallest number of elements to drop that results in a total <i>MW Effect</i> that is within 5% of the desired <i>MW Effect</i>, but does not exceed the desired <i>MW Effect</i>.</p> <p>MWEFFECTOPENEXCEED : Same as MWEFFECTOPEN, but it will ensure that the total <i>MW Effect</i> is within 5% of the desired <i>MW Effect</i> and also meets or exceeds the desired <i>MW Effect</i>.</p>
--	--	--

		<p>MWBESTFITOPEN : Value will be interpreted as the amount of MW flow change. When using this option the participation factors of the interface elements do not impact which elements are opened. The flow on an element, which is determined by its MW flow multiplied by the weighting factor specified with the element, is used to determine which elements should be opened. If the flow on an element is in the appropriate direction to achieve the desired flow change on the interface, that element is eligible for being opened. To determine if an element will actually be opened, the best fit algorithm attempts to determine the combination of elements that will achieve the desired flow change by opening the least amount of elements and achieving an actual flow change within 5% of the desired flow change without exceeding the desired amount.</p> <p>MWBESTFITOPENEXCEED : Same as MWBESTFITOPEN except that the MW flow change is allowed to exceed the desired amount of change.</p> <p>%BESTFITOPEN : Same as MWBESTFITOPEN except that the value is interpreted as percentage of the contingency</p>
--	--	--

		<p>reference state MW flow.</p> <p><code>%BESTFITOPENEXCEED</code></p> <p>: Same as <code>%BESTFITOPEN</code> except that the flow change is allowed to exceed the desired amount of change.</p> <p>Note that the '<i>value</i>' string may be expressed in three ways. This functions as described at the beginning of this section.</p> <p>See comment below about evaluating participation factors in the reference case. Also see comment regarding <code>INTERFACEELEMENT</code> objects that refer to another interface.</p>
Not applicable	<pre>SETTO 'value' %MERITORDEROPEN SETTO 'value' MWMERITORDEROPENEXCEED SETTO 'value' %MERITORDEROPENEXCEED</pre> <p><i>The following options Added in Simulator Version 20</i></p> <pre>SETTO 'value' MWBESTFITOPEN SETTO 'value' MWBESTFITOPENEXCEED SETTO 'value' %BESTFITOPEN SETTO 'value' %BESTFITOPENEXCEED</pre>	<p>These work the same as the <code>CHANGEBY</code> actions above, except instead of expressing that the interface flow change by a particular amount, the interface flow is set to a particular amount instead by opening elements in the interface.</p> <p>Note: <code>MWEFFECT</code> and <code>MWEFFECTEXCEED</code> are not valid for the <code>SETTO</code> actions.</p>
<p>When using an action that requires participation factors, an optional parameter <code>PPREF</code> can be specified. This indicates that the participation factors should be determined in the contingency reference case.</p> <p>Interfaces can contain other interfaces. The treatment of interfaces within interfaces is to open the entire contained interface when using <code>MERITORDEROPEN</code>, <code>MWEFFECT</code>, and <code>BESTFIT</code> type actions.</p>		

Table 9: Injection Group Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
<pre>OPEN 200 MW GEN OPEN 500 MW LOAD OPEN 100 MVAR LOAD OPEN 400 MVAR SHUNT</pre>	Not Applicable	<p>Opens generators, loads or shunts up until the total MW or Mvar removed would exceeds the value specified. The MW or Mvar values are based on the initial conditions. The order precedence of which devices are opened is determined by the participation</p>

		factor of the participation point. Higher participation factors are processed first.
Not applicable	<p>OPEN OPEN 'value'</p> <p>The following will evaluate the participation factors in the reference case: OPEN 'value' PPREF</p> <p>The following will evaluate the participation factors in the reference case and the 'value' in the reference case: OPEN 'value' REF PPREF</p>	<p>Opens all devices in the injection group if no value is specified. If a value is specified, only that number of devices is opened in the injection group in the order of highest to lowest participation factor.</p> <p>Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.</p> <p>See comment below about evaluating participation factors in the reference case.</p>
Not applicable	<p>CLOSE</p> <p><i>The following options Added in Simulator Version 20</i> CLOSE 'value'</p> <p>The following will evaluate the participation factors in the reference case: CLOSE 'value' PPREF</p> <p>The following will evaluate the participation factors in the reference case and the 'value' in the reference case: CLOSE 'value' REF PPREF</p>	<p>Closes all devices in the injection group if no value is specified. If a value is specified, only that number of devices is closed in the order of highest to lowest participation factor.</p> <p>Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.</p> <p>See comment below about evaluating participation factors in the reference case.</p>
Not applicable	<p>CHANGEBY 'value' % CHANGEBY 'value' MW CHANGEBY 'value' %MERITORDER CHANGEBY 'value' MWMERITORDER CHANGEBY 'value' %MERITORDEROPEN CHANGEBY 'value' MWMERITORDEROPEN CHANGEBY 'value' %MERITORDEROPENEXCEED CHANGEBY 'value' MWMERITORDEROPENEXCEED CHANGEBY 'value' MWEFFECTOPEN CHANGEBY 'value' MWEFFECTOPENEXCEED</p> <p><i>The following options Added in Simulator Version 20</i> CHANGEBY 'value' MWBESTFITOPEN CHANGEBY 'value' MWBESTFITOPENEXCEED</p>	<p>Changes MW injection by a defined amount. For Transient Stability Analysis, this is not available. For Power Flow Contingency Analysis the following options are available:</p> <p>For the following two options, the change in the injections will be done proportional to the participation factors of the participation points.</p> <p>% : Will change the MW injection of the group by a percentage of the</p>

	<p>CHANGEBY 'value' %BESTFITOPEN CHANGEBY 'value' %BESTFITOPENEXCEED</p> <p>The following sets the MW equal to the present MVAR: CHANGEBY 'MVAR' MW</p> <p>The following sets the MW equal to the Model Expression <i>My Expression</i> evaluated in the reference case: CHANGEBY 'My Expression' MW REF</p> <p>The following sets the MW equal to the Model Expression <i>My Expression</i> evaluated in the reference case and the participation factors are evaluated in the reference case: CHANGEBY 'My Expression' MW REF PPREF</p>	<p>MW : contingency reference state injection. : Will change the MW injection of the group and the value will be interpreted as MWs</p> <p>See comments in Section 5.15.6 for the following choices.</p> <p>%MERITORDER : Will change the MW injection of the group by a percentage of the contingency reference state injection. Change will be achieved by processing generators and loads in merit order.</p> <p>MWMERITORDER : Will change the MW injection of the group and the value will be interpreted as MW. Change will be achieved by processing generators and loads in merit order.</p> <p>%MERITORDEROPEN : Will change the MW injection of the group by a percentage of the contingency reference state injection. Change will be achieved by opening generators or loads in merit order.</p> <p>MWMERITORDEROPEN : Will change the MW injection of the group and the value will be interpreted as MWs. Change will be achieved by opening generators or loads in merit order.</p> <p>%MERITORDEROPENEXCEED : Will change the MW injection of the group by a percentage of the contingency reference state injection. Change will be achieved by opening generators or loads in merit order. The change in MW is allowed to exceed the desired amount.</p> <p>MWMERITORDEROPENEXCEED : Will change the MW injection of the</p>
--	---	---

		<p>group and the value will be interpreted as MWs. Change will be achieved by opening generators or loads in merit order. The change in MW is allowed to exceed the desired amount.</p> <p>MWEFFECTOPEN : Value that is specified with the action will be the desired <i>MW Effect</i> that the action should have. The participation factors defined with the Injection Group will be interpreted as effectiveness factors akin to transfer distribution factors. These factors are supplied as input by the user when defining the injection group. The effectiveness factors are multiplied by the present output of generators (or loads) in the injection group to determine how much effect they will have if dropped. The action will find the smallest number of generator (or loads) to drop which results in a total <i>MW Effect</i> that is within 5% of the desired <i>MW Effect</i>, but does not exceed the desired <i>MW Effect</i>.</p> <p>MWEFFECTOPENEXCEED : Same as MWEFFECTOPEN, but it will ensure that the total <i>MW Effect</i> is within 5% of the desired <i>MW Effect</i> and also meets or exceeds the desired <i>MW Effect</i>.</p> <p>MWBESTFITOPEN : Value is interpreted as the amount of MW injection change. When using this option the participation factors do not impact which elements are opened. All generators or loads defined within the</p>
--	--	---

		<p>injection group can participate if they are online. Specifically which generators or loads depends on an algorithm that attempts to get the actual injection change within 5% of the desired injection change by opening the smallest number of generators or loads without exceeding the desired amount.</p> <p><code>MWBESTFITOPENEXCEED</code> : Same as <code>MWBESTFITOPEN</code> except that the MW injection change is allowed to exceed the desired amount of change.</p> <p><code>%BESTFITOPEN</code> : Same as <code>MWBESTFITOPEN</code> except that the value is interpreted as percentage of the contingency reference state MW injection.</p> <p><code>%BESTFITOPENEXCEED</code> : Same as <code>%BESTFITOPEN</code> except that the MW injection change is allowed to exceed the desired amount of change.</p> <p>Note that the '<i>value</i>' string may be expressed in three ways. This functions as described at the beginning of this section.</p> <p>See comment below about evaluating participation factors in the reference case. Also see comment regarding <code>PARTPOINT</code> objects which refer to another injection group.</p>
	<pre> SETTO 'value' % SETTO 'value' MW SETTO 'value' %MERITORDER SETTO 'value' MWMERITORDER SETTO 'value' %MERITORDEROPEN SETTO 'value' MWMERITORDEROPEN SETTO 'value' %MERITORDEROPENEXCEED SETTO 'value' MWMERITORDEROPENEXCEED </pre> <p><i>The following options Added in Simulator Version 20</i></p>	<p>These work the same as the <code>CHANGEBY</code> actions above, except instead of expressing that a value change by a particular amount, the devices are set to a particular amount instead.</p> <p>Note: <code>MWEFFECT</code> and <code>MWEFFECTEXCEED</code> are not valid for the <code>SETTO</code> actions.</p>

	<pre> SETTO 'value' MWBESTFITOPEN SETTO 'value' MWBESTFITOPENEXCEED SETTO 'value' %BESTFITOPEN SETTO 'value' %BESTFITOPENEXCEED </pre>	
<p>When an action uses participation factors to determine a change, the AutoCalcMethod for the participation factor may allow the value of the participation factor to be dynamically determined. If using an appropriate AutoCalcMethod and AutoCalc is set to YES, an additional option is available to allow participation factors to be evaluated in the reference case. This is indicated by appending PPREF after the value. See Section 5.10 for more information on the AutoCalcMethod.</p> <p>Injection Group can contain PartPoints which reference another Injection Group. The treatment of Injection Groups defined within Injection Groups will be interpreted to drop the entire contained Injection Group when using the MERITORDEROPEN, MWEFFECT, and BESTFIT type actions.</p>		

Table 10: DC Converter Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
Not Applicable	OPEN	Opens the multi-terminal DC Converter
Not Applicable	<pre> CLOSE 'value' MW CLOSE 'value' Amps </pre>	<p>Closes in the multi-terminal DC Converter. Must also specify the MW or Amps setting of the converter as well.</p> <p>Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.</p>
Not Applicable	<pre> CHANGEBY 'value' % CHANGEBY 'value' MW CHANGEBY 'value' Amps </pre>	<p>Changes the multi-terminal DC Converter set-point by an incremental amount of MW or Amp. May also specify the change as a percentage of the contingency reference state set-point. Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.</p>
Not Applicable	<pre> SETTO 'value' % SETTO 'value' MW SETTO 'value' Amps </pre>	<p>These work the same as the CHANGEBY actions above, except instead of expressing that a value change by a particular amount, the setpoint is set to a particular amount instead.</p>
Not Applicable	Not Applicable	Ramping values not added presently.

Table 11: DC Line Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
----------------------------	-------------------	-----------------------------------

OPEN	OPEN	Opens the two-terminal DC Line
Not Applicable	CLOSE 'value' MW CLOSE 'value' Amps	Closes in the two-terminal DC Line. Must also specify the MW or Amps setting of the converter as well. Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.
Not Applicable	CHANGEBY 'value' % CHANGEBY 'value' MW CHANGEBY 'value' Amps	Changes the two-terminal DC Line set-point by an incremental amount of MW or Amp. May also specify the change as a percentage of the present set-point. Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.
Not Applicable	SETTO 'value' % SETTO 'value' MW SETTO 'value' Amps SETTO 'value' OHMS	These work the same as the CHANGEBY actions above, except instead of expressing that a value change by a particular amount, the setpoint is set to a particular amount instead. SETTO actions also allow the resistance of the DC Line to be set by using the OHMS setting. There is no CHANGEBY action that will adjust the resistance.
Not Applicable	Not Applicable	Ramping values not added presently.

Table 12: Substation Actions

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
Not Applicable	OPEN	Opens the substation
Not Applicable	<i>Added in Simulator Version 20</i> CHANGEBY 'value' % CHANGEBY 'value' MW The following will evaluate the 'value' in the reference case: CHANGEBY 'value' % REF CHANGEBY 'value' MW REF	Changes the MW output of online generators in the substation to the specified value.
Not Applicable	<i>Added in Simulator Version 20</i> SETTO 'value' % SETTO 'value' MW The following will evaluate the 'value' in the reference case: SETTO 'value' % REF SETTO 'value' MW REF	These work the same as the CHANGEBY actions above except that the output of online generators in the substation are set to the specified value instead.

Table 13: VSC DC Line Actions

All VSC DC Line actions were added in the January 11, 2018 patch of Simulator Version 20.

Transient Stability Syntax	Power Flow Syntax	Description and Required Elements
OPEN	OPEN	Opens the VSC DC Line
Not Applicable	CLOSE 'value' MW	Closes in the VSC DC Line. Must also specify the MW setting of the converter as well. Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.
Not Applicable	CHANGEBY 'value' % CHANGEBY 'value' MW	Changes the VSC DC Line set-point by an incremental amount of MW. May also specify the change as a percentage of the present set-point. Note that the 'value' string may be expressed in three ways. This functions as described at the beginning of this section.
Not Applicable	SETTO 'value' % SETTO 'value' MW SETTO 'value' OHMS	These work the same as the CHANGEBY actions above, except instead of expressing that a value change by a particular amount, the setpoint is set to a particular amount instead. SETTO actions also allow the resistance of the DC Line to be set by using the OHMS setting. There is no CHANGEBY action that will adjust the resistance.
Not Applicable	Not Applicable	Ramping values not added presently.

5.15.6 Special InjectionGroup Contingency Action for Generators by Merit Order

Normally all generators and loads in the injection group are adjusted according to their relative participation factors. All with non-zero participation factors will be adjusted to meet the desired injection. When using the option `MWMERITORDER` or `%MERITORDER`, generators and loads will be adjusted in order of highest relative participation factor to lowest with each element in the list being adjusted until it hits either its maximum or minimum MW limit before moving on to the next element. This process continues until the desired injection is met. Generator status will not be changed in the process, which means all online generators will continue to provide Mvar support. Loads that have both their minimum and maximum MW limits set to zero will not be allowed to increase. They can only decrease to 0 MW.

There are also options `MWMERITORDEROPEN` and `%MERITORDEROPEN`. When using these, if the MW output requested is lower than the existing MW injection of the injection group, then the merit order dispatch will be modified by only opening generators. (Note: the expectation is that the `ChangeBy` option would most frequently be used with this option with a negative value.) If requested injection is lower, the generator in the injection group with the highest participation factor will have its status changed to Open, followed by the second generator and so on. This will continue until the amount of MW opened is as close to the desired amount as possible but has not exceeded the desired amount of change. If opening a generator will cause the amount of MW opened to exceed the desired amount, that generator will be skipped and the next one in merit order will be examined. If the MW injection requested is higher than the present MW injection, loads will be opened in the same manner. If the MW injection requested is higher than the present MW injection and there are no loads in the injection group, generators will be increased toward their maximum MW output in the same manner as done for `MWMERITORDER` or `%MERITORDER`. If the MW injection requested is lower than the present MW injection and there are no generators in the injection group, loads will be increased toward their maximum MW output in the same manner as done for `MWMERITORDER` or `%MERITORDER`.

The options `MWMERITORDEROPENEXCEED` and `%MERITORDEROPENEXCEED` are very similar to the `MWMERITORDEROPEN` and `%MERITORDEROPEN` options except that the amount of MW opened is allowed to exceed the desired amount of change. Generators or loads will be opened in merit order until the desired amount is met or exceeded.

5.15.7 Special Interface Contingency Action for Merit Order Open

The merit order open actions for interfaces indicated by the `MWMERITORDEROPEN` and `%MERITORDEROPEN` options will allow a change in flow on the interface by opening elements within the interface. Participation factors must be specified with each interface element to set the merit order in which they should be opened. Each element is opened in the order of highest to lowest participation factor until the desired flow is met. If opening an element will cause a change in flow that is not in the desired direction, that element is not opened and the next element in merit order is examined. The flow of an element is determined by its MW flow multiplied by the Weight factor specified with the element. This will continue until the amount of MW opened is as close to the desired amount as possible but has not exceeded the desired amount of change.

The options MWMERITORDEROPENEXCEED and %MERITORDEROPENEXCEED are very similar to the MWMERITORDEROPEN and %MERITORDEROPEN options except that the amount of MW opened is allowed to exceed the desired amount of change. Elements will be opened in merit order until the desired amount is met or exceeded.

5.16 RemedialAction and RemedialActionElement

RemedialActions are intended to be named containers of actions representing RAS. The elements of each remedial action are inherently applied to every contingency. The fields recognized by the RemedialAction object type are the same as for the Contingency object type. The exception is that no Category is assigned to the RemedialActionScheme.

The fields recognized by the RemedialActionElement object type are the same as for the ContingencyElement object type except for the additional fields that are described as follows.

Field	Description and Rules for Field
InclusionFilter (optional, default blank)	Name of a filter or device filter (See Section 3 or 3.3) that gets applied to each contingency. If the contingency meets the Inclusion filter defined, that contingency will include this element. Otherwise, the remedial action element will be ignored. A description of the format of this string is in Section 3.4.
CriteriaCheckOnce (optional, default NO) <i>Added in August 11, 2022 patch of Simulator Version 22</i>	Set this to YES if the Criteria should only be checked once during the process of applying a RemedialActionElement in response to Contingency actions. This means that the Criteria will only be evaluated once for elements with TopologyCheck, PostCheck, or SolutionFail CriteriaStatus. If the Criteria is not met, this action will not be implemented and the Criteria will not be evaluated again. The Persistent field is ignored when this is set to YES. The action will not be implemented and the Criteria will not be evaluated again for a Criteria that is met but the TimeDelay is greater than the TimeDelays of other actions whose Criteria is also met. This field has no impact if Criteria is not defined. This field is intended to model an action that should only be implemented due to Contingency actions and not respond due to RemedialActions.

The RemedialAction and RemedialActionElement object types both have fields in addition to the fields that they inherit from the Contingency object type and the ContingencyElement object type respectively. These fields allow arming conditions to be specified in addition to conditions under which actions are actually implemented. For an action that is part of a RemedialActionElement to be implemented, its arming condition must be met and the arming condition of the RemedialAction to which it belongs must also be met. This functionality was *Added in Simulator Version 20*.

Field	Description and Rules for Field
ArmingCriteria (optional, default blank)	If specified, this is the name of either a ModelCondition or a ModelFilter that determines the situation under which the action will be armed. If not specified, the action is considered to be armed. The specified condition is evaluated in the contingency reference case. For a RemedialActionElement to be armed, its RemedialAction must also be armed.
ArmingStatus (optional, default Check)	Set to either <i>Always</i> , <i>Never</i> , or <i>Check</i> . Default value used when none specified is <i>Check</i> . <i>Always</i> – action is considered armed regardless of the ArmingCriteria <i>Never</i> – action is not armed <i>Check</i> – action is armed if ArmingCriteria is true or not specified

A sample file section is shown as follows:

```
RemedialAction(Name, Skip, Memo)
{
"Cowboy RAS" "NO" ""
"Viking RAS" "NO" ""
"Dolphin-Raider RAS" "NO" ""
"Viking-Dolphin 1 Overload" "NO" ""
"Viking-Dolphin 2 Overload" "NO" ""
}
RemedialActionElement (RemedialAction, Object, Action, Criteria,
CriteriaStatus, TimeDelay, InclusionFilter, Comment)
{
"Cowboy RAS" "GEN 31 1" "OPEN" "OPEN Cowboy G1" "TOPOLOGYCHECK" 0 "" ""
"Viking RAS" "INJECTIONGROUP 'Viking G1 and G2'" "OPEN" "OPEN Viking G1 and G2"
"TOPOLOGYCHECK" 0 "" ""
"Dolphin-Raider RAS" "GEN 28 1" "OPEN" "Dolphin-Raider 1 138 kV Line"
"TOPOLOGYCHECK" 0 "" ""
"Viking-Dolphin 1 Overload" "BRANCH 28 29 1" "OPEN" "Viking-Dolphin 1 345/138 Over 135%"
"POSTCHECK" 0 "" ""
"Viking-Dolphin 2 Overload" "BRANCH 28 29 2" "OPEN" "Viking-Dolphin 2 345/138 Over 135%"
"POSTCHECK" 0 "" ""
}
```

5.17 ModelResultOverride

ModelResultOverrides allow the direct specification of the result of a ModelCondition, ModelFilter, or ModelExpression. When a ModelResultOverride is active, the logic for the object it is overriding is ignored. The logic of the overridden object can remain defined and used when necessary, but a direct replacement of the result is very simple without having to redefine contingency action and remedial action model criteria. This object was *Added in Simulator Version 20*.

Field	Description and Rules for Field
Name (key)	Name of the ModelResultOverride. There can only be one ModelResultOverride with this name.
Object (optional, default blank)	Object identifier of the ModelCondition, ModelFilter, or ModelExpression that is being overridden.

ResultValue (optional, default 0.0)	If the Object is a ModelExpression, this is the numeric value that is used as the result of the expression. This field is not specified if the Object is a ModelCondition or ModelFilter.
ResultBoolean (optional, default NO)	If the Object is a ModelCondition or ModelFilter, this is the boolean result that is used for the object that is being overridden. This field is not specified if the Object is a ModelExpression.
Enabled (optional, default YES)	Set this field to YES to apply the override and use the result specified for the specified Object and ignore the logic defined with the Object itself.

A sample file section is shown as follows:

```
ModelResultOverride (Name, Object, ResultValue, ResultBoolean, Enabled)
{
"Override BigGen Drop Lookup" "ModelExpression 'BigGen Drop Lookup'" -1500.00 "" "YES"
"Override Path 1 Unit 1" "ModelFilter 'Path 1 Unit 1'" "" "YES" "YES"
}
```

6 Steady State Contingency Analysis with RAS and Stability Models

A contingency processor will go through each contingency record marked as SKIP = NO. It will gather all the specified actions as well as every action contained in any Remedial Action Scheme record (again marked as SKIP = NO). This will then form a list of actions that will be processed.

The use of transient stability models inside of the power flow contingency analysis should also be handled. Transient stability actions are evaluated at specific points in the process and will be applied based on their time parameters. At the point in the process that dynamic models are processed by the steady state contingency analysis, the stability models defined in the power system model will be queried and any stability models types that are set to Trip/Act (see Section 5.8) and whose conditions for action are met will be added to a list. For each model in this list a time delay is calculated based on the transient stability model parameters and the power flow system state at that point in the process (this might be a definite time delay parameter or a time-inverse characteristic). This list is then sorted and only those actions, including both power flow and transient, that have the smallest time delay will be taken (all times are rounded to the nearest integer microsecond). The contingency processor will then solve the power flow and go back through the entire process of other contingency actions again.

The overall process goes as follows. When we refer to “actions” in this flow process we mean both contingency actions and remedial action scheme actions collectively. When we refer to “Transient actions” we mean actions caused by a transient stability dynamic model.

1. Apply ALWAYS actions and true CHECK actions
2. Update system topology (branch and bus Status and Derived Status)
3. Apply true TOPOLOGYCHECK actions
 - a. TRANSIENT actions will also be evaluated
 - b. TRANSIENT or TOPOLOGYCHECK actions with the smallest TimeDelay will be applied
4. Store reference state for use if solution failure occurs and SOLUTIONFAIL actions exist
5. Solve power flow

- a. If the power flow solution fails and `SOLUTIONFAIL` actions are available then the reference state in step 4 is restored and then any true `SOLUTIONFAIL` actions with the smallest `TimeDelay` will be applied.
- b. If any `SOLUTIONFAIL` actions are applied then process will go back step 4 and repeat. (Note: this loop will abort after 100 solution failures)
- c. If there is still a solution failure then abort the contingency process and report failure.
6. Apply true `POSTCHECK` actions and true `TOPOLOGYCHECK` actions
 - a. `TRANSIENT` actions will also be evaluated
 - b. `TRANSIENT`, `POSTCHECK`, or `TOPOLOGYCHECK` actions with the smallest `TimeDelay` will be applied
7. If any `POSTCHECK`, `TOPOLOGYCHECK`, or `TRANSIENT` actions are done then go back to step 2 and repeat 2-6 (Note: this loop will abort after 100 times through this loop)

After this process has been completed, the contingency analysis processor should provide mechanisms to report which actions were applied during the contingency solution. In addition it should provide mechanisms to report violations that occurred. The format does not prescribe how the contingency result reporting should be performed as that is purely an output of a software tool. The limit monitoring settings however are really an integral part of a contingency processor, so the Limit Monitoring Settings and data structures for specifying them are described in Section 8.

7 Transient Stability Contingency Analysis Processing with RAS

It was discussed in the Document Summary Section that the ability to immediately, completely and generically specify RAS for use in the *transient stability* environment is not be achieved in this document. Taken that as a given, the accomplishments of this document do open a promising avenue for doing this going forward in an incremental way. Specific RAS models could be created for the transient stability environment in much the same process that new dynamic models are done now (for example the new wind turbine models developed through the WECC MVWG or the new CmplDw load model developed through that same working group.) PowerWorld Simulator has already added a feature to model the Fast AC Reactive Insertion (FACRI) RAS in WECC as a switched shunt model (FACRI_SS) and a series cap model (FACRI_SC). It should be possible to move these dynamic models into the power flow based contingency analysis tool in a manner similar to that already done for relay models as discussed in Section 5.8.1. It is PowerWorld's recommendation that this avenue be explored, but we do realize this is an area of discussion.

8 Limit Monitoring Settings

Although these settings are called “Limit Monitoring Settings” they are not designed to specify what to monitor as much as to specify what NOT to monitor. By default it will be assumed that limit monitoring is done on all buses, branches and interfaces in the power system. Thus a novice user specifying none of this information will cause the system to monitor everything. With the monitoring of all records as a starting point, the following data records provide mechanisms to choose when not to monitor a device. A device will only be monitored if the following 4 conditions are met.

1. **Monitor Field:** Each bus, branch, and interface has its own Monitor Field. These fields are described in Sections 8.4, 8.5 and 8.6. These fields must be set to YES in order for the device to be monitored.
2. **LimitSet Disabled Field:** Each bus, branch, and interface in the system is assigned to a LimitSet. The LimitSet’s Disabled field must be set to NO. These are described in Section 8.1.
3. **Area Monitoring:** The device’s area (or one of the areas if it is a tie-line) must have its MonitorLimits field set to YES and the device must meet the MonitorMinkV to MonitorMaxkV range of the area. These are described in Section 8.2.
4. **Zone Monitoring:** The device’s zone (or one of the zones if it is a tie-line) must have its MonitorLimits field set to YES and the device must meet the MonitorMinkV to MonitorMaxkV range of the zone. These are described in Section 8.3.

8.1 LimitSet

LimitSet records store information about how buses, branches, and interfaces are monitored. Each Bus, Branch, and Interface is assigned to one LimitSet and inherits properties for how it is monitored from the LimitSet. The fields recognized by the LimitSet object type are shown in the following table.

Field	Description and Rules for Field
Name (key)	Name of the LimitSet. This is the unique identifier for the LimitSet so there can only be one LimitSet with this Name.
Disabled (required)	Set to YES to disable all monitoring of devices belonging to this LimitSet. Set to NO to enable monitoring
DataMaintainerAssign (optional, default blank)	Name of the DataMaintainer for this object. This can be blank as well which indicates no DataMaintainer has been assigned.
<i>Following fields are related to monitoring branches and interfaces</i>	
AmpMVA (required)	Set to Amp / MVA to monitor based on Amp limits on transmission lines and MVA limit on transformers. Set to MVA to monitor based on MVA limits on all branches.
BranchPercent (required)	Set to the percentage at which violations will be reported for branches
InterfacePercent (required)	Set to the percentage at which violations will be reported for interfaces
BranchRateSet (required)	The rating set used to monitor branches during in the reference case. Set to either A, B, C, D, E, F, G, or H. See Section 8.1.1.

InterfaceRateSet (required)	The rating set used to monitor interfaces during in the reference case. Set to either A, B, C, D, E, F, G, or H. See Section 8.1.1.
BranchRateSetCTG (required)	The rating set used to monitor branches during a contingency solution. Set to either A, B, C, D, E, F, G, or H. See Section 8.1.1.
InterfaceRateSetCTG (required)	The rating set used to monitor interfaces during a contingency solution. Set to either A, B, C, D, E, F, G, or H. See Section 8.1.1.
<i>Following fields are related to monitoring high and low bus voltages. See Section 8.1.2 for details.</i>	
HighVolt (required)	Set to the per unit voltage above which is considered a high violation in the the reference case.
LowVolt (required)	Set to the per unit voltage below which is considered a low violation in the the reference case.
HighVoltCTG (optional, default 1.1)	Set to the per unit voltage above which is considered a high violation in the the contingency solution.
LowVoltCTG (optional, default 0.9)	Set to the per unit voltage below which is considered a low violation in the the contingency solution.
HighVoltRateSet (optional, default A)	The rating set used for high bus voltages during in the reference case. Set to either A, B, C, D. These options are only used if a bus is configured to store its own voltage limits, which is not what is most common.
LowVoltRateSet (optional, default A)	The rating set used for low bus voltages during in the reference case. Set to either A, B, C, D. These options are only used if a bus is configured to store its own voltage limits, which is not what is most common.
HighVoltRateSetCTG (optional, default A)	The rating set used for high bus voltages during a contingency solution. Set to either A, B, C, D. These options are only used if a bus is configured to store its own voltage limits, which is not what is most common.
LowVoltRateSetCTG (optional, default A)	The rating set used for low bus voltages during a contingency solution. Set to either A, B, C, D. These options are only used if a bus is configured to store its own voltage limits, which is not what is most common.
<i>Following fields are related to the monitoring of violations based on how the system changes after a contingency solution.</i>	
UseSetCTGMon (optional, default NO)	Set to YES to specify that the following options override the CTG_Options_Value options with the same names. Set to NO to ignore the following options. Normally these options are specified globally for all devices during the contingency analysis, but by setting this option to YES these values will override them for devices in this LimitSet.
VoltChangePercent (optional, default NO)	See Section 5.8
MonDiscBus (optional, default NO)	See Section 5.8
NeverReport (optional, default NO)	See Section 5.8
NeverBranchInc (optional, default 0.0)	See Section 5.8
NeverLowVoltDec (optional, default 0.0)	See Section 5.8
NeverHighVoltInc (optional, default 0.0)	See Section 5.8

NeverInterfaceInc (optional, default 0.0)	See Section 5.8
AlwaysReport (optional, default NO)	See Section 5.8
AlwaysBranchInc (optional, default 999.0)	See Section 5.8
AlwaysLowVoltDec (optional, default 2.0)	See Section 5.8
AlwaysHighVoltInc (optional, default 2.0)	See Section 5.8
AlwaysInterfaceInc (optional, default 999.0)	See Section 5.8

A sample file section is shown as follows:

```
LimitSet (Name,LowVolt,HighVolt,BranchPercent,InterfacePercent,NomogramPercent,
BranchRateSet,BranchRateSetCTG,InterfaceRateSet,InterfaceRateSetCTG,Disabled,
AmpMVA,NeverReport,AlwaysReport,VoltChangePercent,NeverBranchInc,
AlwaysBranchInc,NeverLowVoltDec,AlwaysLowVoltDec,NeverHighVoltInc,
AlwaysHighVoltInc,NeverInterfaceInc,AlwaysInterfaceInc,MonitorEnd,
LowVoltRateSet,HighVoltRateSet,LowVoltRateSetCTG,
HighVoltRateSetCTG,LowVoltCTG,HighVoltCTG,MonDiscBus,UseSetCTGMon,
DataMaintainerAssign)
{
"Default"      0.95  1.05  100.0  100.0  100.0  "A"  "B"  "A"  "B"  "NO"  "Amp/MVA"
"NO"  "NO"  "NO"  0.0  999.0  0.0  2.0  0.0  2.0  0.0  999.0  "Higher"  "A"  "A"  "B"  "B"
0.900  1.100  "NO"  "NO"  "DM1"
"Limit Set 1"  0.96  1.04  110.0  100.0  100.0  "C"  "D"  "C"  "D"  "NO"  "Amp/MVA"
"NO"  "NO"  "NO"  0.0  999.0  0.0  2.0  0.0  2.0  0.0  999.0  "Higher"  "C"  "C"  "D"  "D"
0.910  1.110  "NO"  "NO"  "DM1"

"Limit Set 2"  1.00  1.10  120.0  100.0  100.0  "E"  "F"  "A"  "B"  "NO"  "Amp/MVA"
"NO"  "NO"  "NO"  0.0  999.0  0.0  2.0  0.0  2.0  0.0  999.0  "Higher"  "A"  "A"  "B"  "B"
0.950  1.150  "NO"  "NO"  "DM1"
}
```

8.1.1 Branch and Interface relationship to LimitSet

Each branch in the underlying power system data records has 8 limits assigned to it. These are referred to as Limit A, B, C, D, E, F, G, and H. The fields associated with the limits are LimitMVA, LimitMVAB, LimitMVAC, LimitMVAD, LimitMVAE, LimitMVAF, LimitMVAG, and LimitMVAH.

Similarly, each interface has 8 limits (A-H) assigned to it. The fields associated with the limits are LimitMWA, LimitMWB, LimitMWC, LimitMWD, LimitMWE, LimitMWF, LimitMWG, and LimitMWH.

The LimitSet has various fields that specify which rating set to use when monitoring in the contingency reference case or during the post-contingency monitoring. These refer to these A – H limits.

8.1.2 Bus relationship to LimitSet

Traditionally, power flow data records have not stored voltage ratings with each individual bus record. As a result, the typical way that high and low bus limits are assigned to a bus is by assigning the bus to a LimitSet and then configuring the LimitSet fields HighVolt/LowVolt and HighVoltCTG/LowVoltCTG appropriately to assign the High/Low voltage limits during the reference case and post-contingency monitoring respectively.

It is also possible to assign 4 sets of high and low per unit voltage limits for each bus (call them High A, B, C, and D and Low A, B, C, and D). With each bus record, there is then a flag called “Use bus-specific limits”. If this flag is set to YES, the bus limits will be determined by using the LimitSet fields that refer to a “RateSet” in much the same way as is done for Branch and Interface limits as described in Section 8.1.1. The fields associated with these bus-specific limits are as follows: UseSpecificLimits, LimitHighA, LimitHighB, LimitHighC, LimitHighD, LimitLowA, LimitLowB, LimitLowC, and LimitLowD.

8.2 Area (settings for limit monitoring)

Special area limit monitoring options are entered to specify which devices are monitored for violations during the contingency analysis process. The fields are shown in the following table:

Field	Description and Rules for Field
ObjectID	Identifies the area using the object string in format specified in Section 2.3
MonitorLimits (optional, default YES)	Set to YES to specify that objects belonging to this area be monitored for violations. Set to NO to not monitor objects in the area. Devices such as a branch that ties two areas together may be monitored if either one of its terminal areas are monitored.
MonitorMinkV (optional, default 0.0)	Specify the minimum nominal kV level at which monitoring is done.
MonitorMaxkV (optional, default 9999.0)	Specify the maximum nominal kV level at which monitoring is done. For branches that are tie-lines, the branch may be monitored if either terminal bus meets the voltage range.

A sample file section is shown as follows:

```
Area (ObjectID, MonitorLimits, MonitorMinkV, MonitorMaxkV)
{
  "Area 50"           "YES"      150.0  600.0
  "Area 'BCHydro'"   "YES"      60.0   600.0
  "Area 'Arizona'"   "NO"       0.0   999.0
}
```

8.3 Zone (settings for limit monitoring)

Special zone limit monitoring options are entered to specify which devices are monitored for violations during the contingency analysis process. The fields are shown in the following table:

Field	Description and Rules for Field
ObjectID	Identifies the zone using the object string in format specified in Section 2.3
MonitorLimits (optional, default YES)	Set to YES to specify that objects belonging to this zone be monitored for violations. Set to NO to not monitor objects in the zone. Devices such as a branch that ties two zone together may be monitored if either one of its terminal zone are monitored.
MonitorMinkV (optional, default 0.0)	Specify the minimum nominal kV level at which monitoring is done.
MonitorMaxkV (optional, default 9999.0)	Specify the maximum nominal kV level at which monitoring is done. For branches that are tie-lines, the branch may be monitored if either terminal bus meets the voltage range.

A sample file section is shown as follows:

```
Zone (ObjectID, MonitorLimits, MonitorMinkV, MonitorMaxkV)
{
  "Zone 50"           "YES"      150.0  600.0
  "Zone 'WestSide'"  "YES"      60.0   600.0
  "Zone 566"         "NO"       0.0    999.0
}
```

8.4 Bus (settings for limit monitoring)

Special bus limit monitoring options are entered to specify whether to monitor this bus and which LimitSet it belong to. The fields are shown in the following table:

Field	Description and Rules for Field
ObjectID	Identifies the bus using the object string in format specified in Section 2.3
Monitor (optional, default YES)	Set to YES to specify that this bus should be monitored. Set to NO to not monitor this bus.
LimitSet (optional, default Default)	Name of the Limit Set to which the bus belongs

A sample file section is shown as follows:

```
Bus (ObjectID, Monitor, LimitSet)
{
  "Bus 10"           "YES" "Limit Set 1"
  "Bus 'MyLabel'"    "YES" "Limit Set 2"
  "Bus 'Springfield_345.0'" "YES" "Limit Group 2"
}
```

8.5 Branch (settings for limit monitoring)

Special branch limit monitoring options are entered to specify whether to monitor this branch and which LimitSet it belong to. The fields are shown in the following table:

Field	Description and Rules for Field
ObjectID	Identifies the branch using the object string in format specified in Section 2.3
Monitor (optional, default YES)	Set to YES to specify that this branch should be monitored. Set to NO to not monitor this branch.
LimitSet (optional, default Default)	Name of the Limit Set to which the branch belongs

A sample file section is shown as follows:

```
Branch (ObjectID, Monitor, LimitSet)
{
  "Branch 10 55 '1'" "YES" "Limit Set 1"
  "Branch 'MyLabel'" "YES" "Limit Set 2"
  "Branch 'MyName_345.0' ' MyName _138.0' '2'" "YES" "Limit Group 2"
}
```

8.6 Interface (settings for limit monitoring)

Special interface limit monitoring options are entered to specify whether to monitor this interface and which LimitSet it belong to. The fields are shown in the following table:

Field	Description and Rules for Field
ObjectID	Identifies the interface using the object string in format specified in Section 2.3
Monitor (optional, default YES)	Set to YES to specify that this interface s should be monitored. Set to NO to monitor this interface.
LimitSet (optional, default Default)	Name of the Limit Set to which the interface belongs

A sample file section is shown as follows:

```
Interface (ObjectID,           Monitor, LimitSet)
{
"Interface 'PDCI' "           "YES" "Limit Set 1"
"Interface 'COI' "           "YES" "Limit Set 2"
"Interface 'West of Springfield'" "YES" "Limit Group 2"
}
```

8.7 CustomMonitor

Standard limit monitoring in power flow based contingency analysis looks only at branch MVA limits, bus voltage limits, and interface MW limits. These limits are specified in the standard power flow case input data formats already. There may be a need for more specific types of monitoring, which can be achieved by defining a CustomMonitor data record. Examples of such needs are as follows:

1. The monitoring of other fields (say generator MW outputs)
2. Ability to enable or disable monitoring based on the Category of the contingency
3. Ability to use modified monitoring based on a change from the reference case based on Category of the contingency

The CustomMonitor object has the following fields:

Field	Description and Rules for Field
Name (key)	Unique Name for the custom monitor object
Enabled (optional, default YES)	Set to YES to enable this custom monitor. Set to NO to turn off the use of this monitor.
Category (optional, default blank)	A comma delimited list of strings representing the contingency categories assigned to this custom monitor. A custom monitor will only be used to look for violations during a contingency if at least one category is in common between the Contingency and the CustomMonitor object.
ObjectType (required, ObjectType or Object must be specified)	Object type to be monitored by this custom monitor. See choices for object types in Section 2.2.

Object (required, ObjectType or Object must be specified)	If this field is left blank then all objects of the type specified by ObjectType will be monitored by this CustomMonitor. Otherwise a specific object may be specified by entering a string using the format described in Section 2.3.
ObjectField (optional, default blank)	Field that is monitored for the objects or object describe by the ObjectType or Object of this record. The fields are the strings described in Section 2.4.
FilterPre (optional, default blank)	Name of a filter or device filter (See Section 0 or 3.3). If this is specified, an object must meet this filter in the contingency reference state in order for it to be monitored in the contingency analysis run. A description of the format of this string is found in Section 3.4. Violations will be reported only if both FilterPre and FilterPost are met.
FilterPost (optional, default blank)	Name of a filter or device filter (See Section 0 or 3.3). If this is specified, an object must meet this filter in the post-contingency state in order for it to report a violation in the contingency analysis tool. A description of the format of this string is found in Section 3.4. Violations will be reported only if both FilterPre and FilterPost are met.
UseMinIncrease (optional, default NO)	Set to YES to specify that a violation should be reported if the increase in the value being monitored is greater than the value specified as MinIncrease. Set to NO to disable this feature.
MinIncrease (optional, default 0.0)	The value that goes with the UseMinIncrease option
UseMinDecrease (optional, default NO)	Set to YES to specify that a violation should be reported if the decrease in the value being monitored is greater than the value specified as MinDecrease. Set to NO to disable this feature.
MinDecrease (optional, default 0.0)	The value that goes with the UseMinDecrease option
ValueMeaning (optional, default Actual)	Meaning of the MinDecrease and MinIncrease values. Percent : means values should be interpreted as a percent change from the initial value Actual : means values should be interpreted as the actual change in the units of the field being monitored
DataMaintainerAssign (optional, default blank)	Name of the DataMaintainer for this object. This can be blank as well which indicates no DataMaintainer has been assigned.

A sample file section is shown as follows:

```


Filter (Name,ObjectType,Logic,FilterPre,Enabled,DataMaintainerAssign)
{
  "Roughride over Max" "Gen" "AND" "NO" "YES" "DM1"
}
Condition (ObjectType,Filter,CondNum,ObjectField,ConditionType,Value,OtherValue,Absolute)
{
  "Gen" "Roughrider Max" 1 "MW" ">" "<Field>MWMax" "" "NO"
}
CustomMonitor (Name,Enabled,Category,ObjectType,Object,ObjectField,FilterPre,
FilterPost,UseMinIncrease,MinIncrease,UseMinDecrease,MinDecrease,ValueMeaning,
DataMaintainerAssign)
{
  "Bus Voltage Drops" "YES" "" "Bus" "" "Vpu" "" "" "YES" 5 "NO" 0 "Percent"
  // following appears across 2 lines of text.
  "Roughrider high" "YES" "" "Gen" "Gen '54' '1'" "MW" ""
    "Roughrider Max" "NO" 0 "NO" 0 "Actual" "DM1"
}

```


9 Final Demonstration

9.1 Saving a file in this format


The data format described in this document has been fully integrated in PowerWorld Simulator Version 18 and will serve as a more concise and readable version of PowerWorld's Auxiliary File Format. This format builds on that technology but has improved it to make it easier for humans to read and presumably simpler for others to parse. In order to save this file from within the PowerWorld Simulator software tool, one need only open the Contingency Analysis dialog and click on the **Save** button shown in the following figure.



In the Save Dialog that then appears, the **Save as Type** drop-down should be changed to *WECC Contingency and RAS file (*.aux)* as shown in the following figure.



Finally, after choosing a file to which to save, another dialog will appear prompting you to choose which type of key identifiers to use when saving the file. The choice of key identifiers was described more in Section 2.3. The dialog will look as shown below.



After clicking **Choose**, this will then save the file to the hard drive.

9.2 Saving a file in this Format with more Flexibility

Using the file type entitled *WECC Contingency and RAS file (*.aux)* will always store a specific list of objects. If more flexibility is desired, then you may also choose the option *Simulator Contingency File (*.aux)*. When choosing this option, a more detailed dialog will appear giving you options of what to save to the file as shown below. The options along the left allow you to choose what to store to the AUX file. The options on the right allow you to specify what format to use. To conform to the syntax rules of this document then the 5 check-boxes inside the red box below must be checked. You may click the button **Set What to Store and Formatting options to match the WECC RAS and Contingency Format**.

Contingency Settings

There are numerous settings which affect the Contingency Analysis calculations. Choose which settings you would like to store and also some formatting options on how to represent them in the AUX file

What to Store

- Save Contingency Definitions
- Save Remedial Actions and Global Actions
 - Save unlinked contingency actions (none)
- Save ModelFilter, ModelCondition, and ModelExpression
- Save Contingency Options (also Area Makeup, Gen Line Drop, Gen AGC, Gen Max MW, Bus Load Throw, Shunt)
 - Suppress Gen and Bus Contingency Options
- Save Voltage Control Groups
- Save General Power Flow Solution Options
- Save Custom Monitors
- Save Limit Monitoring Settings (Area, Zone, LimitSet, Bus, Branch, and Interface)
 - Save Limit Cost Functions if they exist (none)
- Save List Display Settings
- Save Contingency Results
 - Save Inactive Violations
- Save Interface Definitions
- Save Injection Group Definitions
- Save Distributed Computing Settings
- Save Advanced Filters Used by Custom Monitors, ModelConditionConditions, and RemedialActionElements
- Merge Contingency Blocks and Global Actions

Check All Uncheck All

Formatting Options

Save Data Using

- Number
- Name and Nominal kV
- Label (Use Number if no label)

- Use Concise Variable Names and AUX Headers
- Replace SUBDATA with DATA (recommended)
- Use Object ID fields with Area, Zone, Bus, Branch, Gen, Shunt, and Interface objects to simplify AUX file output
 - Use Special Objects IDs for MS Line Sections
 - Use Special Objects IDs for 3 Winding Transformer windings

Set What to Store and Formatting options to match the WECC RAS and Contingency Format

Save Selected Data Maintainers Only

Select Data Maintainers

OK Cancel


For a complete help on this dialog see the following website:

http://www.powerworld.com/WebHelp/#MainDocumentation_HTML/Contingency_Analysis_Save_Aux.htm

9.3 Loading a file in this Format into PowerWorld Simulator

The structure described in this document will be read into PowerWorld Simulator as though it is one of PowerWorld's own Auxiliary Files. Thus loading the file is very simple:

1. Go the **File** menu and choose **File, Load Auxiliary**
2. Use the Open Dialog to navigate to the file
3. Click **Open**



Within PowerWorld Simulator, you may also open an Auxiliary Files from the local menu of any case information display (table of data), but the most basic way will be as shown above.

9.4 Example file in this format

The following represents a sample of all the information described in the previous portions of this document. The file is concise yet contains enough self-documentation that it is human readable.

```
//-----  
// THE FOLLOWING INJECTION GROUP DEFINITIONS ARE BEING SAVED BY  
//-----  
INJECTIONGROUP (Name)  
{  
"Viking G1 and G2"  
}  
PARTPOINT (GroupName, Object, AutoCalcMethod, PartFact, AutoCalc)  
{  
"Viking G1 and G2" "Gen '28' '1'" "SPECIFIED" 150.00000 "NO "  
"Viking G1 and G2" "Gen '28' '2'" "SPECIFIED" 150.00000 "NO "  
}  
  
//-----  
// THE FOLLOWING LIMIT MONITORING SETTINGS ARE BEING SAVED BY THE CONTINGENCY TOOL.  
//-----  
LIMITSET (Name, LowVolt, HighVolt, BranchPercent, InterfacePercent,  
BranchRateSet, BranchRateSetCTG, InterfaceRateSet, InterfaceRateSetCTG, Disabled,  
AmpMVA, NeverReport, AlwaysReport, VoltChangePercent, NeverBranchInc,  
AlwaysBranchInc, NeverLowVoltDec, AlwaysLowVoltDec, NeverHighVoltInc,  
AlwaysHighVoltInc, NeverInterfaceInc, AlwaysInterfaceInc,  
LowVoltRateSet, HighVoltRateSet, LowVoltRateSetCTG,  
HighVoltRateSetCTG, LowVoltCTG, HighVoltCTG, MonDiscBus, UseSetCTGMon)  
{  
"Default" 0.95 1.05 100.0 100.0 "A" "B" "A" "B" "NO" "Amp/MVA" "NO" "NO" "NO" 0.0 999.0  
0.0 2.0 0.0 2.0 0.0 999.0 "A" "A" "B" "B" 0.900 1.100 "NO" "NO"  
  
"Limit Set 1" 0.96 1.04 110.0 100.0 "C" "D" "C" "D" "NO" "Amp/MVA" "NO" "NO" "NO" 0.0 999.0  
0.0 2.0 0.0 2.0 0.0 999.0 "C" "C" "D" "D" 0.910 1.110 "NO" "NO"  
  
"Limit Set 2" 1.00 1.10 120.0 100.0 "E" "F" "A" "B" "NO" "Amp/MVA" "NO" "NO" "NO" 0.0 999.0  
0.0 2.0 0.0 2.0 0.0 999.0 "A" "A" "B" "B" 0.950 1.150 "NO" "NO"  
}  
  
AREA (ObjectID, MonitorLimits, MonitorMaxkV, MonitorMinkV)  
{  
"Area '1'" "YES" 30.0000 345.0000  
}  
  
ZONE (ObjectID, MonitorLimits, MonitorMaxkV, MonitorMinkV)  
{  
"Zone '1'" "YES" 30.0000 345.0000  
}  
  
SCRIPT  
{  
// set all buses to monitored as part of first limit group  
SetData(Bus, [Monitor, LimitSet], ["YES", "Default"], All);  
}  
BUS (ObjectID, Monitor, LimitSet)  
{  
"Bus '10'" "YES" "Limit Group 1"  
"Bus '14'" "YES" "Limit Group 1"  
"Bus '16'" "YES" "Limit Group 2"  
"Bus '17'" "YES" "Limit Group 2"  
}  
  
SCRIPT  
{  
// set all branches to monitored as part of first limit group  
SetData(Branch, [Monitor, LimitSet], ["YES", "Default"], All);  
}
```

```

BRANCH (ObjectID,Monitor,LimitSet)
{
"Branch '1' '40' '1'" "YES" "Limit Group 1"
"Branch '3' '41' '1'" "YES" "Limit Group 2"
"Branch '5' '44' '1'" "YES" "Limit Group 2"
"Branch '10' '19' '1'" "YES" "Limit Group 1"
"Branch '12' '40' '1'" "YES" "Limit Group 1"
}
SCRIPT
{
// set all interfaces to monitored as part of first limit group
SetData(Interface, [Monitor,LimitSet], ["YES", "Default"], All);
}
FILTER (Name,ObjectType,Logic,FilterPre,Enabled)
{
"Roughride over Max" "Gen" "AND" "NO" "YES"
}
CONDITION (ObjectType,Filter,CondNum,ObjectField,ConditionType,Value,OtherValue,Absolute)
{
"Gen" "Roughrider Max" 1 "MW" ">" "<Field>MWMax" "" "NO"
}
CUSTOMMONITOR (Name,Enabled,Category,ObjectType,Object,ObjectField,FilterPre,FilterPost,
UseMinIncrease,MinIncrease,UseMinDecrease,MinDecrease,ValueMeaning)
{
"Bus Voltage Drops" "YES" "" "Bus" "" "Vpu" "" "" "YES" 5 "NO" 0 "Percent"
"Roughrider high" "YES" "" "Gen" "Gen '54' '1'" "MW" "" "Roughrider Max" "NO" 0 "NO" 0 "Actual"
}
//-----
// THE FOLLOWING SECTION CONTAINS OPTIONS FOR THE CONTINGENCY ANALYSIS.
//-----
CTG_OPTIONS_VALUE (Option,Value)
{
"AlwaysReport" "YES"
"AlwaysBranchInc" "999"
"AlwaysHighVoltInc" "2"
"AlwaysInterfaceInc" "999"
"AlwaysLowVoltDec" "2"
"NeverReport" "YES"
"NeverBranchInc" "2"
"NeverHighVoltInc" "0"
"NeverInterfaceInc" "0"
"NeverLowVoltDec" "0"
"VoltChangePercent" "NO"
"MonDiscBus" "NO"
"DisableGenDropOverlap" "NO"
"AGCTolerance" "0.05"
"MakeUpPower" "Gen Part Factors"
"TSModelMaxDelay" "3600"
"TSModelsTrip" ""
"TSModelsMonitor" ""
"DynAssignSlack" "Default"
"PUConvergenceTol" "0.001"
"DisableOptMult" "Default"
"MaxItr" "50"
"MinVoltILoad" "Default"
"MinVoltSLoad" "Default"
"EnforceGenMWLimits" "YES"
"LTCTapBalance" "Default"
"ChkPhaseShifters" "NO"
"ChkSVCs" "NO"
"ChkShunts" "NO"
"ChkTaps" "NO"
"DisableGenMVRCheck" "Default"
"ChkVarImmediately" "Default"
"MaxItrVoltLoop" "Default"
"MinLTCsense" "Default"
"ModelPSDiscrete" "Default"
"PreventOscillations" "Default"
"ShuntInner" "NO"
}

```

```

//-----
// THE FOLLOWING SECTION CONTAINS THE POWER FLOW SOLUTION OPTIONS.
//-----
SIM_SOLUTION_OPTIONS_VALUE (Option,Value)
{
"DynAssignSlack" "YES"
"DisableOptMult" "NO"
"MaxItr" "50"
"MinVoltILoad" "0.5"
"MinVoltSLoad" "0.7"
"AGCTolerance" "0.05"
"EnforceGenMWLimits" "YES"
"LTCTapBalance" "YES"
"ChkPhaseShifters" "YES"
"ChkSVCs" "YES"
"ChkShunts" "YES"
"ChkTaps" "YES"
"ChkVarImmediately" "NO"
"MaxItrVoltLoop" "20"
"MinLTCsense" "0.01"
"ModelPSDiscrete" "NO"
"PreventOscillations" "YES"
"ShuntInner" "YES"
}

// THE FOLLOWING SECTION CONTAINS OPTIONS FOR MAKE UP GENERATION FOR CONTINGENCY
AREA (ObjectID,CTGMakeUpGen)
{
"Area '1'" 0.0000
}

// THE FOLLOWING SECTION CONTAINS OPTIONS FOR ALL GENERATION SET TO LIMIT THE MW
// RESPONSE OF A GENERATOR IN THE POST-CONTINGENCY SOLUTION
SCRIPT
{
// set all generators to have no Maximum response
SetData(Gen, [CTGMaxResp], [-1.0], All);
}
GEN (ObjectID,CTGMaxResp)
{
"Gen '28' '1'" 15.0000
"Gen '31' '1'" 44.0000
"Gen '48' '1'" 5.0000
"Gen '53' '1'" 12.0000
}

// THE FOLLOWING SECTION CONTAINS OPTIONS FOR ALL GENERATION SET TO LIMIT THE
// AGC RESPONSE OF A GENERATOR IN THE POST-CONTINGENCY SOLUTION
SCRIPT
{
// set all generators to not prevent post-contingency ATC response
SetData(Gen, [CTGPreventAGC,CTGPartFact], ["NO","same"], All);
}
GEN (ObjectID,CTGPreventAGC,CTGPartFact)
{
"Gen '14' '1'" "RESPOND" 11.000000
"Gen '28' '2'" "YES" same
"Gen '31' '1'" "RESPOND" 12.000000
"Gen '50' '1'" "NO" 13.000000
}

// THE FOLLOWING SECTION CONTAINS OPTIONS FOR ALL GENERATION SET TO USE LINE DROP/REACT CURRENT
COMP IN POST-CONTINGENCY
SCRIPT
{
// set all generators to not use line drop comp
SetData(Gen, [UseLineDrop], ["NO"], All);
}
GEN (ObjectID,UseLineDrop,Xcomp)
{
"Gen '28' '2'" "PostCTG" 0.055500
}

```



```

{
"OPEN Cowboy G1" "AND" ""
"OPEN Stampeder G1" "OR" ""
"OPEN Viking G1 and G2" "AND" ""
"Roughrider-Raven 1 & 2" "AND" ""
"Roughrider-Raven 2 & 3" "AND" ""
}
MODELFILTERCONDITION (ModelFilter,CondNum,Criteria,Logic)
{
"OPEN Cowboy G1" 1 "Cowboy-Cardinal 1 345kV Line" ""
"OPEN Cowboy G1" 2 "Cowboy-Seahawk 1 345kV Line" ""
"OPEN Cowboy G1" 3 "Cowboy-Line 345/138kV Transformer" ""
"OPEN Stampeder G1" 1 "Roughrider-Raven 1 & 2" ""
"OPEN Stampeder G1" 2 "Roughrider-Raven 2 & 3" ""
"OPEN Viking G1 and G2" 1 "Dolphin-Raider 1 138 kV Line" ""
"OPEN Viking G1 and G2" 2 "Dolphin-Panther 1 138kV Line" ""
"Roughrider-Raven 1 & 2" 1 "Roughrider-Raven 1 69kV Line" ""
"Roughrider-Raven 1 & 2" 2 "Roughrider-Raven 2 69kV Line" ""
"Roughrider-Raven 2 & 3" 1 "Roughrider-Raven 2 69kV Line" ""
"Roughrider-Raven 2 & 3" 2 "Roughrider-Raven 3 69kV Line" ""
}

//-----
// THE FOLLOWING SECTION CONTAINS A DESCRIPTION OF THE REMEDIAL ACTION RECORDS.
//-----
REMEDIALACTION (Name,Skip,Memo)
{
"Stampeder RAS" "NO" ""
"Cowboy RAS" "NO" ""
"Viking RAS" "NO" ""
"Dolphin-Raider RAS" "NO" ""
"Viking-Dolphin 1 Overload" "NO" ""
"Viking-Dolphin 2 Overload" "NO" ""
}
REMEDIALACTIONELEMENT (RemedialAction,Object,Action,Criteria,CriteriaStatus, TimeDelay, Comment)
{
"Stampeder RAS" "GEN 53 1" "OPEN" "OPEN Stampeder G1" "TOPOLOGYCHECK" 0 ""
"Cowboy RAS" "GEN 31 1" "OPEN" "OPEN Cowboy G1" "TOPOLOGYCHECK" 0 ""
"Viking RAS" "INJECTIONGROUP 'Viking G1 and G2'" "OPEN" "OPEN Viking G1 and G2" "TOPOLOGYCHECK" 0
""
"Dolphin-Raider RAS" "GEN 28 1" "OPEN" "Dolphin-Raider 1 138 kV Line" "TOPOLOGYCHECK" 0 ""
"Viking-Dolphin 1 Overload" "BRANCH 28 29 1" "OPEN" "Viking-Dolphin 1 345/138 Over 135%"
"POSTCHECK" 0 ""
"Viking-Dolphin 2 Overload" "BRANCH 28 29 2" "OPEN" "Viking-Dolphin 2 345/138 Over 135%"
"POSTCHECK" 0 ""
}

//-----
// THE FOLLOWING SECTION CONTAINS A DESCRIPTION OF THE CONTINGENCY RECORDS.
//-----
CONTINGENCY (Name,Category,Skip,Memo)
{
"L-2_Roughrider-Raven 2&3" "" "NO" ""
"L-2_Roughrider-Raven 1&2" "" "NO" ""
"L_Falcon-PatriotC1" "" "NO" ""
"T_Falcon-TitanC1" "" "NO" ""
"L_Packer-RedskinC1" "" "NO" ""
"L_Raven-RoughriderC2" "" "NO" ""
"L_Raven-RoughriderC3" "" "NO" ""
"L_Raven-RoughriderC1" "" "NO" ""
"T_Roughrider-StampederC1" "" "NO" ""
"T_Packer-BrownC2" "" "NO" ""
"T_Packer-BrownC1" "" "NO" ""
"L_Packer-SteelerC1" "" "NO" ""
"L_Bear-JetC1" "" "NO" ""
"L_Patriot-BomberC1" "" "NO" ""
"L_Bronco-BillC1" "" "NO" ""
"L_49er-BrownC1" "" "NO" ""
"L_Chief-EskimoC1" "" "NO" ""
"L_Cowboy-CardinalC1" "" "NO" ""
"L_Buccaneer-RaiderC1" "" "NO" ""
}

```

```

"L_Packer-ColtC1" "" "NO" ""
"L_Lion-TitanC1" "" "NO" ""
"L_Bengal-SteelerC1" "" "NO" ""
"L_Colt-GiantC1" "" "NO" ""
"L_Redskin-EagleC1" "" "NO" ""
"L_Redskin-EagleC2" "" "NO" ""
"L_Bear-ChargerC1" "" "NO" ""
"L_Roughrider-BomberC1" "" "NO" ""
"L_Bear-EskimoC1" "" "NO" ""
"L_Saint-JetC1" "" "NO" ""
"L_Saint-JetC2" "" "NO" ""
"L_Bronco-RedskinC1" "" "NO" ""
"L_Raven-RamC1" "" "NO" ""
"L_Dolphin-RaiderC1" "" "NO" ""
"L_Panther-DolphinC1" "" "NO" ""
"L_Raven-BengalC1" "" "NO" ""
"L_Cowboy-VikingC1" "" "NO" ""
"L_Argonaut-DolphinC1" "" "NO" ""
"L_Buccaneer-PantherC1" "" "NO" ""
"T_Viking-DolphinC2" "" "NO" ""
"T_Lion-CowboyC1" "" "NO" ""
"L_Texan-BillC1" "" "NO" ""
"T_Chief-PantherC1" "" "NO" ""
"T_Viking-DolphinC1" "" "NO" ""
"L_Ram-BillC1" "" "NO" ""
"L_Lion-ArgonautC1" "" "NO" ""
"T_Titan-CardinalC1" "" "NO" ""
"T_Titan-CardinalC2" "" "NO" ""
"L_Titan-BrownC1" "" "NO" ""
"L_Titan-JaguarC1" "" "NO" ""
"T_Bill-RaiderC1" "" "NO" ""
"T_Bill-RaiderC2" "" "NO" ""
"T_Jet-JaguarC1" "" "NO" ""
"L_Jaguar-StampederC1" "" "NO" ""
"L_Jet-RoughriderC1" "" "NO" ""
"L_Texan-ChargerC1" "" "NO" ""
"L_Falcon-GiantC1" "" "NO" ""
"L-2_Dolphin-Panther/Dolphin-Raider" "" "NO" ""
"L_49er-RaiderC1" "" "NO" ""
"T_Seahawk-BrownC1" "" "NO" ""
"L-2_Cowboy-Cardinal\Cowboy-Seahawk" "" "NO" ""
"L_Seahawk-CowboyC1" "" "NO" ""
}
CONTINGENCYELEMENT (Contingency, Object, Action, Criteria, CriteriaStatus, TimeDelay, Comment)
{
"L-2_Roughrider-Raven 2&3" "BRANCH 15 54 2" "OPEN" "" "CHECK" 0 ""
"L-2_Roughrider-Raven 2&3" "BRANCH 15 54 3" "OPEN" "" "CHECK" 0 ""
"L-2_Roughrider-Raven 1&2" "BRANCH 15 54 1" "OPEN" "" "CHECK" 0 ""
"L-2_Roughrider-Raven 1&2" "BRANCH 15 54 2" "OPEN" "" "CHECK" 0 ""
"L_Falcon-PatriotC1" "BRANCH 10 13 1" "OPEN" "" "CHECK" 0 ""
"T_Falcon-TitanC1" "BRANCH 10 39 1" "OPEN" "" "CHECK" 0 ""
"L_Packer-RedskinC1" "BRANCH 12 18 1" "OPEN" "" "CHECK" 0 ""
"L_Raven-RoughriderC2" "BRANCH 15 54 2" "OPEN" "" "CHECK" 0 ""
"L_Raven-RoughriderC3" "BRANCH 15 54 3" "OPEN" "" "CHECK" 0 ""
"L_Raven-RoughriderC1" "BRANCH 15 54 1" "OPEN" "" "CHECK" 0 ""
"T_Roughrider-StampederC1" "BRANCH 54 53 1" "OPEN" "" "CHECK" 0 ""
"T_Packer-BrownC2" "BRANCH 12 40 2" "OPEN" "" "CHECK" 0 ""
"T_Packer-BrownC1" "BRANCH 12 40 1" "OPEN" "" "CHECK" 0 ""
"L_Packer-SteelerC1" "BRANCH 12 27 1" "OPEN" "" "CHECK" 0 ""
"L_Bear-JetC1" "BRANCH 20 48 1" "OPEN" "" "CHECK" 0 ""
"L_Patriot-BomberC1" "BRANCH 13 55 1" "OPEN" "" "CHECK" 0 ""
"L_Bronco-BillC1" "BRANCH 5 44 1" "OPEN" "" "CHECK" 0 ""
"L_49er-BrownC1" "BRANCH 3 40 1" "OPEN" "" "CHECK" 0 ""
"L_Chief-EskimoC1" "BRANCH 33 50 1" "OPEN" "" "CHECK" 0 ""
"L_Cowboy-CardinalC1" "BRANCH 31 38 1" "OPEN" "" "CHECK" 0 ""
"L_Buccaneer-RaiderC1" "BRANCH 30 41 1" "OPEN" "" "CHECK" 0 ""
"L_Packer-ColtC1" "BRANCH 12 17 1" "OPEN" "" "CHECK" 0 ""
"L_Lion-TitanC1" "BRANCH 35 39 1" "OPEN" "" "CHECK" 0 ""
"L_Bengal-SteelerC1" "BRANCH 16 27 1" "OPEN" "" "CHECK" 0 ""
"L_Colt-GiantC1" "BRANCH 17 19 1" "OPEN" "" "CHECK" 0 ""
"L_Redskin-EagleC1" "BRANCH 18 37 1" "OPEN" "" "CHECK" 0 ""

```



```

"L_Redskin-EagleC2" "BRANCH 18 37 2" "OPEN" "" "CHECK" 0 ""
"L_Bear-ChargerC1" "BRANCH 20 34 1" "OPEN" "" "CHECK" 0 ""
"L_Roughrider-BomberC1" "BRANCH 54 55 1" "OPEN" "" "CHECK" 0 ""
"L_Bear-EskimoC1" "BRANCH 20 50 1" "OPEN" "" "CHECK" 0 ""
"L_Saint-JetC1" "BRANCH 21 48 1" "OPEN" "" "CHECK" 0 ""
"L_Saint-JetC2" "BRANCH 21 48 2" "OPEN" "" "CHECK" 0 ""
"L_Bronco-RedskinC1" "BRANCH 5 18 1" "OPEN" "" "CHECK" 0 ""
"L_Raven-RamC1" "BRANCH 15 24 1" "OPEN" "" "CHECK" 0 ""
"L_Dolphin-RaiderC1" "BRANCH 29 41 1" "OPEN" "" "CHECK" 0 ""
"L_Panther-DolphinC1" "BRANCH 32 29 1" "OPEN" "" "CHECK" 0 ""
"L_Raven-BengalC1" "BRANCH 15 16 1" "OPEN" "" "CHECK" 0 ""
"L_Cowboy-VikingC1" "BRANCH 31 28 1" "OPEN" "" "CHECK" 0 ""
"L_Argonaut-DolphinC1" "BRANCH 56 29 1" "OPEN" "" "CHECK" 0 ""
"L_Buccaneer-PantherC1" "BRANCH 30 32 1" "OPEN" "" "CHECK" 0 ""
"T_Viking-DolphinC2" "BRANCH 28 29 2" "OPEN" "" "CHECK" 0 ""
"T_Lion-CowboyC1" "BRANCH 35 31 1" "OPEN" "" "CHECK" 0 ""
"L_Texan-BillC1" "BRANCH 14 44 1" "OPEN" "" "CHECK" 0 ""
"T_Chief-PantherC1" "BRANCH 33 32 1" "OPEN" "" "CHECK" 0 ""
"T_Viking-DolphinC1" "BRANCH 28 29 1" "OPEN" "" "CHECK" 0 ""
"L_Ram-BillC1" "BRANCH 24 44 1" "OPEN" "" "CHECK" 0 ""
"L_Lion-ArgonautC1" "BRANCH 35 56 1" "OPEN" "" "CHECK" 0 ""
"T_Titan-CardinalC1" "BRANCH 39 38 1" "OPEN" "" "CHECK" 0 ""
"T_Titan-CardinalC2" "BRANCH 39 38 2" "OPEN" "" "CHECK" 0 ""
"L_Titan-BrownC1" "BRANCH 39 40 1" "OPEN" "" "CHECK" 0 ""
"L_Titan-JaguarC1" "BRANCH 39 47 1" "OPEN" "" "CHECK" 0 ""
"T_Bill-RaiderC1" "BRANCH 44 41 1" "OPEN" "" "CHECK" 0 ""
"T_Bill-RaiderC2" "BRANCH 44 41 2" "OPEN" "" "CHECK" 0 ""
"T_Jet-JaguarC1" "BRANCH 48 47 1" "OPEN" "" "CHECK" 0 ""
"L_Jaguar-StampederC1" "BRANCH 47 53 1" "OPEN" "" "CHECK" 0 ""
"L_Jet-RoughriderC1" "BRANCH 48 54 1" "OPEN" "" "CHECK" 0 ""
"L_Texan-ChargerC1" "BRANCH 14 34 1" "OPEN" "" "CHECK" 0 ""
"L_Falcon-GiantC1" "BRANCH 10 19 1" "OPEN" "" "CHECK" 0 ""
"L-2_Dolphin-Panther/Dolphin-Raider" "BRANCH 32 29 1" "OPEN" "" "CHECK" 0 ""
"L-2_Dolphin-Panther/Dolphin-Raider" "BRANCH 29 41 1" "OPEN" "" "CHECK" 0 ""
"L_49er-RaiderC1" "BRANCH 3 41 1" "OPEN" "" "CHECK" 0 ""
"T_Seahawk-BrownC1" "BRANCH 1 40 1" "OPEN" "" "CHECK" 0 ""
"L-2_Cowboy-Cardinal\Cowboy-Seahawk" "BRANCH 31 38 1" "OPEN" "" "CHECK" 0 ""
"L-2_Cowboy-Cardinal\Cowboy-Seahawk" "BRANCH 1 31 1" "OPEN" "" "CHECK" 0 ""
"L_Seahawk-CowboyC1" "BRANCH 1 31 1" "OPEN" "" "CHECK" 0 ""
}

```