

Steady-State Power System Security Analysis with PowerWorld Simulator



S6: Voltage Stability Using PV Curves



PowerWorld
Corporation

2001 South First Street
Champaign, Illinois 61820
+1 (217) 384.6330

support@powerworld.com
<http://www.powerworld.com>

Voltage Stability Concepts



- Voltage stability is the ability of a power system to maintain acceptable voltage at all buses under normal operating conditions and after being subjected to a contingency
- Voltage stability is a local phenomenon, but its consequences may have a widespread impact
 - A local voltage collapse can and does lead to a widespread collapse of the power system

Voltage Stability Studies



- Characteristics of interest are the relationships between transmitted power (P), receiving end voltage (V), and reactive power injection (Q)
- Traditional forms of displaying these relationships are PV and QV curves obtained through steady-state analysis
- V-Q sensitivities can also be used as indicators of voltage stability

PV Study




- The “PV” (Power-Voltage) analysis process involves using a series of power flow solutions for increasing transfers of MW and monitoring what happens to system voltages as a result
- Relationship of voltage to MW transfer is non-linear, which requires the full power flow solutions

PV Study



- Traditionally, MW transfer is designed to model increasing load in a part of the system
- Specific buses must be selected for monitoring and PV curves are plotted for each bus

Typical PV Curve Plot



PV Curve Results



- At the “knee” of the PV curve, voltage drops rapidly with an increase in MW transfer
- The power flow solution fails to converge beyond this limit, which is indicative of instability
 - You may remember the term “Maximum Power Transfer” from electrical engineering courses. This is the same topic.
- Operation at or near the stability limit risks a large-scale blackout
 - A satisfactory operating condition is ensured by allowing sufficient “power margin”

PV Curve Example



- Use the MAIN 10,452 bus example
 - *Midwest.RAW*
 - *Midwest Injection Groups.aux*
 - *Midwest PV Options.aux*
 - *ARPINCTG.aux*
- We will study a transfer of power from generators in MAPP to an increasing Wisconsin load
- First step - define an injection group containing MAPP generators to serve as the source

Injection Groups




- *Injection Groups* in Simulator PVQV define which region or regions will import the transfer and which region or regions will supply it
- These are discussed in section I5: Data Aggregation
- The groups will act in unison to implement a power transfer
- One side is the source - the other is the sink

Defining Injection Groups



- Select **Aggregations** → **Injection Groups** from the Model Explorer
- Presently reads *None Defined*. Right click and select **Insert** from the local menu.
- Rename the group MAPP (default: DefaultIG1)
- This opens the following display




The screenshot shows the 'Injection Groups' dialog box. The 'Name' field is set to 'MAPP'. The 'Participation Points' tab is selected, and the 'Custom' sub-tab is active. The 'Insert Points' button is highlighted. The dialog box contains several input fields for parameters like '# Gens', '# Loads', '# Shunts', and various percentage values. At the bottom, there is a table with columns for 'Point Type', 'Number', 'Name', 'ID', 'AutoCalc?', 'Initial Value', and 'ParFac'. The table currently shows one row with 'None' in the 'Point Type' column and 'Defined' in the 'Number' column. The 'Rename' button is highlighted with a red dashed border.

Point Type	Number	Name	ID	AutoCalc?	Initial Value	ParFac
None	Defined					

Defining Participation Points



- Now add the points of injection to the group
- To do this, click **Insert Points** or choose **Records** → **Insert** on the Participation Points list
- This opens the dialog below



Use Filters to Choose Points



- Click the button **Edit Area/Zone Filters**
- Set all areas to *No* except MAPP
- Close the Area/Zone Filters display
- Check the box **Use Area/Zone Filters**
- The list of generators will now only show those generators which are in MAPP

Defining Participation Points



- Select all the generators in the list by clicking the button **Select All**
- For this example, assume all generators will participate proportional to their MW reserves
 - Therefore, select **Base on Positive Reserve**
- Use **Add ->** key to move the selected generators into the participation point list

Defining Participation Points



- Each generator will have a participation factor calculated for it based on the method of calculation selected, or will use the pre-defined values
- In this case, the participation factors will be proportional to the MW reserves
- Hit **OK** to add points to injection group

Define the Sink Group



- Process is very similar
- Change area/zone filters so that only areas 64-67 (WPL, WEP, WPS, and MGE) are set to YES
- Open Injection Groups display again. Select **Records → Insert**
- Call this group *WUMS*
- Choose **Insert Points** or **Records → Insert**
- Switch to Load Tab, because we want the loads to serve as injection points

Define the Sink Group



- Select all the loads in the list
- Use **Base on Size** to calculate the participation factor, so that the larger loads will participate more heavily in the transfer
- Click the **Add ->** button to move loads into the list

Points for Injection Group WUMS

Sort by Name Number

LOAD	12TH AVE	(38635)	#1	9.5020
LOAD	1ST AVE	(38574)	#1	13.4000
LOAD	20S 138	(39230)	#1	21.1150
LOAD	28 ST 1	(38535)	#1	18.6310
LOAD	28 ST 1	(38537)	#1	23.2880
LOAD	28 ST 2	(38536)	#1	23.2880
LOAD	28 ST 2	(38538)	#1	27.9460
LOAD	30TH AVE	(38625)	#1	8.3690
LOAD	4TH AVE	(38622)	#1	16.8130
LOAD	68 ST 7	(38522)	#1	54.3640
LOAD	68 ST 8	(38523)	#1	48.4330
LOAD	96TH 12	(38486)	#1	128.5610
LOAD	A03 138	(39236)	#1	3.8190
LOAD	ABY	(38849)	#1	4.5930
LOAD	ACA 69	(38216)	#99	43.8360
LOAD	ACC/JRT	(38850)	#1	5.2420
LOAD	AL DE NA	(39129)	#1	0.6440
LOAD	ALA CITY	(38581)	#1	9.0000

Saving the groups



- We have now defined a set of source and sink points. The PV study will model an increasing transfer from source to sink.
- This procedure involved a lot of steps, so you don't want to have to redefine the groups for a slightly different case



To save the injection groups, select an injection group and use the Save Auxiliary Menu

- This will save the groups in a text file along with any other auxiliary data you may have
- The data can then be loaded into a different case as needed

Contingency Definition



- In addition to analyzing the system for its current topology, you may want to examine a specific set of contingencies
- Simulator's contingency analysis is fully integrated into the PVQV package to allow you to gauge the impact of contingencies
- To define a contingency list, go to **Tools** → **Contingency Analysis**

Contingency Definition



- For this example, we will use a pre-defined contingency called WPS-ARP2e which is a common contingency in the MAIN list

```
OPEN Branch ARP 345 (39244) TO EAU CL 3 (61853) CKT 1  
OPEN Branch WIEN (39706) TO T-CRNR57 (61866) CKT 1
```

- Also only monitor the regions in MAIN
 - Open **Tools** → **Limit Monitoring Settings and Violations**
 - Go to the Area Reporting tab
 - Set MAIN areas to Report Limits = YES. (Areas 56-68). Set all other areas to NO.
- The file *ARPINCTG.AUX* contains the contingency definition and the Area Monitoring Settings

Performing a PV Curve Study: Open the PV Study



- We are finally ready to perform the PVQV study. Select **Add Ons** ribbon tab → **PV Curves**.
- This form is organized in a series of pages, that are arranged in the order they should be considered
- We will use this form to set up a transfer from MAPP to WUMS

Setup: Common Options

Transfer Definition



- Under Source, click on the drop-down box and select *MAPP*, our predefined injection group
- Under Sink, select *WUMS*
- You can also define these groups from this dialog by selecting **View/Define Groups**

Setup: Common Options



The screenshot shows the PV CURVES software interface. The main window is titled "Setup" and has a sidebar on the left with a tree view containing the following items: Setup, Common Options (highlighted), Injection Group Ramping Options, Interface Ramping Options, Advanced Options, Quantities to track, Limit violations, PV output, QV setup, PV Results, and Plots.

The main content area is divided into several sections:

- Ramping Method:** Includes radio buttons for "Injection Group Source/Sink" (selected) and "Interface MW Flow".
- Transfer power between the following two groups:** Includes dropdown menus for "Source" (MAPP) and "Sink" (WUMS), and a "View / Define Groups" button.
- Common Options:** A tabbed section with sub-tabs for "Common Options", "Injection Group Ramping Options", "Interface Ramping Options", and "Advanced Options".
 - Critical Scenarios:** A text box containing "Stop after finding at least 1 critical scenarios".
 - Base Case and Contingencies:** Includes checkboxes for "Skip contingencies" (with a "Manage contingency list ..." button) and "Run base case to completion" (with a "Base Case Solution Options ..." button).
 - Vary the transfer as follows:** Includes input fields for "Initial Step Size (MW)" (100.00), "Minimum Step Size (MW)" (10.00), and "When convergence fails, reduce step by a factor of" (2.00). There is also a checkbox for "Stop when transfer exceeds" with a value of 0.00.

At the bottom of the window, there are buttons for "Save Auxiliary ...", "Load Auxiliary ...", "Launch QV curve tool ...", "? Help", and "Close".

Setup: Common Options

Vary transfer options



- Initial Step Size
 - The rate at which transfer will increase initially
 - **100 MW for example**
- Minimum Step Size
 - Whenever Simulator fails to converge at a particular transfer level, it will return to the previous one and use a smaller increase. This is the minimum.
 - **10 MW for example**
- Reduce step by a factor of
 - Amount Simulator will reduce the transfer by in case of non-convergence (Not MWs)
 - **2 for example**
- Stop when transfer exceeds
 - When checked, the PV analysis will stop after a specified MW transfer level has been achieved
 - **Unchecked for example**

Setup:

Injection Group Ramping Options



The screenshot displays the 'PV CURVES' software interface. The main window is titled 'Setup' and contains several tabs: 'Common Options', 'Injection Group Ramping Options', 'Interface Ramping Options', and 'Advanced Options'. The 'Injection Group Ramping Options' tab is active, showing the following settings:

- Ramping Method:** Injection Group Source/Sink, Interface MW Flow
- Transfer power between the following two groups:**
 - Source: MAPP
 - Sink: WUMS
- View / Define Groups:** Button
- Injection Group Options:**
 - Island-Based AGC Tolerance: 5.0000
 - Allow only AGC units to vary
 - Enforce unit MW limits
 - Do not allow negative loads
 - Generator Merit Order Dispatch:**

	Use	Use Economic
Source	<input type="checkbox"/>	<input type="checkbox"/>
Sink	<input type="checkbox"/>	<input type="checkbox"/>

(Enabled injection group-specific scaling options will override these options. Injection group-specific options do not include the AGC Tolerance.)

At the bottom of the window, there are buttons for 'Save Auxiliary ...', 'Load Auxiliary ...', 'Launch QV curve tool ...', 'Help', and 'Close'.

Setup:

Injection Group Ramping Options



- Island-Based AGC Tolerance
 - Tolerance used in the MW control loop when solving the power flow during implementation of the transfer
 - General rule of thumb is that Minimum Step Size should be at least 1 to 2 times larger than this value
 - Simulator will modify this so that MVA convergence tolerance < AGC Tolerance < Minimum Step Size
 - **5 MW for example**
- Allow only AGC units to vary
 - In Simulator each unit may be on or off of AGC. If this box is checked only those set on AGC can vary.
 - **Unchecked for example**

Setup:

Injection Group Ramping Options



- Enforce unit MW limits
 - When checked generators will only participate in the transfer if they are within their min/max MW limits
 - **Unchecked for example**, so we may examine the transfer capacity regardless of reserve in MAPP
- Do not allow negative load
 - When this box is checked, loads will be prevented from being set below zero
 - **Unchecked for example**
- Generator Merit Order Dispatch
 - When in use, each individual generator will be moved to its min/max in succession in order of descending participation factor (as set in its injection group participation point)
 - Can choose to do this for the source only, sink only, or both
 - Can also choose to Use Economic merit order dispatch to maintain units within an Economic Min/Max
 - **Unchecked for this example**

Setup: Common Options



- Stop after finding at least ... critical scenarios
 - Minimum number of critical scenarios that will be found
 - **1 for example**
- Skip Contingencies
 - Check this box to run the analysis for the base case only
 - **Unchecked for example**
- Run Base Case to Completion
 - When checked, the critical transfer point is found for the base case in addition to the number of specified critical scenarios
 - **Unchecked for example**

Setup: Advanced Options



PV CURVES

Setup

Ramping Method

- Injection Group Source/Sink
- Interface MW Flow

Transfer power between the following two groups:

Source: MAPP

Sink: WUMS

View / Define Groups

Common Options | Injection Group Ramping Options | Interface Ramping Options | **Advanced Options**

How should reactive power load change during ramping?

- Maintain the MW/MVAR ratio at each load, but then scale MVAR by a factor of 1.0000
- As MW changes, change the MVAR at a power factor of 1.0000

(If enabled, injection group specific scaling options will override these options.)

Reverse Transfer

- Apply Reverse Transfer
- Maximum Reverse Transfer (MW > 0): 1000.00

Load Component Variation

- All changes apply to constant power (S MW, S MVAR)
- Vary in proportion to existing Z,I,P ratios
- Vary using proportions specified below:

	P (MW)		Q (MVAR)	
	Source	Sink	Source	Sink
Power (S)	1.00	1.00	1.00	1.00
Current (I)	0.00	0.00	0.00	0.00
Impedance (Z)	0.00	0.00	0.00	0.00

Save Auxiliary ... Load Auxiliary ... Launch QV curve tool ... ? Help Close

pfQMult

pf_{specified}

Each column must sum to 1

Setup: Advanced Options



- How should reactive power load change during ramping?
 - Maintain the MW/MVAR ratio at each load, but then scale MVAR by a factor of

$$pf = \cos \left(\tan^{-1} \left(\frac{Q_{Existing}}{P_{Existing}} \right) \right)$$

$$\Delta Q = \tan \left(\cos^{-1} (pf) \right) * \Delta P * pfQMult$$

- As MW changes, change the MVAR at a power factor of

$$\Delta Q = \tan \left(\cos^{-1} \left(pf_{specified} \right) \right) * \Delta P$$

Setup: Advanced Options



- Load Component Variation
 - Total load (P,Q) at a load can be specified as the sum of constant power (S), constant current (I), and constant impedance components (Z)
 - Constant current and constant impedance components are both functions of voltage at the bus
 - These options determine the proportion of the load change that each component receives

Setup: Advanced Options



- Load Component Variation

- All changes apply to constant power (S MW, S MVAR)

$$\Delta P_S = \Delta P, \Delta P_I = 0, \Delta P_Z = 0, \Delta Q_S = \Delta Q, \Delta Q_I = 0, \Delta Q_Z = 0$$

- Vary in proportion to existing Z,I,P ratios

- Existing ratios determined based on the existing total nominal load (P_{nom}, Q_{nom}) prior to any change due to the transfer

$$k_{PS} = \frac{P_{nomS}}{P_{nom}}, k_{PI} = \frac{P_{nomI}}{P_{nom}}, \dots, k_{QS} = \frac{Q_{nomS}}{Q_{nom}}, \dots, k_{QZ} = \frac{Q_{nomZ}}{Q_{nom}}$$

- Ratios are multiplied by the total nominal load change to calculate the nominal load change for each component

$$\Delta P_{nomS} = k_{PS} * \Delta P_{nom}, \Delta P_{nomI} = k_{PI} * \Delta P_{nom}, \dots, \Delta Q_{nomS} = k_{QS} * \Delta Q_{nom} \dots$$

Setup: Advanced Options



- Load Component Variation

- Vary in proportion to existing Z,I,P ratios

- The total nominal power change is determined based on the total real power change required due to the transfer, the calculated ratios, and present voltage at a bus

$$\Delta P_{nom} = \frac{\Delta P}{k_{PS} + k_{PI} * V + k_{PZ} * V^2}$$

- Change in nominal reactive power is determined based on the option selected for how reactive power should change during the transfer

Setup: Advanced Options



- Load Component Variation
 - Vary using proportions specified below
 - Proportions are grouped by real and reactive power and then source or sink
 - Proportions for each group must sum to 1 so that component changes sum to the total load change
 - Same calculations as option to use existing Z,I,P ratios except that the ratios are user-specified
- Apply Reverse Transfer
 - For any contingency that does not solve in the base case, apply a transfer from the Sink to the Source in an attempt to find a solution
 - Must specify the Maximum Reverse Transfer because it is possible that a solvable point will not be found

Interface MW Flow Ramping Method



The screenshot displays the 'PV CURVES' software window. On the left is a tree view with the following items: Setup (expanded), Common Options, Injection Group Ramping Options, Interface Ramping Options (highlighted), Advanced Options, Quantities to track, Limit violations, PV output, QV setup, PV Results, and Plots. The main area is titled 'Setup' and contains several configuration options:

- Ramping Method:** Two radio buttons are present: 'Injection Group Source/Sink' (unselected) and 'Interface MW Flow' (selected).
- Interface X:** A dropdown menu set to 'AEP-CIN' with a 'Find...' button.
- Use Interface Y:** A checked checkbox.
- Interface Y:** A dropdown menu set to 'AEP-CIPS' with a 'Find...' button.
- Angle:** A numeric spinner set to '0.00'.

Below these options are four tabs: 'Common Options', 'Injection Group Ramping Options', 'Interface Ramping Options' (active), and 'Advanced Options'. The active tab contains:


- Use Interface Z:** A checked checkbox.
- Interface Z:** A dropdown menu set to 'AEP-IP' with a 'Find...' button.
- MW Setpoint:** A numeric spinner set to '100'.

At the bottom of the window are five buttons: 'Save Auxiliary ...', 'Load Auxiliary ...', 'Launch QV curve tool ...', a 'Help' button with a question mark icon, and a 'Close' button with a window icon.

Interface MW Flow Ramping Method




- Requires the OPF add-on
- Ramps transfer by increasing flow on 1 or 2 interfaces
 - Search direction determined by **Step Size** and **Angle**
- Optional constraint to maintain flow on a third interface



Quantities to Track



- On the **Quantities to track** page, there are several sub pages that allow you to track values for various devices
-  Let's monitor the following bus voltages (use the Find button):
 - ARP 138 (39245)
 - SPG 138 (39114)
- And this line's MVA
 - 39244 (ARP 345) to 61853 (EAU CL 3) circuit 1. Monitor in the direction (TO-FROM)
- Search for the fields and toggle to change values

Quantities to Track



PV CURVES

- Setup
 - Common Options
 - Advanced Options
- Quantities to track
 - Buses**
 - Generators
 - Groups
 - Lines
 - Transformers
 - Shunts
 - Interfaces
 - Case
 - Devices At Limits
- Limit violations
- PV output
- QV setup
- PV Results
- Plots

Quantities to track

Note: Any quantities which are defined as part of a plot on the New Plots area will also result in that quantity being tracked.

Buses Generators Groups Lines Transformers Shunts Interfaces Case Devices At Limits

	Number	Name	Nom kV	Voltage?	kV Voltage?	Angle?	MW Load?	Mvar Load?	dV
1	39114	SPG 138	138.00	YES	NO	NO	NO	NO	NO
2	39245	ARP 138	138.00	YES	NO	NO	NO	NO	NO
3	24	LIMERICK	500.00	NO	NO	NO	NO	NO	NO
4	13	PEACHBTM	500.00	NO	NO	NO	NO	NO	NO
5	32	KEYS G1	22.00	NO	NO	NO	NO	NO	NO
6	33	KEYS G2	22.00	NO	NO	NO	NO	NO	NO
7	35	PCHBTM 3	22.00	NO	NO	NO	NO	NO	NO
8	249	SENECA#1	13.80	NO	NO	NO	NO	NO	NO
9	36	SALEM G1	22.00	NO	NO	NO	NO	NO	NO
10	19	BURCHES	500.00	NO	NO	NO	NO	NO	NO
11	38	SUSQ 2	24.00	NO	NO	NO	NO	NO	NO
12	39	HOPE CG1	22.00	NO	NO	NO	NO	NO	NO
13	40	C CLF1	25.00	NO	NO	NO	NO	NO	NO
14	41	C CLF2	22.00	NO	NO	NO	NO	NO	NO

Modify Existing Bus Tracking to Track Only Single Bus Per Super Bus

Note: The active defined contingencies affect the selection of super buses and resulting tracked buses.

Include ATC Extra Monitors

Warning: Do not track too many quantities. Simulator stores all the data in memory in your computer. If you track too much you will run out of

Save Auxiliary ... Load Auxiliary ... Launch QV curve tool ... ? Help Close

Quantities to Track: Devices At Limits



- Can track devices that hit or back off limits during the analysis
 - Limits are only tracked during the base case ramping and not during contingencies
- Generator var, switched shunt var, LTC transformer tap, line thermal, and interface thermal limits can be tracked
- Limit the amount of elements that are tracked by defining filters for each type of element tracked

Limit Violations



The screenshot shows the 'PV CURVES' software window with the 'Limit violations' tab selected. The left sidebar contains a tree view with the following items: Setup, Quantities to track, Limit violations (highlighted), PV output, QV setup, PV Results, and Plots. The main panel is titled 'Limit violations' and contains the following settings:

- Voltage Violations**
 - Identify bus voltages with ...
 - Low Voltage Violations
 - Always Report Lowest Voltage
 - High Voltage Violations
 - To change the pu limits, see Limit Group Definitions
 - [Limit Group Definitions ...](#)
- Inadequate voltage level**
 - Stop when voltage becomes inadequate
 - Store inadequate voltages
 - Interpolate inadequate voltages
 - Voltage Level to consider inadequate**
 - Specify voltage for all buses in pu: 0.00001
 - Use Low Voltage Violation Limits for each bus
 - Use a specified Low Voltage Limit Set: A
 - Do not consider radial buses to have inadequate voltage (including buses that become radial due to a contingency)
- Negative dV/dQ Sensitivities**
 - Stop when dV/dQ sensitivities become negative

At the bottom of the window, there are buttons for 'Save Auxiliary ...', 'Load Auxiliary ...', 'Launch QV curve tool ...', 'Help', and 'Close'.

Limit Violations



- Use the **Identify Bus Voltage Violations with...** section to tell the PV tool to keep track of buses that violate their voltage limits as of the last successful solution for each scenario
 - Low Voltage Violations
 - Always Report Lowest Voltage will report a voltage even if it does not violate a low voltage limit
 - High Voltage Violations
- Selecting either one of the two voltage violation boxes will make available a few tools and fields on the **Overview** table on the **PV Results** page

Limit Violations



- Limit Monitoring Settings determine which buses are monitored and how high and low voltage violations are identified for each bus
 - **Limit Group Definitions...** button will open the **Limit Monitoring Settings** dialog
- Inadequate voltage level
 - Stop when voltage becomes inadequate
 - A scenario will be judged critical once any monitored voltage falls below the inadequate voltage level
 - Store inadequate voltages
 - Keeps track of inadequate voltages without considering a scenario to be critical
 - Interpolate inadequate voltages
 - Allows linear estimation of where a voltage becomes inadequate without having to reduce the step size in order to exactly determine when a voltage becomes inadequate

Limit Violations



- Inadequate Voltage Level
 - Specify voltage level to consider inadequate
 - Specify voltage for all buses
 - Use Low Voltage Violation Limits for each bus
 - Use a specified Low Voltage Limit Set
 - Do not consider radial buses to have inadequate voltage
 - Buses that are connected by only a single in-service branch are considered radial. If buses are connected by more than one branch, all but one of the branches is open.
 - Buses that are radial for a given scenario, even those that become radial due to a contingency, will not be monitored
 - Limit Monitoring Settings option to not monitor radial lines and buses will exclude from monitoring those buses that are connected by a single branch in the base case

PV Output

Save results to file



- Simulator records the value of each monitored quantity at each transfer level for each contingency being studied
- Data only present in memory unless storage file and location specified
- Save results to file
 - Check and specify the file path and name
 - Results stored with transfer level in rows and tracked quantities in columns
 - Comma-separated file regardless of file extension chosen
 - For this example, choose file *c:\temp\voltage.txt*
- Transpose results
 - Results stored with tracked quantities in rows and transfer levels in columns
- Single Header File
 - Only a single header is shown at the top of the file rather than repeating the header at the start of each scenario section

PV Output State Archiving



- Entire system can be saved during the analysis
- Directory and prefix must be specified to help in distinguishing between separate PV runs
- Can save as PWB, AUX, or both
- This can require significant disk space, but can be quite helpful to examine a particular transfer level
- Save only the base case for each critical contingency
 - Base case without contingency but with critical transfer level implemented will be saved for each critical scenario
- Save all states
 - All states at each valid transfer will be saved
 - Non-critical states will be saved with contingency implemented. Only base case saved at the critical transfer level.
 - Base case state without contingency implemented will be saved for all scenarios at all transfer levels at which that scenario will solve

Save/Load Auxiliary Options



- This form has a large number of options
- These do not have to be set every time - just use the **Save Auxiliary** button at the bottom of the form to transfer options between case
- Options are saved in Simulator's Auxiliary File format
- You may also load options back in by choose the **Load Auxiliary** button

PV Results

Performing the Analysis

- Go to the PV Results page to initiate the PV Curve analysis. Click **Run** to begin.

The screenshot shows the PV CURVES software interface. The left sidebar contains a navigation tree with the following items: Setup, Quantities to track, Limit violations, PV output, QV setup, PV Results (selected), and Plots. The main window is titled 'PV Results' and contains the following elements:

- Run** and **Stop** buttons.
- A status bar indicating **Processing scenario WPS-ARP2E**.
- Input fields for **Present nominal shift** (1700.000) and **Present step size** (100.000).
- A table showing power generation and load data:

	Gen MW	Load SMW	Load IMW	Load ZMW
Source	33116.93	0.00	0.00	0.00
Sink	0.00	12006.91	0.00	0.00

Buttons for **View detailed results** and **Other actions >>** are also present.

Below the data table, there is a section for **Overview**, **Legacy Plots**, and **Track Limits**. The **Overview** section contains a table of PV scenarios:

	PV Scenario	Critical?	Critical Reason	Max Shift	Max Export	Max Imp
1	base case	NO				
2	WPS-ARP2e	NO				

The bottom of the interface features a toolbar with buttons for **Save Auxiliary ...**, **Load Auxiliary ...**, **Launch QV curve tool ...**, **Help**, and **Close**.

PV Results

Overview, Plot



- When the PV run is completed, the **Overview** list display will show a summary of the results
- Critical scenarios (contingencies) are identified along with information about the critical buses and maximum achieved transfer levels
- Plots of tracked quantities can be made from the **Legacy Plots** tab or **Plots** page
- System state is left at the transfer level of the last studied critical scenario with any contingency restored

PV Results

Legacy Plots Tab



- Once the PV tool has completed running, you may plot the results using the Legacy Plots tab of the PV Results page

The screenshot shows the 'PV CURVES' application window with the 'Legacy Plots' tab selected. The interface includes a 'Run' button, a status message 'There are no more limiting cases left to find.', and a table of power flow data. The 'Legacy Plots' section has three sub-tabs: 'Overview', 'Legacy Plots', and 'Track Limits'. The 'Legacy Plots' sub-tab is active, showing options for 'Horizontal axis value' (Nominal Shift), 'Vertical axis value type' (PU Volt), and a table for 'Plot values for these elements'. A 'Plot title' field is at the bottom, and a 'Plot' button is on the right. Callouts with arrows point to various elements: 'Choose Horizontal Axis and Vertical Axis values' points to the axis selection dropdowns; 'For vertical axis, choose which elements to plot with selected values' points to the 'Plot?' column in the table; 'Enter a title for the plot' points to the 'Plot title' field; 'Choose which contingencies to include on the plot' points to the 'Plot?' column in the 'For these scenarios...' table; and 'Click to show the plot' points to the 'Plot' button.

Source	Gen MW	Load SMW	Load IMW	Load ZMW
33464.44	0.00	0.00	0.00	
Sink	0.00	12163.56	0.00	0.00

Horizontal axis value	Vertical axis value type	Plot values for these elements ...						
Nominal Shift	PU Volt							
		<table border="1"><thead><tr><th>Description</th><th>Plot?</th></tr></thead><tbody><tr><td>SPG 138 _138.0 (39114)</td><td>YES</td></tr><tr><td>ARP 138 _138.0 (39245)</td><td>YES</td></tr></tbody></table>	Description	Plot?	SPG 138 _138.0 (39114)	YES	ARP 138 _138.0 (39245)	YES
Description	Plot?							
SPG 138 _138.0 (39114)	YES							
ARP 138 _138.0 (39245)	YES							

PV Scenario	Critical?	Plot?
base case	NO	NO
WPS-ARP2e	YES	YES

Choose Horizontal Axis and Vertical Axis values

For vertical axis, choose which elements to plot with selected values

Enter a title for the plot

Choose which contingencies to include on the plot

Click to show the plot

PV Results

Legacy Plots Tab




- The plot tab allows the user to plot all of the values that were designated to be monitored during the analysis
- For example, we can plot the bus voltages vs. the size of the transfer
- For Horizontal-Axis, select *Nominal Shift*
- For Vertical-Axis, select *PU Volt*
- Select all the buses as elements
- Select all PV Scenarios
- Use appropriate title

PV Results

Example PV Curve



Notice the “jaggedness” of the plot. This is caused by the switched shunt and LTC transformer control actions trying to pull the voltages up.
Traditionally when performing PV runs, one should disable this control switching.



Build Date: August 16, 2010

PV Results

Track Limits



PV CURVES

PV Results

Run Stop

There are no more limiting cases left to find.

Present nominal shift: 2050.000

Present step size: []

	Gen MW	Load SMW	Load IMW	Load ZMW
Source	33464.44	0.00	0.00	0.00
Sink	0.00	12163.56	0.00	0.00

View detailed results

Other actions >>

Found 1 limiting case.

Overview Legacy Plots Track Limits

Filter out devices that never hit or backoff a limit during the PV run

Generator Var Limits (Filter:Generators in..) Shunt Var Limits LTC Var Limits Line Thermal Limits Interface Thermal Limits

	Number of Bus	Name of Bus	ID	0.00	100.00	200.00	300.00	400.00	500.00
1	38070	TUR G4	4	Within Range	Within Range	Within Range	Within Range	Within Range	Within Range
2	38109	SPU G1	1	Within Range	Within Range	Within Range	Within Range	Within Range	Within Range
3	38176	PDS G1	1	Within Range	Within Range	Within Range	Within Range	Within Range	Within Range
4	38177	PDS G2	2	Within Range	Within Range	Within Range	Within Range	Within Range	Within Range
5	38301	KIL G1	1	Within Range	Within Range	Within Range	Within Range	Within Range	Within Range
6	38330	CAR G1	1	Within Range	Within Range	Within Range	Within Range	Within Range	Within Range
7	38490	OC GT9	9	Within Range	Within Range	Within Range	Within Range	Within Range	Within Range
8	38497	POB GT5	5	Within Range	Within Range	Within Range	Within Range	Within Range	Within Range
9	38549	KAU CEN	1	At Max	At Max	At Max	At Max	At Max	At Max

Save Auxiliary ... Load Auxiliary ... Launch QV curve tool ... Help Close

PV Results

Other actions



- View activity log
 - Outlines step-by-step the activities the PV tool performed during the run
- View detailed results
 - Opens a text file that contains the detailed results including the values of the tracked quantities at each step for each scenario
- Clear results
 - Purges the currently stored results from memory
- Restore Initial State
 - Brings back the case that was in memory prior to the PV run
- Restore Last Solved State
 - Brings back the solved power flow model that depicts the system at the largest transfer level that was studied. This is a base case state with no contingency implemented.

PV Results

Other actions



- Save critical contingencies
 - Saves contingency settings and records in an auxiliary file for each scenario where a critical state was reached
- Set current state as initial
 - Removes the case that was in memory at the beginning of the PV run and replaces it with what is currently in memory
- Start Over
 - Removes all results from memory, restores the initial case, and removes all entries from the activity log
- Run QV tool
 - Launches the QV tool using the case that is currently in memory as its basis

Time Saving Measures



- Only define a few contingencies - each contingency monitored can add significant time to the PV study
- Try to limit the number of Quantities to Track. There is no hard limit on this, but the amount of computer memory can become substantial if you try to monitor too much.

Plot Designer



PV CURVES
⌵ ⌶ ⌵

- ▷ Setup
- ▷ Quantities to track
- ... Limit violations
- ... PV output
- ... QV setup
- ▷ PV Results
 - ... Overview
 - ... Legacy Plots
 - ▷ Track Limits
- ▷ Plots
 - Plot Designer
 - ▷ Plot Definition Grids

Plots

Plot Designer Plot Definition Grids

Device Type: Bus

Choose Fields

- Angle (Deg)
- dV/dQ
- Load Mvar
- Load MW
- PU Volt
- Switched Shunts Mvar
- Volt (kV)
- VP Sensitivity

Add >>

Choose Objects

Sort by: Name Number

SPENCER7 (64263) [115 kV]

SPENCER8 (60581) [69 kV]

SPENCER9 (64264) [34.5 kV]

SPENCER 8 (60580) [69 kV]

SPG 138 (39114) [138 kV]

SPG 69 (38127) [69 kV]

SPGVTP 2 (57715) [69 kV]

SPIRI71G (60616) [13.8 kV]

SPIRI72G (60617) [13.8 kV]

Add >> Group Fields

Add >> Group Objects

Select All Clear All

Choose PV Scenarios to Plot

Generate Selected Plots Close All Plots

(1) Select the Device Type
(2) Select a set of fields and a set of objects
(3) Click the Add >> button

Plots, Subplots, Axis Groups

- └ Bus_PU Volt
 - ⚡ PU Volt _Bus 'ARP 138_138.00'
 - ⚡ PU Volt _Bus 'SPG 138_138.00'
- └ Add new plots here
 - ⚡ Add objects/field combinations

Add Plot Delete Plot

Collapse All Expand All

Save Plot Definitions to Auxiliary

Bus_PU Volt

MAPP-WUMS Transfer

- base case, PU Volt, Bus 'ARP 138_138.00'
- WPS-ARP2e, PU Volt, Bus 'ARP 138_138.00'
- base case, PU Volt, Bus 'SPG 138_138.00'
- WPS-ARP2e, PU Volt, Bus 'SPG 138_138.00'

MAPP-WUMS Transfer

PV Example

February 14, 2013 17:58:07

Blank Page