


Wind, Solar, and Other Renewable Generation Models in PowerWorld Simulator



2001 South First Street
Champaign, Illinois 61820
+1 (217) 384.6330

support@powerworld.com
<http://www.powerworld.com>

U.S. Annual and Cumulative Wind Power Capacity Growth




Note: Utility-scale wind capacity includes installations of wind turbines larger than 100-kW for the purpose of the AWEA U.S. Wind Industry Quarterly Market Reports. Annual capacity additions and cumulative capacity may not always add up due to decommissioned and repowered wind capacity. Wind capacity data for each year is continuously updated as information changes. AWEA did not track quarterly activity prior to 2008.

Modular Approach to Generator Modeling



- Industry has always used a modular approach for generator models
 - Machine
 - Exciter
 - Governor
 - Stabilizer
 - Under Excitation Limiter
 - Over Excitation Limiter
 - Relay Model
 - GP1, LHFRT, LHVRT
 - Compensator Model
 - Often is part of the machine model, but can also be a separate model
 - The old BPA IPF program models included this in the Exciter model

“Traditional” Synchronous Machine Modules




Modular Approach to Generator Modeling



- First generation wind turbine models stuck with this structure
 - Added additional signals to pass between modules
 - Don't get hung up on nomenclature "Exciter" just means the electrical control
- Unrelated to wind turbine modeling, another module was added for better modeling of large steam plants
 - LCFB1 – extra controller feeding the governor allowing control of P_{ref}


LCFB1 model: Controller for P_{ref}



First Generation Type 3 Wind Turbine (WT3G, WT3E, WT3T, WT3P)



2nd Generation will add more control features up here!



Limitations of First Generation Wind Models



- First Generation model had few mechanisms to provide control features of
 - Real Power or Torque Control
 - Reactive Power
 - Voltage Control
 - For First Generation models, the wind turbine basically tried to bring values back to the initial condition
 - Pref bring power back to initial Power
 - Qref or Vref or PowerFactorRec

Comparing First and Second Generation Models




- Many parts actually change very little
 - “Machine”: Voltage Source Converter model of the generator is nearly identical
 - WT3G/WT4G is pretty much same as REGC_A
 - “Governor”: Mechanical Model of wind turbine is identical
 - Combination of WTGT_A and WTGAR_A is *identical* to WT3T
 - “Stabilizer”: Pitch Control model has only a small addition
 - WT3P is pretty much same as WTGPT_A
- What’s Different – Control System Models
 - The WT3E and WT4E models essentially embedded voltage control and power control inside the model
 - This is now split into separate models
 - REEC_A: models only control with setpoints are as inputs to this model. Control features a little more flexible than the WT3E and WT4E models
 - WTGTRQ_A: control system resulting in the output of PRef
 - REPC_A : control system resulting in output of both a P and V/Q signal

First Generation Type 3 Wind Turbine (WT3G, WT3E, WT3T, WT3P)



2nd Generation will add more control features up here!




2nd Generation Type 3 Wind Turbine

(REGC_A, REEC_A, WTGT_A, WTGAR_A, WTGPT_A, WTGTRQ_A, REPC_A)



2nd Generation adds the Aero, PRef and Plant Controllers




© 2019 PowerWorld Corporation

11

First Generation Type 4 Wind Turbine (WT4G, WT4E, WT4T)



2nd Generation will add more control features up here!




Legacy "Governor" WT4T
This really acts like the new PRef controller

We will leave it in the toolbox as a "Governor" anyway

© 2019 PowerWorld Corporation


12

2nd Generation Type 4 Wind Turbine (REGC_A, REEC_A, WTGT_A, REPC_A)




Note: If REEC_A parameter Pflag = 0, then WTGT_A really doesn't do anything so it can be omitted completely

2nd Generation Solar Plant



**Used REEC_B Initially,
But actually don't anymore!
Go back to REEC_A**

2nd Generation Energy Storage



Use REEC_C

Software Implementation



- PowerWorld has kept the existing general classes of generator models
 - Machine (Generator/Converter Model)
 - Exciter (P and Q controller)
 - Governor (Drive Train)
 - Stabilizer (Pitch Control)
 - Relay Model
 - Under Excitation Limiter
 - Over Excitation Limiter
 - Compensator Model
- Added 3 new types of generator modules
 - Aerodynamic Model
 - Pref Controller
 - Plant Controller

Scope of new Modules



- Aerodynamic Model
 - Can only be used with Type 3 wind turbine
- Pref Controller
 - Can be used with any type of generator
 - Existing model LCFB1 is now a Pref Controller
 - Pref Signal Output
 - Feeds into Governor if governor accepts Pref
 - Else feeds into Exciter if exciter accepts Pref
- Plant Controller
 - Can be used with any type of generator
 - Existing model PLAYINREF is now a Plant Controller
 - Vref/Qref Signal Output
 - Vref/Qref signal will feed into Exciter if the exciter accepts it
 - Pref Signal Output
 - Pref feeds into Pref Controller if it exists
 - Else feeds into Governor if governor accepts Pref
 - Else feeds into Exciter if exciter accepts Pref

© 2019 PowerWorld Corporation

17

Error Checking



- Error checking is performed when validation is done
 - Ensure there is only 1 Pref controller defined
 - Ensure there is only 1 Plant controller defined
 - Ensure there is only 1 Aerodynamic model
 - Also note, if an aerodynamic model is required between the stabilizer and the governor (WTGPT_A and WTGT_A), but one is not defined, Simulator assumes a WTGAR_A exists with $K_a = 0.007$ and $\Theta = 0$
- General error checking is done to make sure the model mix makes sense
 - GENTPF can't have a REEC_A "exciter"

© 2019 PowerWorld Corporation

18

Initialization Notes




- Because of the way these various blocks connect together, the initialization order of the blocks is important
 - Example: the “initial speed” of the wind turbine is calculated in different places
 - For 1st Gen Type 3 → WT3E (*Exciter*)
 - For 2nd Gen Type 3 → WTGTRQ_A (*PRef controller*)
 - For 2nd Gen Type 4 → WTGT_A (*Governor*)
 - This is all handled internally by Simulator so the user does not need to be concerned with the order

Where does it appear in GUI



- Machine, Exciter, Governor, and Stabilizer remain prominent
- *Other Models* contain the other categories of modules
- You see it in the Model Explorer
- When inserting a new *Other Model* from the generator dialog
- Plot Designer in Transient Stability Dialog



Model Explorer



The screenshot shows the 'Model Explorer: Generator Other Models' window. On the left is a tree view with 'Generator Other Models' selected. In the center, a table lists models with columns: Fully Supported, Number of Bus, ID, and Name_Nomin. On the right, a detailed view of the 'Gen Other Model' tree is shown, with several sub-folders highlighted by colored boxes: a purple box around 'Aerodynamic Model', a blue box around 'Plant Controller', and a green box around 'Pref Controller'.

Fully Supported	Number of Bus	ID	Name_Nomin
1	YES	41905	1 RE TERM_0.60
2	YES	41905	1 RE TERM_0.60
3	YES	41905	1 RE TERM_0.60

Plot Designer



The screenshot shows the 'Plot Designer' window in the 'Transient Stability Analysis' application. The 'Choose Fields' list on the left is highlighted with a red box. The 'Plots, Subplots, Axis Groups' list on the right is also highlighted with a red box.

- Plant Ctrl State
 - Vmeas
 - Qmeas
 - Reactive PI
 - Qext
 - Pmeas
 - Power PI
 - Pref
 - State 8
 - State 9
- Pref Ctrl State
 - wref
 - Pmeas
 - Integrator
 - State 4

2nd Generation Models



- Type 3 Wind Turbine
 - REGC_A, REEC_A, WTGT_A, WTGPT_A, WTGAR_A, REPC_A, WTGTRQ_A
- Type 4 Wind Turbine
 - REGC_A, REEC_A, WTGT_A, REPC_A
- Solar PV Models
 - REGC_A, REEC_B, REPC_A
 - REEC_B is just a variation of REEC_A with less parameters and features
 - Has been determine that Solar should use REEC_A to model momentary cessation correctly (VDL curves)
- Energy Storage (Battery)
 - REGC_A, REEC_C, REPC_A
- New Pitch Control for Type 1 and 2 Wind Turbines
 - WT1P_B
- Plant Controller with up to 50 machines (and SVCs)
 - REPC_B (similar to REPC_A but has output to 50 devices)

Renewable Energy Models (Wind, Solar, Storage Models)



1st Generation Models

Class of Model Type	Wind Type 1	Wind Type 1	Wind Type 2	Wind Type 2	Wind Type 3	Wind Type 3	Wind Type 4	Wind Type 4	Solar PV
Machine	WT1G	WT1G1	WT2G	WT2G1	WT3G	WT3G1	WT4G	WT4G1	PV1G
Electrical Model			WT2E	WT2E1	WT3E	WT3E1	WT4E	WT4E1	PV1E
Mechanical	WT1T	WT12T1	WT2T	WT12T1	WT3T	WT3T1	WT4T		
Pitch Controller	WT1P	WT12A1	WT2P	WT12A1	WT3P	WT3P1			

2nd Generation Models

Additional Uses

Class of Model Type	Wind Type 1	Wind Type 2	Wind Type 3	Wind Type 4	Solar PV	Distributed PV Model	Energy Storage
Machine	WT1G WT1G1	WT2G WT2G1	REGC_A	REGC_A	REGC_A	PVD1	REGC_A
Electrical Model		WT2E WT2E1	REEC_A	REEC_A	REEC_B		REEC_C
Mechanical	WT1T WT12T1	WT2T WT12T1	WTGT_A	WTGT_A			
Pitch Controller	WT1P_B	WT2P WT12A1	WTGPT_A				
Aerodynamic			WTGA_A				
Prof Controller			WTGTRQ_A				
Plant Controller			REPC_A or REPC_B	REPC_A or REPC_B	REPC_A or REPC_B		REPC_A or REPC_B

3 new classes of models

Detailed Documentation on the “Second Generation” From WECC




- Type 3 Wind-Turbine
 - https://www.powerworld.com/WebHelp/#Other_Documents/WECC-Type-3-Wind-Turbine-Generator-Model-Phase-II-012314.pdf
- Type 4 Wind-Turbine / (Same for Solar/Storage)
 - https://www.powerworld.com/WebHelp/#Other_Documents/WECC-Type-4-Wind-Turbine-Generator-Model-Phase-II-012313.pdf

REGC_A (or REGCA1)

https://www.powerworld.com/WebHelp/#TransientModels_HTML/Machine%20Model%20REGC_A.htm



- “Machine Model”: Really a network interface



REGC_A Description




- This model is doing very little actually
 - Time delay T_g is the entirety of the converter model
 - Crudely, the model says
“Electrical Controller asks for a real and reactive current \rightarrow 0.020 seconds later the converter creates this”
 - We are NOT modeling any of the power electronics at all
 - We are not modeling any phase-locked-loop (PLL)
 - Our assumption is all of that stuff is really fast
- “High Voltage Reactive Current Management” and “Low Voltage Active Current Management”
 - These are a dubious names because we aren’t modeling things in enough detail to really have “control” here
 - This control happens in the less than 1 cycle time-frame!

© 2019 PowerWorld Corporation

27

What is Happening? Voltage and Mvar Spike



September 13, 2019 17:42:21

28

High Voltage Reactive Current Management




- What is Happening?
 - During the fault, the REEC* model control is going to push the reactive current command to a large value
 - It's trying to pull the voltage up as best it can!
 - Then the fault clears and the voltage pops back up
 - The current command is still high
 - The command goes through a time-delay of T_g (0.020 normally)
 - Thus higher voltage, High reactive current
 - → Giant Mvar output and a voltage spike!
- In an actual converter it would detect this extremely fast system changes and prevent this spike
 - I suspect you'd still see the spike, it just wouldn't last so long

High Voltage Reactive Current Management



- Power electronics are going to protect the equipment
 - If a high voltage (parameter V_{lim}) is detected then the reactive current will drop (and go negative) nearly instantaneously to prevent damage
 - This must be handled in the network boundary equations actually
 - If voltage goes above this threshold, then we model a reactive current that puts the voltage nearly exactly at this V_{lim} limit

Vlim = 1.15




© 2019 PowerWorld Corporation

31

Low Voltage Current Management

- Immediately after a fault occurs, the numerical simulation is going to be pushing current into a fault (0.0 voltage)
- That is both not possible AND will make the software fail to solve
- This is parameter are for
 - Lvpnt0 and Lvpnt1
 - Do NOT set these to 0.0!
 - (Simulator won't allow them lower than 0.2 and 0.4)



© 2019 PowerWorld Corporation

32


REGC_B (Beta Model)

https://www.powerworld.com/WebHelp/#TransientModels_HT ML/Machine%20Model%20REGC_B.htm

“Machine Model”: Really a network interface

Rate limits on reactive current for recovery after fault.
Upward limit is active when $Q_{gen_0} > 0$
Downward limit is active $Q_{gen_0} < 0$

I_Q = per unit current that corresponds to reactive power
 I_P = per unit current that corresponds to real power
 $I_P + jI_{Qneg}$ = desired current injection in phase with terminal voltage
 E_d = per unit voltage in phase with terminal voltage
 E_q = per unit voltage out of phase with terminal voltage
 V_{last} = per unit terminal voltage magnitude at last time step
 θ = per unit terminal voltage angle at the terminal bus




33

REGC_C (Beta Model)

https://www.powerworld.com/WebHelp/#TransientModels_HT ML/Machine%20Model%20REGC_C.htm

“Machine Model”: Really a network interface

Rate limits on reactive current for recovery after fault.
Upward limit is active when $Q_{gen_0} > 0$
Downward limit is active $Q_{gen_0} < 0$




34

REEC_A (same as REECA1)

https://www.powerworld.com/WebHelp/#TransientModels HT ML/Exciter%20REEC_A.htm

- Warning!**
 Extreme care should be taken in coordinating the parameters dbd1, dbd2 and V_{dip} , V_{up} so as not to have an unintentional response from the reactive power injection control loop.

Electrical Model




REEC_A Description

- First thing you must do is choose the control strategy
 - Voltage, Reactive Power, Constant Power Factor
 - When current limit is hit, do you have a preference to keep real power or reactive power up?
 - You can NOT “tune” these parameters!
- After than you set the PI controller parameters
 - Be careful not to set the K value too large. Large K means a very fast controller

REEC_B (same as REECB1)

https://www.powerworld.com/WebHelp/#TransientModels_HT ML/Exciter%20REEC_B.htm


Electrical Model



37

REEC_C (Model for Storage)

https://www.powerworld.com/WebHelp/#TransientModels_HT ML/Exciter%20REEC_C.htm



38

REEC_D (New Electrical Model)

[https://www.powerworld.com/WebHelp/#TransientModels HT ML/Exciter%20REEC_D.htm](https://www.powerworld.com/WebHelp/#TransientModels_HTML/Exciter%20REEC_D.htm)

Warning!!
Extreme care should be taken in coordinating the parameters dbd1, dbd2 and V_{dip} , V_{up} so as not to have an unintentional response from the reactive power injection control loop.

Parts of the block diagram in red text or red lines represent differences between REEC_D and REEC_A


Qext Input from REPC* Plant Controller
(Qext is initialized to a constant, or can be connected to an external model. It may represent a voltage or reactive power)

- States**
- 1 - Vmeas
 - 2 - Pmeas
 - 3 - PIQ
 - 4 - PIV
 - 5 - Q_V
 - 6 - Pord
 - 7 - Vcomp

Pref Input from REPC* Plant Controller

wg Input from WTGT* mechanical

(P_ref is initialized to a constant, or can be connected to an external model)



Iqfrz and Thld Parameters
If Thld = 0 – no other action is taken.
If Thld > 0, then for Thld seconds following a voltage dip (i.e. voltage_dip goes from 1 back to 0) Iqcmd is held at its current value (i.e. value just prior to the end of the voltage_dip) for Thld seconds and is then released.
If Thld < 0, then for Thld seconds following a voltage dip (i.e. voltage_dip goes from 1 back to 0) Iqcmd is held equal to Iqfrz for Thld seconds and is then released.

Outputs REEC* machine model
 I_{qcmd}

Outputs REEC* machine model
 I_{pcmd}


REEC_D

- Added voltage compensation
- Added charging support ($K_e > 0$)
- VDLp and VDLq tables have 10 points and treatment when $I_{qmax} < 0$ means $I_{qmin} = I_{qmax}$

- Better support for momentary cessation modeling
- This is also why the REEC_B model is no longer recommended for Solar modeling

Example VDLp and VDLq tables showing negative Iq5 value
Vp1=0.00; Vp2=0.15; Vp3=0.46; Vp4=0.67; Vp5=1.21; Vp6=1.40
Ip1=0.00; Ip2=1.00; Ip3=1.00; Ip4=1.30; Ip5=1.30; Ip6=0.00
Vq1=0.00; Vq2=0.20; Vq3=0.72; Vq4=1.00; Vq5= 1.20; Vq6= 1.40
Iq1=1.20; Iq2=1.20; Iq3=0.50; Iq4=0.50; Iq5=-1.20; Iq6=-1.20

Figures at bottom show different values of Ke parameter.
 $I_{pmin} = -K_e I_{pmax}$




WTGT_A and WTDTA1

https://www.powerworld.com/WebHelp/#TransientModels_HTML/Governor%20WTDTA1.htm
https://www.powerworld.com/WebHelp/#TransientModels_HTML/Governor%20WTGT_A.htm



- Mechanical Model (models turbine blades and induction inertia)




41

WTGPT_A (WTGP_A or WTPTA1)

https://www.powerworld.com/WebHelp/#TransientModels_HTML/Stabilizer%20WTGPT_A.htm



- Pitch Controller




WTGPT_B

[https://www.powerworld.com/WebHelp/#TransientModels HT ML/Stabilizer%20WTGPT B.htm](https://www.powerworld.com/WebHelp/#TransientModels_HT ML/Stabilizer%20WTGPT_B.htm)



• Pitch Controller




43

WTGAR_A (WTGA_A and WTARA1)

[https://www.powerworld.com/WebHelp/#TransientModels HT ML/Aerodynamic%20Model%20WTGAR A.htm](https://www.powerworld.com/WebHelp/#TransientModels_HT ML/Aerodynamic%20Model%20WTGAR_A.htm)



• Aerodynamic Model




Model supported by PowerWorld
 Named WTGA_A in PSLF
 Named WTARA1 in PSS/E

WTGTRQ_A (WTTQA1)

https://www.powerworld.com/WebHelp/#TransientModels_HTML/Pref%20Controller%20WTGTRQ_A.htm



- Torque Controller for Wind Turbine
- Normal Recommendation is Tflag = 0 as this includes the lookup table of speed from Power




REPC_A (REPCA1, REPCTA1)

https://www.powerworld.com/WebHelp/#TransientModels_HTML/Plant%20Controller%20REPC_A.htm



- Plant Controller




- Model supported by PowerWorld
- Model is named REPC_A in PSLF
- Model is named REPCA1 when used with Type 4 wind turbine in PSS/E
- Model is Named REPCTA1 when used with a Type 3 wind turbine in PSS/E

Renewable Generator Questions started in 2013



- Renewable generators regulate a point closer to the point of interconnection





- They regulate the voltage at the POI (the 115 kV bus) against a QV characteristic curve
- Starting to get questions about Solar PV plant voltage control

Typical Configuration may have multiple Generators



Generators are all configured to regulate the Controlled Bus




Slope Control with Deadband



- Getting questions about solar and wind farms that have voltage control that is not a setpoint
- **A deadband is given**
 - 0.98 to 1.02 per unit voltage – provide zero Mvars (or a constant value)
- Once outside these deadband, a negative slope characteristic is followed
- Maximum and Minimum Mvar will be hit eventually

REPC_A has this Voltage Droop Control with Deadband!



2nd Generation Type 3 Wind Turbine

(REGC_A, REEC_A, WTGT_A, WTGAR_A, WTGPT_A, WTGTRQ_A, REPC_A)



2nd Generation adds the Aero,
PRef and Plant Controllers

